尺寸:405mmX126mm

材质: 157g 双铜 风琴折页 折叠式双面打印



Massage gun is a portable and rechargeable vibration massage device with high torque, long battery life and Multi-position adjustment features. It can effectively alleviate the soreness caused by lactic acid accumula after strenuous exercise, and slow down the discomfort of the muscles of all the people who have been sitting for a long time.

Safety Precautions

Pay attentionYou must understand the following before use, otherwise it may cause damage or danger!

About the use of people and parts

- 1. Only for healthy adults except the elderly;
- 2. Use the product only on the soft tissues of the body without causing pain or discomfort: 3. Do not use on the head, or any part of the body that is hard or has
- 4. Whether it is restrained pressing down or applying pressure bruises may occur. Check the massage area frequently, Once there are signs of pain or discomfort, stop using it immediately.
- and back of the vibrating head, because they may be pinched:

Only dry, Use on clean skin surface, gently press and move on the

- Do not use it near the bones with less muscle coverage, such as: tibia, back of feet, back of hands; 7. Do not use in and around the following sensitive parts: eyes, teeth, breast augmentation, reproductive organs, artificial limbs
- 8. Do not use the product on any possible fracture site: 9. If the pain is persistent, stop using it immediately and consult a doctor. This product is not a medical device and is not recommended for medical use, and is not intended for medical

- 1. The vibrating head that can produce the most ideal effect should be used;
- 2. Do not place any objects in the ventilation holes of the product;
 3. Don't flood into the water, and don't let water enter the ventilation holes of the product:
- 5. Before use, carefully check the operating status of the host. battery, charger, etc., to ensure that it can meet normal use. 6. Do not change or modify the product in any way;
- 7. Never let the product run or charge unattended 8. It is forbidden to start the device during the charging process;
- 9. It is forbidden to throw the equipment into the fire

About the battery

1. Do not put the battery in water or get it wet!

- 2. It is forbidden to charge the battery under fire or extreme heat conditions! Do not use near heat sources (such as fire or heaters) Or store the battery! If the battery leaks or emits a peculiar smell, immediately move it away from the open flame!

 3. Do not throw the battery into the fire or heat the battery!
- 4. It is forbidden to short-circuit the positive and negative electrodes of the battery with wires or other metal objects, and it is forbidden to connect the battery with necklaces or hairpinTransport or store together with other metal objects!
- not pierce the battery shell with nails or other sharp objects, and do not hammer or pedal the battery!
- 6. It is forbidden to hit or throw the battery! 7. It is forbidden to disassemble the battery in any way!
- 8. It is forbidden to put the battery in a microwave oven or pressure

- 1. Before the first use, charge for about three to four hours, fully charge it, and you can connect to the device while charging. To disconnect the device;
- 2. The battery can be charged at any power level; please make sure the massager is off when charging, When the device is running, the charging will automatically protect;
- 4. The average running time of the equipment after loading is about four hours, which depends on the vibration frequency during the song And applied pressure.

Technical Parameters

Product name: MASSAGE GUN Product model: NPMGUN-006

The structure is mainly composed of a control part and a

Amplitude: 10mn

Rated power: 55.08Wh Rated voltage: 24 V

Battery capacity: 2550mAh Timing: 15 minutes smart timing

The instrument has an output control function switch The massage head can be replaced as needed




Add: 601 6/F, Tung Hip Commercial Building, 248

Des VoeuxRoad Central, Sheung Wan, Hong Kong

Aukey International Limited

Web: www.naipocare.com

E-mail: wholesale@naipocare.com




Massage head * 6



Instructions for use

***Instructions for use**



1.0pen the button on the bottom of massage gun

2.Press the button to power on and start running.
3.The keys"+ ""-"canadjust for the levels from 1-20.

4.When the battery charge is less than 20%, the bottom line of the machine is shown in red;when the battery is less than 10%,lf the "E1" is displayed in the battery display window, it will not work and you need to charge it immediately

5.Power display changes from 01 to 10 in successively when charging, and reaching to 10 meahspower charging ful. At the sametime, When the battery is fully charged, the light line at the bottom of the machine

6. This device has a timing function and automatically stops running after 15 minutes of operation

7.When the massage head is strongly pressed to stop the motor, the device starts theautomatic protection function and the machine stops.Run, the frequency is displayed as "E4", it can be used normally after the machine

8.Turn "ON" the device at the bottom of battery. Note that if you don't do anything within 3 minutes, the device will be standby mode. You can restart it by press any key on the screen or turn the switchat the bottom

Malfunctions and warranty, etc.

- Clean the equipment with a slightly damp towel, and then wipe
- If the equipment is uncertain for a long time, please store it in the box; • Do not remove screws or attempt to disassemble the device;
 • In order to make the new battery achieve the best use effect in a short
- period of time, you can complete three times or more Charge and

Product installation and transportation storage condition:

- Product installation condition • Temperature: 5℃—40℃
- Relative humidity: W90%;
- Atmospheric pressure: 70kPa~106kPa;

transport

- Ambient temperature: -20°C~+50°C
- Relative humidity: W90%:
- This product is suitable for transportation by automobiles, trains, ships, and airplanes; The product should be fixed during transportation to prevent
- violent vibration, collision, rolling and falling, and upward,
- The number of layers of massagers must not exceed 5;

- The massager should be stored in a well-ventilated, non-corrosive gas warehouse, 250mm above the ground;
- The number of layers of massagers must not exceed 5;

 When the massager is not used for a long time, it should becleaned
- and packaged and stored, and it is best to take it out every month; Charge once to prevent moisture.

and man-made damag e is not covered by the warranty.

Precautions when disposing of the productPlease support the recycling of Yandian batteries



The battery used in this product is a special rechar geable battery. It should not be used in otherproducts. Do not charge the removed rechargeable • Do not throw into the fire, so that it will be

overheated: overheated;
Do not pierce with nails, impact by gravity or carry out decomposition and transformation;
Do not connect the positive and negative poles

of the battery directly with metal Do not store it together with necklaces,

Do not use and place lice in high temperature

Please keep the removed rechargeable battery out of the reach of infants and young children.

If there is a situation of being stolen, please consult a doctor immediately;

When the battery liquid leaks, please do not touch

the liquid with bare hands, and handle it according to the following methods:



according to the following methods;

• When the battery fluid enters the eyes, there is a risk of blindness. Do not rub your eyes directly with your hands. You need to wash them with clean water immediately and consult a doctor for treatment. When the battery fluid gets into your body into clothing, it may cause skin irritation or injury. , Please rinse with clean water. If you still feel unwell, you need to find the source of return immediately.

• The product can only be disassembled when it is

The product can only be disassembled when it is discarded. If you ignore it, it may cause accidents such as mosquitoes, electric shocks, and injuries. If you need to repair it (except in the case of replac ing the battery), please consult the original seller.

