

ACWVO®



EARBUDS
DwOTS X
Manual



Appearance:

- ① Left Earbud
- ② Right Earbud
- ③ Charging Case
- ④ Left Earpiece Charging Socket
- ⑤ Right Earpiece Charging Socket
- ⑥ Type-C Charging Interface
- ⑦ Multi-Function Touch Area
- ⑧ Type-C Dongle

What Will You Find In The ACwO Box?

- Charging Case
- Pair of ANC Earbuds
- Type - Dongle
- Type-C Charging Cable
- Warranty Card
- Scan Me Card
- ACwO X Sunil Chhetri Catalogue
- Comfortable Ear Tips

Product Features:

- 50 Hours of Music Playtime
- PURE AUDIO™ ANC Upto 32dB
- Dual Wireless Connectivity (Bluetooth + 2.4GHz Type-C Dongle)
- Quad Mic With ENC
- Near Zero Lag 2.4GHz Connection
- Advanced Audio Codec
- 13mm BaS BooM X™ Hi-Fi Drivers

- IPX5 Water & Sweat Resistant
- Instant Auto Connect
- Bluetooth V5.4 Technology
- HYPERBOOST™ 10Mins Charge = 120 Mins Playtime

Safety Guidelines:

- Please refrain from dismantling the product or attempting to remove its battery. Such actions can pose a fire hazard or cause electrical malfunctions. Seek the services of a qualified technician or the manufacturer for any necessary maintenance or repairs.
- When cleaning the earbuds, exercise caution by using a damp, soft cloth. Avoid using any oily or volatile liquids for cleaning purposes. Additionally, ensure that the earphones are kept away from extreme temperature conditions, both hot and cold.
- Please be aware that any damage to the earbuds that is not attributed to a manufacturing defect will render the product's warranty null and void.
- Do not wear them in situations where it is unsafe, such as when operating a vehicle, crossing streets, or engaging in activities requiring full situational awareness.

- To safeguard your hearing, ensure that the volume on your music player is set at an appropriate level when using the earphones. Prolonged exposure to high noise levels can gradually lead to hearing impairment.
- Do not wear the earbuds for a long period of time as it can lead to possible hearing loss or major hearable issues.

ACwO DwOTS X

Kindly Note:

- Please take off the sticker peels attached below the earbuds before you charge them.
- Charge the charging case and the ACwO DwOTS X Wireless Earbuds at least 70% before the first usage.

Charging:

- Charging Case:
Connect the type-c charging cable to the charging case to charge your ACwO DwOTS X Wireless Earbuds.
- Earbuds:
Place the earbuds in the charged Charging Case to charge the ACwO DwOTS X Wireless Earbuds.

Bluetooth Pairing Process:

- Take out the ACwO DwOTS X Earbuds from the Charging Case and place them in your ears.

- Go to the Bluetooth settings of your device and switch it on.
- Scan available devices.
- Search For " ACwO DwOTS X" from the list of available devices.
- Pair " ACwO DwOTS X" from the list and your Earbuds will be connected.

Once you've completed the initial pairing process, the ACwO DwOTS X will connect seamlessly to your device every time you open the charging case.

Kindly Note - If the earbuds are not in use and are left outside the charging case, they will automatically turn off after approximately 5 minutes

How To Connect With Type-C Dongle:

Remove the Type-C Dongle from the charging case.

- Insert the Type-C Dongle into the Type-C port of your device.
- The device will automatically connect to your DwOTS X earbuds.

Alternative Connection Method:

If your device does not connect automatically:

- Go to your device's Settings.
- Select System Settings.
- Tap on OTG Connection and switch it on.
- Your DwOTS X earbuds will then automatically connect to your device.

(You can connect your DwOTS X Type-C Dongle to any device with a Type-C port, including tablets, smartphones, gaming devices like the PS5, and other compatible devices.)

Bluetooth Reset Process: ACwO DwOTS X

- In case your earbuds encounter pairing issues or if only one earbud is functioning, you can easily perform a reset.
- Clear all Bluetooth data named "ACwO DwOTS X" from your device and disable Bluetooth.
- Place the earbuds back into their charging case and then remove them to initiate the Bluetooth pairing process once more.

How To Use Your ACwO DwOTS X?


Touch Controls: The Multi-FunctionTouch Area, often referred to as the "Touch Area," is situated on the upper section of the earbud's handle.

Smart Functions ACwO DwOTS X

- Play/Pause:
Single Tap on Multi-FunctionTouch Area of either earbud.
- Next Track
Double Tap on the Multi-Function Multi-FunctionTouch Area of left earbud.

- Repeat / Previous Track:
Double Tap on the Multi-Function touch area of the right earbud
- Switch Between Transparency/ ANC Mode:
Tap and Hold the Right Earbud to switch between Transparency, ANC and Normal Mode.
- Switch Between Bass / Theatre / Normal Mode:
Tap and Hold Left Earbud to switch between Bass / Theatre / Normal Mode.
- To Answer Calls:
Single tap on the Multi-Function Multifunction Touch Area of either earbud.
- To Hang Up Calls:
Single tap on the Multi-Function Multi-FunctionTouch Area of either earbud.
- To Decline Calls:
Double Tap on the Multi-Function Multi-FunctionTouch Area of either earbud.
- Increase Volume:
Triple Tap on the Multi-Function Touch area of the right earbud.
- Decrease Volume:
Triple Tap on the Multi-Function Touch area of the left earbud.

- Voice Assistant:
Tap Four times on the Multi-Function Touch Area of either earbud.
- Power Off Left/Right Earbud:
Tap and hold for 5 seconds on the Multi-Function Multi-function Touch Area of either earbud.
- Power On Right Earbud:
Tap and hold for 5 seconds on the Multi-Function Multi-function Touch Area of the right earbud
- Power On Left Earbud:
Tap and hold for 5 seconds on the Multi-Function Multi-function Touch Area of the left earbud



TRUSTED BY THE LEGEND OF
INDIAN FOOTBALL TEAM

Sunil Chhetri