



SINCERE GRATITUDE

As a manufacturer, we are committed to provide you complete customer satisfaction. If you have any questions, or find there are missing or damaged parts, please contact us and we guarantee you complete satisfaction. Please attach your user name, order ID, where you buy this product, details of your problem, you can mark the broken/missing parts on the instruction book, and take a photo to show us, so that we can assist you better.

STORAGE:

Remove all holiday decorations. Gently press tips back into center branch. Raise all branches to original upright position taking care not to place undue pressure on the attached ends of the branches. When disassembling tree, a twisting motion will help to separate the sections from each other. All tree parts can be replaced in carton and should be stored in a cool, dry place.

NOTE

After assembly, it takes 30 to 45 minutes to arrange the leaves. After assembly, you need to hang the decorations on the tree by yourself.

Use the camera in your mobile phone or a QR code scanning tool to scan the QR code below, and directly enter our YouTube video library.
(Note: If the QR code scanning fails, you can manually enter the link: <https://www.youtube.com/@ChristmasDecoration-VCD/videos>)



Video Installation Guide

- Christmas - themed Products

Dear customers,

Thank you for purchasing our Christmas series products! To ensure that you can assemble the products smoothly, we have provided you with exclusive video tutorials. Please follow the steps below to search for the assembly videos of the corresponding products:

Step 1: Scan the QR code to access the video library.

Use the camera in your mobile phone or a QR code scanning tool to scan the QR code below, and directly enter our YouTube video library.
(Note: If the QR code scanning fails, you can manually enter the link: <https://www.youtube.com/@ChristmasDecoration-VCD/videos>)



Step 2: Search for the SKU code of your product.

1. After entering the video library page, click on the search bar at the top (magnifying glass icon).
2. Enter the SKU code of your product (e.g., XMAS-1192-2023), and press the Enter key to search.
3. Locate the video in the search results that matches the name of your product, and click to play it to watch the complete assembly tutorial.
4. Find the video in the search results that matches the name of your product, click to play it, and then you can watch the complete assembly tutorial.

Notes

- Make sure the entered SKU code is completely identical to the label on the product packaging (case-sensitive and pay attention to hyphens).
- Please check your network connection before operation. If the loading is slow, you can try refreshing the page.
- It is recommended to watch the high-definition video in a Wi-Fi environment to save mobile data.
- The product videos demonstrate the assembly process of the same or similar products. Although there may be differences in product appearance, the assembly methods are identical.

Can't find the video?


1. Check whether the SKU code is entered incorrectly.
2. Visit our customer service center (support@vinkl.com), and provide the SKU code. We will send you a direct link.




NOTICE

1. Do not use seasonal products outdoors unless marked suitable for indoor and outdoor use.
2. This seasonal use product is not intended for permanent installation or use.
3. Do not mount or place near gas or electric heaters, fireplace, candles or other similar sources of heat.
4. If you use other light product to decorate the Christmas tree, please use it safely.
5. Do not use this product for other than its intended use.

HARDWARE



PARTS




NOTE: Wires may come wrapped around frame pieces. Locate and unwrap wires before assembly.



Please be careful at the connection, the interface at the top is different from other parts.

PRODUCT ASSEMBLY

Assemble the tree.
NOTE: Bottom section is wider than the middle section.
Make sure sections are arranged in the correct order.



FOR 5FT/ 6FT/ 7FT TREE

FLUFFING INSTRUCTIONS

For an optimum appearance and satisfaction, this product **MUST** be fluffed according to the following directions
NOTE: start from the interior and work outward

1. Find the innermost branch tips and pen them in a "V" shape



2. Open the next set of (3) branch tips with pointing outward and one pointing up.



3. Open the next set of (4) branch tips with two pointing outward and two in a wide "V" shape.




4. Open the next set of (5) branch tips in a five-pointed "star" shape.



FLUFF TIME (APPROXIMATE)

Christmas Trees	15-80 min.
Wreaths	15-30 min.
Garlands	10-20 min.

LED INSTRUCTIONS



Lighting control buttons and instructions are on the plug