

键盘用户手册 5108 (B-PLUS) (

User Manual






感谢您购买及使用本产品



为了给您带来更好的使用体验,在使用产品前请仔细阅读本说明书,并请妥善保管,以便日后参观。

包装内容





系统需求

Windows®XP / Vista / 7 / 8 / 10或更高版本

华太 埃尔托位置

安装步骤

将键盘USB连接线插入电脑的USB接口即可开始使用。

独立指示灯

-DC/GC	追いいは巨	44	BUAJ	ÆIXM93
BT1	按键E灯	蓝色慢闪	蓝色快闪	蓝灯常亮2s熄灭
BT2	按键R灯	蓝色慢闪	蓝色快闪	蓝灯常亮2s熄灭
BT3	按键T灯	蓝色慢闪	蓝色快闪	蓝灯常亮2s熄灭
2.4G	按键Y灯	绿色慢闪	绿色快闪	绿灯常亮2s熄灭
有线	按键U灯	无	无	红灯常亮2s熄灭
状态	指示灯位置		指示方式	
低电	独立指示灯3	白灯慢闪		
充电	独立指示灯3	白灯常亮		
充满	独立指示灯3	灯灭		
Caps	独立指示灯2	白光常亮		
锁Win	Lwin鍵	白光常亮		
Num	独立指示灯1	白光常亮		


5108B Plus 组合键功能



	F1	我的电脑
	F2	电子邮件
Fn+	F3	Windows搜索
	F4	浏览器主页
	F5	多媒体播放器



5108B Plus 系统功能 (Windows)



锁Win键

Fn + 左Win

恢复出厂设置

长按 左Win + 右Win 5秒

切换菜单键

长按 Fn + 右Ctrl 3秒

5108B Plus 系统功能 (Mac)



F1 隆低显示屏高度

F2 增加显示屏高度

F3 开放任务控制

呼出Siri F4

Command 右Alt

右Win Option F7 上一曲

F8 播放/暂停

F9 下一曲

F10 静音

Fn + (F1 ~ F12)

F1 ~ F12

F11 音量-


音量+ F12

Option 左Win

左Alt

Command

5108B Plus 灯光调节



Fn+-灯光速度变慢 Fn+= 灯光速度变快

Fn+↑ 灯光变亮

Fn+↓ 灯光变暗

Fn+← 灯光方向向左

Fn+→ 灯光方向向右

灯光关闭/开启 Fn+L

Fn+lns

Fn+\

常亮(默认)、流星、呼吸

Fn+Home 涟漪、如影随形、川流不息 Fn+PgUp 繁星点点、霓虹、光波、层出不穷

Fn+Del 彩泉涌动、峰回路转、百花争艳


Fn+End 极光、正弦波、雨滴


Fn+PqDn

斜风细雨、踏雪无痕、聚合、一石二鸟

切换背光致7种单色+RGB循环

5108B Plus 连接使用指南





蓝牙配对

键盘开机后,按下Fn+E/R/T进入蓝牙模式,长按Fn+E/R/T组合键3S,键盘进入对码状态,蓝色指示灯快闪,连上后指示灯常亮2S,如果没有连上设备指示灯熄灭,键盘进入睡眠。

2.4G配对

键盘开机后,按下Fn+Y进入2.4G模式,再按下Fn+Y组合键3S进入配对模式后,插入接收器,指示灯快 闪,配对成功后退出对码,模式灯常亮2S,找不到配对设备30s后,退出对码模式灯熄灭,键盘进入睡 眠。

电量查询

按下组合键Fn+空格, 电量低于30%空格键上红光; 30-50% 空格键上提示为橙色; 50-70 空格键上提示为紫色; 70-90% 空格键上提示为黄色; 90-100% 空格键上提示为绿色。

按键/灯光自定义说明和调用说明

- 1. 键盘三种工作模式下均可连接驱动并进行灯光和按键自定义
- 2. 键盘三种工作模式下可搭配驱动实现音乐律动
- 3. 请在我司官网下载"Akko Cloud"驱动
- 4. 驱动下载地址www.akkogear.com

Akko保修和服务声明

- Akko为中国大陆的客户提供一年保修。对于其他地区, 请联系您的卖家(Akko分销商)以了解具体的保修政策。
- 如果保修期到期,客户需要支付维修费用。如果用户喜欢自己修理键盘, Akko也会提供说明。用户应对自行修复过程中发生的任何损失承担全部责任。
- 3. 在未经制造商/卖方指示的情况下拆开键盘将立即导致保修无效
- 4. 官方售后服务时间为每周一至周五上午10: 00至下午18: 00 节假日以国家法定节日休息为准。
- 5. 退货和保修政策在不同的平台上可能有所不同,并在购买时取决于具体的经销商。

公司:深圳银宸科技有限公司

地址:深圳市宝安区松岗街道碧头第一工业区朗碧路33号

电话: 0755-23216420 网址: www.akkogear.com

产地:中国•深圳

Company: Shenzhen Yinchen Technology Co., Ltd

Address: 33 Langbi Rd, Bitou First Industrial Zone, Bao'an District, Shenzhen, China

WARNING Water and Bev

the Keyboard.

(€ F© 🗘 🗵

中国制造/Made in China


注意 事项 人为损坏不局限于键盘进水、高处坠落、过度用力拉扯线材等,键盘为电子产品 请按照电子产品保护方式爱惜使用。



To provide you with a better user experience, please read this manual carefully before using the product.

Packing List





System Requirement

Windows®XP / Vista / 7 / 8 / 10 or higher version

Side LED Indicator 3

Side LED Indicator 2

Lwin key

Side LED Indicator 1

Connectivity Method

Connect the keyboard to your computer by plugging in the USB cable into an available USB port to start using it.

LED Indicators

Fully Charged

Caps Lock Win

Num

State	Indicator	Re-Connecting	Pairing	Connected
Bluetooth device 1	LED for Key E	Blue light blinks slowly	Blue light blinks fast	The blue light is off 2s
Bluetooth device 2	LED for Key R	Blue light blinks slowly	Blue light blinks fast	The blue light is off 2s
Bluetooth device 3	LED for Key T	Blue light blinks slowly	Blue light blinks fast	The blue light is off 2s
2.4G wireless device	LED for Key Y	Green light blinks slowly	Green light blinks fast	The green light is on for 2 seconds
Wired mode	LED for Key U	N/A	N/A	The red light turns off for 2 seconds
Status	Indicator		Indicating mo	ode
Low Battery	Side LED Indicator 3	White light blinks slowly		
Charge	Side LED Indicator 3	Steady white		


LED OFF

Steady white

Steady white

Steady white


5108B Plus HotKeys



	F1	File Explorer
	F2	E-mail
Fn+	F3	Windows Search
	F4	Browser Homepage
	F5	Media



5108B Plus System Commands (Windows)



Press Fn and
Left Win Key


Restore Factory Settings

Hold down Left Win and press ~ Key for 5S

Revert Ctrl into Menu Key

Hold down Fn and press right Ctrl for 3S

5108B Plus System Commands (Mac)




Ĺ					
F1	Decrease display brightness	F7	Skip back (Audio)	F11	Decrease Volume
F2	Increase display brightness	F8	Pause/Play (Audio)	F12	Increase Volume
F3	Open mission control	F9	Skip forward (Audio)	Left Win	Option
F4	Activate Siri	F10	Mute	Left Alt	Command

Right Alt	Command	
Right Win	Option	




5108B Plus Backlight Settings



Fn+-	Slower Animation	Fn+Ins	Effect 1, Effect 2, Effect 3
Fn+=	Faster Animation	Fn+Home	Effect 4、Effect 5、Effect 6
Fn+↑	Bright	Fn+PgUp	Effect 7、Effect 8、Effect 9、Effect 10
Fn+↓	Dim	Fn+Del	Effect 11、Effect 12、Effect 13
Fn+←	Set animation direction to left	Fn+End	Effect 14、Effect 15、Effect 16
Fn+→	Set animation direction to right	Fn+PgDn	Effect 17、 Effect 18、 Effect 19、 Effect 20
Fn+L	Light Off/On	Fn+\	This shortcut allows you to set the backlight color to 7 single color with RGB loop effect

5108B Plus Connection usage Guide





Bluetooth Pairing

After turning on the keyboard, press Fn+E/R/T to enter Bluetooth mode. Press and hold the Fn+E/R/T combination key for 3 seconds to put the keyboard in pairing mode, with the blue indicator light flashing quickly.

After successful pairing, the keyboard will enter a low-power sleep mode after being idle for 2 minutes. The keyboard will enter the hibernate state 15 minutes after entering the low-power sleep mode.

2.4G Pairing

After turning on the keyboard, press Fn+Y to enter 2.4G mode. Then press and hold the Fn+Y combination key for 3 seconds to enter pairing mode. Then insert the receiver, and the indicator light will flash quickly. After successful pairing, the keyboard will enter a low-power sleep mode after being idle for 2 minutes.

The keyboard will enter the hibernate state 15 minutes after entering the low-power sleep mode.

Battery Level Check

Key/Lighting Effects Customization Instruction

- 1. The driver can be connected and lighting and key can be customized under the three working modes of the keyboard
- 2. The three working modes of the keyboard can be matched to drive the music rhythm
- 3. Please download the Akko Cloud driver on our website
- 4. Users can download the driver via en.akkogear.com

AKKO Warranty and Service Statement

- Akko provides One-Year warranty for customers in mainland China. For other regions, please contact your seller (Akko distributor) for specific warranty policy.
- If the warranty window expires, customers need to pay for repairs. Akko will also provide instructions if users prefer to repair the keyboard by themselves.
 - However, users shall take full responsibility for any loss happened during self-repair.
- Dissembling the keyboard without manufacturer/seller's instruction will immediately void the warranty.
- The return and warranty policy may vary in different platforms and are subject to the specific distributor at the time of purchase.

Company: Shenzhen Yinchen Technology Co., Ltd

Address: 33 Langbi Rd, Bitou Community 1st Industrial Zone, Bao'an District, Shenzhen, China

Tel: 0755-23216420

Website: www.akkogear.com Origin: Shenzhen, China





中国制造/Made in China

Precautions

Man-made damage is not limited to immersion, falling off, and pulling off the wires with excessive forces, etc.







@akkogear



