

CONTACT US

Email

support@aurizen.com

Phone

+1-887-218-4830 (Mon-Fri: 9:00 to 7:00 EST)

Have you read and understood these four places carefully for assistance?

Hey Google

EAZZE D1 MAX

USER MANUAL

ENGLISH

01-19

ENGLISH

Tutorial Videos

CONTENTS

TROUBLESHOOTING GUIDE

01

READ BEFORE USE

02

IN THE BOX

03

PRODUCT OVERVIEW

03

Projector

03

Remote Control

04

QUICK START

05

1. Projector Installation

05

2. Power On/Off

06

3. Remote Control Pairing

06

4. Setup Wizard

07

5. Image Adjustment

07

PROJECTOR CONNECTION AND INPUT SOURCE

11

WiFi CONNECTION

11

GOOGLE ASSISTANT

12

GOOGLE CAST™

12

BT SPEAKER MODE

14

MORE SETTINGS

14

PROJECTION DISTANCE AND SIZE

15

SPECIFICATION

16

7. Connect the BT device

Go to **Homepage** > **Dashboard** > **All settings** > **Remotes & Accessories** to check the BT device list, and connect the device.

8. Power adapter getting warm

It's normal for the power adapter to generate heat during use. It's been tested and meets safety standards. Rest assured.

9. How to avoid audio lag when using BT?

It's normal to get rid of the lag, we suggest you mirror your device to the projector via a wired connection. Additionally, please move your BT device closer to the projector in order to minimize interference in the environment.

10. Warm air blowing from the projector's vents

The projector vents warm air as part of its normal cooling process to prevent overheating and maintain optimal performance.

11. Other

Please feel free to contact us via email.

READ BEFORE USE

Please read the Product Instructions carefully.
Thank you for purchasing and using this product.
For your safety and interests, please read the Product Instructions carefully before using the product.

About the Product Instructions:
The trademarks and names mentioned in the Product Instructions are the property of their respective owners.
All Product Instructions shown are for illustration purposes only. The actual product may vary due to product enhancements.
We shall not be liable for any personal injury, property damages, or other damages caused by the failure of the user to comply with the Product Instructions or precautions.

Aurizen reserves the right to interpret and modify the Product Instructions.

IN THE BOX

Projector

Remote (Batteries Not Included)

Power Adapter

User Manual

PROJECTOR OVERVIEW

Projector

IR Receiver

Adjustment Sensor

Keypad

Lens

Foot Pad (Mounting screw hole underneath)

Remote Control

1. Power

2. Google Assistant

3. User Profile

4. OK

5. Back

6. Focus Adjustment

7. Mute

8. Streaming Apps

9. Indicator Light

10. Input Source

11. Settings

12. Navigation

13. HD Quick Switch

14. Home

1. Projector Installation

Front Desktop

Rear Ceiling

Rear Desktop

Front Ceiling

Notes:
Go to **Homepage** > **Dashboard** > **All settings** > **Projector** > **Advanced Settings** > **Projection Mode** to select the corresponding projection mode, so images can be projected correctly.
Mounting Screw: M5 x 4 (not included)

2. Power On/Off

Take off the lens cover.

Connect the power adapter to an outlet.

Press the **Power Button** to turn on the projector, press and hold the **Power Button**, then select **OK** to turn off the projector.

Notes:
When the projector is on, press the power button once to put it into standby mode, press it again to wake it up.
Please use the power adapter provided in the box to prevent product damage.

3. Remote Control Pairing

Turn on the projector, and wait for the pairing prompt on the screen, bring the remote control within 330 ft (100 m) of the projector, then simultaneously press and hold the **OK** and **Home** buttons. Wait for the pairing to complete.

Pairing Instructions

4. Setup Wizard

Follow the visual guide to choose your preferred language, select your region, and sign in with your Google Account or use the basic TV mode.

5. Image Adjustment

For optimal automatic image adjustment and correction, place the projector with no more than a 20° tilt vertically or horizontally toward the screen or wall.

Tip:
Press the **Focus** buttons on the remote or go to **Homepage** > **Dashboard** > **All settings** > **Projector** > **Focus** > **Manual Focus** to sharpen the image focus until the blurry image becomes clear.

Electric/Manual Focus

Press the **Focus** buttons on the remote or go to **Homepage** > **Dashboard** > **All settings** > **Projector** > **Focus** > **Manual Focus** to sharpen the image focus until the blurry image becomes clear.

Keystone Correction

1. Auto Keystone Correction
The projector automatically corrects the keystone distortion when moved to maintain a rectangular image. You can also trigger auto keystone correction by going to **Homepage** > **Dashboard** > **All settings** > **Projector** > **Keystone Correction** > **Auto Keystone Correction**.

Tip:
Go to **Homepage** > **Dashboard** > **All settings** > **Projector** > **Keystone Correction** > **Keystone Correction Settings**, you can enable/disable **Auto Keystone Correction** > **Auto Keystone Correction** > **Auto Keystone Correction After Movement**, allowing the projector to automatically correct the distortion after it is moved.

2. Manual Keystone Correction

Go to **Homepage** > **Dashboard** > **All settings** > **Projector** > **Keystone Correction** > **Manual Keystone Correction** to manually correct the image shape by four points.

Intelligent Screen Fit

Go to **Homepage** > **Dashboard** > **All settings** > **Projector** > **Advanced Settings** > **Fit to Screen** to enable the projector to adjust the projected image to fit the screen.

Intelligent Obstacle Avoidance

Go to **Homepage** > **Dashboard** > **All settings** > **Projector** > **Advanced Settings** > **Avoid Obstacles** to enable the function. The projector will automatically adjust the projected image to avoid any objects on the projection surface during the correction process.

2. Projector Connection and Input Source

Connect your device to the projector correctly, then select the right input source.

USB Connection

Connect the projector to the disk, then go to **Homepage** > **Apps** and select **MyPlayer** under "Your apps" tab to locate and play the file.

HD Connection

Connect the device with an HD cable (not provided), then press the **Input** button on the remote or go to **Homepage** > **Dashboard** > **All settings** > **Projector** > **Focus** > **Manual Focus** to sharpen the image focus until the blurry image becomes clear.

Wired Speaker and Headphones Connection

Not required to select any input source.

WiFi CONNECTION

Connect your projector to your router's WiFi by going to **Homepage** > **Dashboard** > **All settings** > **Network** > **Internet**.

GOOGLE ASSISTANT

Your TV is more helpful than ever. Use our app to find movies, streaming apps, play music and control your TV. Ask Google Assistant to find a specific title, search for genre, or get personalized recommendations. Even get answers on screen, control smart home devices, and more. Press the Google Assistant button on the remote to get started.

GOOGLE CAST™

Google Cast is a platform that lets you stream your favorite entertainment from your phone, tablet, or laptop right to your projector. Easily control your TV with apps you already know and love from your iPhone®, iPad®, Android™ phone or tablet, Mac® or Windows® laptop, or Chromecast. To use Google Cast, please ensure you are using a Google Cast-enabled app and follow the instructions below.
1. Connect your device and the projector to the same wireless network.
2. Open the streaming app on your device.
3. Play a video and tap the casting icon.
4. Select **EAZZE D1 Max** to connect. The projector will display the video from your device.

BT SPEAKER MODE

This projector can function as a BT speaker by connecting your mobile device to it through a BT connection.

Step 1:
Go to **Homepage** > **Dashboard** > **All settings** > **Projector** > **BT Speaker Mode** to make the projector ready for a BT connection.

Step 2:
Access your mobile devices BT settings and activate BT. Search for **EAZZE D1 Max** in the available devices list to use your mobile device with the projector.

Tip:
To exit the **BT Speaker Mode**, simply press the **Back** button on the remote control for 2 seconds.

MORE SETTINGS

1. Future Mode
Go to **Homepage** > **Dashboard** > **All settings** > **Display & Sound** > **Display** to select from **User**, **Standard**, **Video Sports**, **Movie Game**, and **Energy Saving**.

2. Color Temperature

Go to **Homepage** > **Dashboard** > **All settings** > **Display & Sound** > **Display** > **Expert Settings** > **Color Temperature** to select from **User**, **Cool**, **Standard**, and **Warm**.

3. Brightness Mode

Go to **Homepage** > **Dashboard** > **All settings** > **Projector** > **Energy & Performance** > **Brightness Mode** to select from **Standard**, **ECO**, and **High Performance**.

4. Reset

Go to **Homepage** > **Dashboard** > **All settings** > **System** > **About** > **Reset** to restore the projector to factory settings.

5. System & Product Info

Go to **Homepage** > **Dashboard** > **All settings** > **System** > **About** to check system & product information.

PROJECTION DISTANCE AND SIZE

* For optimal image quality, we recommend a projection size of 100". Position the projector 11.8ft (3.6m) away from the wall or screen.
* The recommended projection distance varies with different projector contents. Please adjust the distance between the wall/screen and the projector as needed.
* Ambient darkness will improve the clarity of the projected images.

Dolby Audio

Only Dolby Audio and the double-D symbol are registered trademarks of Dolby Laboratories Licensing Corporation. Manufactured under license from Dolby Laboratories.

NETFLIX

Netflix is a trademark of Netflix, Inc.

CE

Notice: Consumer Reaction Electronics Co., Ltd. declares that this radio equipment is in compliance with Directive 2014/53/EU. The full text of the EU declaration of conformity is available at the following internet address: <https://aurizen.com/pages/declaration>

Power consumption

Standby mode <0.5W
Network standby mode <0.5W
Standby mode <0.5W
Network standby mode <0.5W

Time to enter the condition automatically

Standby mode <30s
Network standby mode <30s

FC

The above complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.
Note: This equipment has been tested and found to comply with the limits for a Class B digital device pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into a outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Important: You are cautioned that changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

RF Exposure Information:
- The radio emitted power of this device meets the limits of FCC radio frequency exposure limits. This device should be operated with a minimum separation distance of 20cm (8 inches) between the equipment and a person's body.
- The remote control has been evaluated to meet general RF exposure requirements, it can be used in portable exposure condition without restriction.

Canada compliance statement (Conformité réglementaire canadienne):
- This device complies with the Canadian Interference-causing Equipment (ICE) standards. Operation is subject to the following two conditions: (1) This device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.
- The radio emitted power of this device meets the limits of FCC radio frequency exposure limits.
- The remote control has been evaluated to meet general RF exposure requirements, it can be used in portable exposure condition without restriction.
Le présent appareil est conforme aux CNR d'Interférence des Émissions de Radio-Fréquence (IREM) du Canada. L'exploitation de cet appareil est soumise aux deux conditions suivantes: (1) l'appareil ne doit pas produire de brouillage, et (2) l'appareil doit accepter tout brouillage radioélectrique susceptible de l'affecter dans son fonctionnement.
Le présent appareil ne doit pas produire de brouillage et doit accepter tout brouillage radioélectrique susceptible de l'affecter dans son fonctionnement.

Dispositif à faible interférence:
- La puissance émise de cet appareil est conforme aux limites de l'IC (Interférence des Émissions de Radio-Fréquence) du Canada. L'exploitation de cet appareil est soumise aux deux conditions suivantes: (1) l'appareil ne doit pas produire de brouillage, et (2) l'appareil doit accepter tout brouillage radioélectrique susceptible de l'affecter dans son fonctionnement.
- La puissance émise de cet appareil est conforme aux limites de l'IC (Interférence des Émissions de Radio-Fréquence) du Canada. L'exploitation de cet appareil est soumise aux deux conditions suivantes: (1) l'appareil ne doit pas produire de brouillage, et (2) l'appareil doit accepter tout brouillage radioélectrique susceptible de l'affecter dans son fonctionnement.

The product complies with FCC ID: 6247-02-001.
The product label and configuration information are located at the bottom of the product.