


19A700100EM Parts List



Ref.	Part Number	Description
1.	710-04064	Cap Screw, 1/4-20 x .750
2.	96606	Retainer Hook Bracket
3.	603-04082-0637	Mount Assembly, RH
4.	603-04083-0637	Mount Assembly, LH
5.	703-05245A-0637	Boot Mount Bracket
6.	703-07670-0637	Catcher Mounting Bracket
7.	710-0176	Hex Head Screw, 5/16-18 x 2.75
8.	710-0751	Hex Head Screw, 1/4-20 x .620
9.	710-3097	Carriage Bolt, 3/8-16 x 1.00
10.	710-3103	Hex Head Screw, 5/16-18 x 2.00
11.	912-0431	Flange Lock Nut, 3/8-16
12.	712-3004A	Flange Lock Nut, 5/16-18
13.	912-3027	Flange Lock Nut, 1/4-20
14.	02002426	Weight Bar
15.	723-0476	Chute Strap
16.	726-04040	Push Nut, 5/16
17.	731-04347A	Discharge Chute Elbow
18.	731-06611	Chute Adapter
19.	936-0185	Flat Washer, .375 x .738 x .063
20.	736-0270	Belleville Washer
21.	736-3092	Flat Washer, .265 X 1.0 X .030
22.	02001688	Baffle
23.	931-04292	Twin Bagger Cover Assembly
24.	631-04295P	Upper Chute Assembly
25.	731-06497	Upper Chute Support
26.	731-06504	Bagger Cover Screen
27.	964-04090	Grass-bag Assembly
28.	683-04461-0637	Twin Bag Support Assembly
29.	683-04519-0637	Vertical Support Bracket
30.	710-0276	Carriage Screw, 5/16-18 x 1.00"
31.	710-3008	Hex Head Screw, 5/16-18 x .75"
32.	711-04988	Cover Hinge Pin
33.	712-04063	Flange Lock Nut, 5/16-18
34.	735-0246A	End Plug
35.	726-3046	Ratchet Clip
36.	721-04388	Foam Strip