

little tikes®

TotSports™ Soccer Trainer

3+
YEARS

SKU: 641992

ADULT ASSEMBLY REQUIRED

LIMITED WARRANTY

The Little Tikes Company makes fun, high quality toys. We warrant to the original purchaser that this product is free of defects in materials or workmanship for one year * from the date of purchase (dated sales receipt is required for proof of purchase). At the sole election of The Little Tikes Company, the only remedies available under this warranty will be the replacement of the defective part or replacement of the product. This warranty is valid only if the product has been assembled and maintained per the instructions. This warranty does not cover abuse, accident, cosmetic issues such as fading or scratches from normal wear, or any other cause not arising from defects in material and workmanship. *The warranty period is three (3) months for daycare or commercial purchasers. U.S.A and Canada: For warranty service or replacement part information, please visit our website at www.littletikes.com, call 1-800-321-0183 or write to: Consumer Service, The Little Tikes Company, 2180 Barlow Road, Hudson OH 44236, U.S.A. Some replacement parts may be available for purchase after warranty expires—contact us for details. Outside U.S.A and Canada: Contact place of purchase for warranty service. This warranty gives you specific legal rights, and you may also have other rights, which vary from country/state to country/state. Some countries/states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you.

Please keep this manual as it contains important information.
Illustrations are for reference only. Styles may vary from actual contents.

© The Little Tikes Company, an MGA Entertainment company. LITTLE TIKES® is a trademark of Little Tikes in the U.S. and other countries. All logos, names, characters, likenesses, images, slogans, and packaging appearance are the property of Little Tikes.
Printed in China

US/CA - Little Tikes Consumer Service
2180 Barlow Road, Hudson, Ohio 44236 U.S.A.
Phone: 1-800-321-0183
blog.littletikes.com/little-tikes-contact-form

UK - MGA Entertainment UK Ltd. 50 Presley Way, Crownhill, Milton Keynes, MK8 0ES, Bucks, UK.
Little Tikes Consumer Services
P.O. Box 2040 Hockley, Essex, SS5 4BF
Phone: 0 800 521 558
E-mail: support@littletikesstore.co.uk

EU - MGA Entertainment (Netherlands) B.V. Baronie 68-70, 2404 XG, Alphen a/d Rijn, The Netherlands
Tel: +31-172-758-010
Email: klantenservice@mgae.com

AU/NZ - Imported by MGA Entertainment Australia Pty Ltd. Suite 5.05, 32 Delhi Road, Macquarie Park NSW 2113. AU.
Tel: 1 300 059 676
Email: au-sales@mgae.com

little tikes

www.littletikes.com
www.littletikes.co.uk
www.littletikes.com.au

MGA ENTERTAINMENT™
0924-0-E/INT



Thank you for choosing the Little Tikes® TotSports™ Soccer Trainer.
We strive to provide a durable, easy-to-assemble toy that is made to last,
giving your child years of imaginative, engaging fun!

WARNING!

- ADULT ASSEMBLY REQUIRED.
- This product is intended for outdoor family use only.
- Keep these instructions for future reference.
- Adult supervision required. Do not leave children unattended.
- In order to avoid fall hazard, this playset should be placed on non-slip level ground or firm grass or soil to allow proper use of stakes.
- This product is intended for use by children ages 3 years and older and is not intended for children under 3 years due to their inability to safely use.
- When not in use store unit indoors to prevent weather or sun related damage.
- Instruct children on proper use of this product, only after properly placed, and not in a manner other than intended.
- Failure to follow these instructions might result in unsafe conditions or even injury.
- Maximum pressure 5.8 psi.
- Do not over inflate the ball.

Let's be careful!

- Read through all the instructions first.
- Never hit ball at animals or moving bicycles. or others.
- Do not use soccer trainer when raining or when ground is wet.
- Avoid placing or using soccer trainer in or near swimming pools, on or near steps, hills or inclines.
- Avoid placing or using soccer trainer in or near street, sidewalks, alleys.
- Do not lean on the product.

MAINTENANCE

- Always inspect product before playing.
- Do not attempt to modify or repair this product. For help contact Little Tikes Consumer Services.
- Clean the unit with a slightly damp cloth (not included). Never use corrosive or abrasive substances to clean the unit. For the net, surface wash only.

DISPOSAL


- Disassemble and dispose of equipment in such a manner that no hazardous conditions such as, but not limited to, small parts and sharp edges exist at the time equipment is discarded.

Learn to Dribble




Let's Play

Once assembled place the unit in a safe spot outside and place the stakes through the bases to prevent it from falling over during play.




Storage


When you're done playing, disconnect the top and bottom connectors.



Next, fold the trainer in half.




Last, rotate the bases to be parallel to the trainer for easy storage. Attach the velcro to keep the trainer folded.




A Few Things Before You Start!

BEFORE you begin assembly, make sure you have all the parts listed below. Side post (E) is very similar to top posts (D), but it is slightly longer. Make sure to handle the correct pieces before connecting.


Contents




Top connector (1)




Bottom connector (1)




Elbow connectors (2)




Bottom post (2)




Top post (2)



Side post (2)



Base (2)



Stake (4)



Net (1)



Reversed side:

Set Accessories



Cones (4)




Soccer ball

ASSEMBLY INSTRUCTIONS


1 Insert posts into net sleeves

Insert top posts (D) to the top sleeves of the net and, then, align and connect the elbow connectors (F) to the top posts. Insert bottom posts (B) to the bottom sleeves of the net.




2 Insert posts into net sleeves cont...

Insert the side posts (E) into the sleeves on the sides of the net, and then align and connect the elbow connectors (F).



3 Assemble the frame

Align and connect the top connector (A) to the top posts. Then, align and connect the bottom connector (C) to the bottom posts.



4 Attach the bases

Attach the bases (G) to the bottom of the frame.

