

(a)hua

1.1 装箱清单

第1章 产品结构

使用安全须知

下面是关于产品的正确使用方法、为预防危险、防止财产受 到损失等内容, 使用设备前请仔细阅读太说明书并在使用时 严格遵守, 阅读后请妥善保存说明书。

使用要求

- 请勿将设备放置和安装在阳光直射的地方或发热设备附
- 请保持设备的水平安装,或将设备安装在稳定场所,注意 防止本产品坠落。
- 请勿将液体滴到或溅到设备上、并确保设备上没有放置装 满液体的物品, 防止液体流入设备。
- 请将设备安装在诵风良好的场所,切勿堵塞设备的诵风口。
- 仅可在额定输入输出范围内使用设备。
- 请勿随意拆卸设备。
- 请在允许的湿度和温度范围内运输、使用和存储设备。

接收产品后,请检查外包装有无明显的损坏。打开包装后,根 据装箱清单检查配件是否齐全。


表1-1 奘筠洁单

名称	数量	名称	数量
2.5英寸固态硬盘	1块	快速操作手册	1份
螺丝(非零售款为选配)	4颗		

1.2 结构尺寸

图1-1 结构尺寸(单位: mm)





浙江华忆芯科技有限公司

固态硬盘

快速操作手册


V1.0.4

快速操作手册

1.3 接口说明

(a)hua

- 数据接□:使用SATA数据线将固态硬盘连接至电脑等设备的 SATA硬盘接口。
- 申源接□:使用SATA申源线将固态硬盘连接至电脑等设备的 SATA电源接口。



第2章 硬盘安装

2.1 安装前准备

表2-1 安装环倍更求

	NE 2 X 30 1 1 70 30 51
安装环境	说明
工作温度	0°C~70°C,-25°C~85°C,-40°C~85°C 详见规格书
存储温度	-40°C∼85°C
工作湿度	5%~95%,不凝结

2.2 安装硬盘

 接线式安装:将SATA数据线和电源线分别接在主板和固态 硬盘上,即完成硬盘安装。

固态硬盘SATA数据线和电源线不随机附带,请用户自行按

直插式安装:将固态硬盘的数据接□和电源接□直插在主 板上,即完成硬盘安装。

图2-1 安装固态硬盘



附录1 使用注意

注意事项

在安装前,请确保您的电脑主板支持所洗购的SSD,并且主板 是上有足够的SATA插槽供SSD单独使用。

售后流程

- 1. 联系销售商,或者拨打4006728166咨询,或者关注 "大华存储" 微信公众号咨询。
- 2. 执行保修承诺、SSD非人为损坏并且在保修期和使用
- 3. 寄送至指定地点(购买店铺或维修点)。

(a)hua

感谢您购买本产品,此卡为您的免费保修凭证

质保说明

保修卡活用您购买的本公司系列产品

1.质保期限内,由于本产品自身引起的故障,请与销售商 或本公司售后服务联系。

附录2 保修卡

- 2.购机后请及时邮寄,传真已填好的保修卡,您可享受免 费的维修和更换,否则恕不办理。
- 3.保修时我们将使用您的保修卡信息,请认真填写。 以下情况,属于不保修范围。
- · 人为原因造成的设备故障
- · 因使用环境不符合本产品要求造成的故障
- · 因不可抗力造成的产品损坏
- · 无产品序号、保修卡,或产品序号及标贴模糊不清、 破损、无法辨识
- ·已过保修期或者超过使用寿命(TBW)

产品名称:	购买日期:
产品序号:	用户名称:
通讯地址:	联系人:
电话:	邮编:
经销商:	传真:
电话:	联系人:

附录3 有毒有害物质或元素含量参照表 本表格依据SJ/T 11364的规定编制

有毒有害物质或元素

快速操作手册

部件名称	铅	(Pb)	汞	(Hg)	镉	(Cd)		多溴肽 苯(PBBI)	多溴 _— 本 醚(PBDE)
金属件	Х		0		0		0	0	0
塑胶件	0		0		0		0	0	0
机电件	Х		0		0		0	0	0
线路板	Х		0		0		0	0	0
电源(如果有)	Х		0		0		0	0	0
线缆 (如果有)	Х		0		0		0	0	0
硬盘(如果有)	Х		0		0		0	0	0
鼠标(如果有)	Х		0		0		0	0	0
遥控器(如果 有)	х		0		0		0	0	0
光驱(如果有)	Х		0		0		0	0	0
液晶屏(如果 有)	х		0		0		0	0	0
光盘(如果有)	0		0		0		0	0	0
干燥剂(如果 有)	0		0		0		0	0	0
配件(如果有)	х		0		0		0	0	0
电池 (如果有)	x		0		0		0	0	0

标准规定的限量以下。

X:表示该有害物质至少在该部件的某一均质材料中的含量超出GB/T 26575标准规定的限量要求。

●: 本标识适合用于在中华人民共和国销售的电子信息产品,环保 使用期限为10年, 在环保使用期限内用户正常使用本产品, 这些物 质不会发生外泄或突变,不会对用户的人身、财产造成损害。

「 让社会更智能 让生活更美好

ENABLING A SMARTER SOCIETY AND BETTER LIVING

浙江华忆芯科技有限公司 | 网址: www.dahuamemory.com | 服务热线: 400-672-8166



Solid State Drive

Ouick Start Guide



V1.0.4

ZHEJIANG DAHUA VISION TECHNOLOGY CO., LTD.

(a)hua Quick Start Guide

Foreword

General

This manual introduces the structure and installation of the Solid State Drive (hereinafter referred to as "the SSD").

Application

Applied to Dahua SSD 2.5 inch.

Safety Instructions

The following categorized signal words with defined meaning might appear in the manual.

Signal Words	Meaning
DANGER	Indicates a high potential hazard which, if not avoided, will result in death or serious injury.
A WARNING	Indicates a medium or low potential hazard which, if not avoided, could result in slight or moderate injury.
Avcaution	Indicates a potential risk which, if not avoided, could result in property damage, data loss, lower performance, or unpredictable result.
©=4TIPS	Provides methods to help you solve a problem or save you time.
Provides additional information as the emphasis and supplement to the text.	

(a)hua

About the Manual

- The manual is for reference only. If there is inconsistency. between the manual and the actual product, the actual product shall prevail.
- We are not liable for any loss caused by the operations that do not comply with the manual.
- The manual would be updated according to the latest laws and regulations of related jurisdictions. For detailed information, refer to the paper manual, CD-ROM, OR code or our official website. If there is inconsistency between paper manual and the electronic version, the electronic version shall prevail
- All the designs and software are subject to change without prior written notice. The product updates might cause some differences between the actual product and the manual. Please contact the customer service for the latest program and supplementary documentation.
- . There still might be deviation in technical data, functions and operations description, or errors in print. If there is any doubt or dispute, we reserve the right of final explanation.
- Upgrade the reader software or try other mainstream reader. software if the manual (in PDF format) cannot be opened.
- All trademarks, registered trademarks and the company names in the manual are the properties of their respective owners.
- Please visit our website, contact the supplier or customer service if there is any problem occurring when using the
- . If there is any uncertainty or controversy, we reserve the right of final explanation.

Important Safeguards and Warnings

This section introduces the proper way of using the SSD, and danger and property damage preventions. Before using the SSD, read this manual carefully. Follow the instructions and keep this manual properly.

@hua

Quick Start Guide

Quick Start Guid


- Do not place or install the product in a place exposed to sunlight or near the heat source.
- Keep the product installed horizontally or on a stable place to prevent it from falling.
- Do not drop or splash liquid onto the product, and make sure that there is no object filled with liquid on the product to prevent liquid from flowing into the product.
- Install the product in a well-ventilated place, and do not block the ventilation of the product.
- Operate the product within the rated range of power input
- Do not disassemble the product.
- . Transport, use and store the product under the allowed humidity and temperature conditions.

1 Structure

1.1 Dimensions

Operating Requirements

Figure 1-1 Dimensions (mm)



(----

(a)hua

1.2 Ports



Table 1-1 Port description

		Table 1 11 oft description
0.	Name	Description
	Data port	Connect the SSD to the SATA data port on devices such as PC with SATA data cable.
	Power port	Connect the SSD to SATA power port on devices such as PC with SATA power cable.

2 Installation

2.1 Preparation

Table 2-1 Environment requirements		
Installation Environment	Description	
Operating Temperature(Accordin	0°C to 70°C (32°F to 158°F)	
to the specification sheet)	-25°C to 85°C (-13°F to 185°F)	
to the specification sheet,	-40°C to 85°C (-40°F to 185°F)	
Storage Temperature	-40°C to 85°C (-40°F to 185°F)	
Operating Humidity	5%-95% (non-condensing)	

2.2 Installing SSD



Before installing, make sure that your PC mainboard supports SSD, and there are enough SATA slots to be used by the SSD.

There are two installation methods for the SSD: Cable connection and direction insertion.

(alhua

direction insertion.

Quick Start Guide

Quick Start Guide

There are two installation methods for the SSD: Cable connection and

devices to the SSD with SATA data cable and power cable.

corresponding ports on the main board of devices.

purchase them separately as needed.

Cable connection: Connect corresponding ports on the main board of

SATA data cable and power cable of the SSD are not included. You can

Direct insertion: Insert data and power ports of the SSD directly to the

Figure 2-1 Install by cable connection

Figure 2-2 Install by direct insertion

(a)hua

Appendix 1 Precautions for Use

 Before installation, make sure that your PC motherboard supports this SSD and it has enough M.2 slots to use independently.

Quick Start Guide

- Please make sure that your PC M.2 port support PCle3.0 bandwidth, or else the SSD won't get your desired performance.
- Since Window 7 operating system does not come with the corresponding driver for NVME protocol. So when you install it, the system will not recognize the NVMe SSD. We sincerely recommend you to use Windows 8.1 or above or Linux operating system. If you continue to use Window 7, we recommend that you download the a standard NVMe driver from the Internet
- The changeable of design and apperance to improve the product, the company keep the reserves right of it.

ENABLING A SMARTER SOCIETY AND BETTER LIVING

ZHEJIANG DAHUA VISION TECHNOLOGY CO., LTD. Website: www.dahuasecurity.com | Postcode: 310053 | Email: overseas@dahuatech.com | Fax: +86-571-87688885 | Tel: +86-571-87688883