



DIGITAL TYRE PRESSURE GAUGE

MODEL NO: TSTPG10.V2

Thank you for purchasing a Sealey product. Manufactured to a high standard, this product will, if used according to these instructions, and properly maintained, give you years of trouble free performance.



IMPORTANT: PLEASE READ THESE INSTRUCTIONS CAREFULLY. NOTE THE SAFE OPERATIONAL REQUIREMENTS, WARNINGS & CAUTIONS. USE THE PRODUCT CORRECTLY AND WITH CARE FOR THE PURPOSE FOR WHICH IT IS INTENDED. FAILURE TO DO SO MAY CAUSE DAMAGE AND/OR PERSONAL INJURY AND WILL INVALIDATE THE WARRANTY. KEEP THESE INSTRUCTIONS SAFE FOR FUTURE USE.

1. SAFETY

- ❑ **WARNING!** Check your tyre pressures regularly. An under or over inflated tyre can add to your fuel consumption and cause additional wear. Both are dangerous.
- ✖ **DO NOT** use this product for applications outside of its intended use.
- ✓ Read and follow ALL instructions before use.

2. INTRODUCTION

Ergonomically designed lightweight tyre pressure gauge. One-button operation with LCD digital display and illuminated nozzle. Read-out available in bar, psi, kg/cm² or kPa. Range: 0-150psi(0-10.3bar). Auto-power-off feature. Compact, can easily be stored in a glove box. Powered by 1 x CR2032, 3 x LR44 batteries (supplied).

3. SPECIFICATION

MODEL NO:	TSTPG10.V2
Battery:	1 x CR2032 3 x LR44 (supplied)
Operating Temperature:	-5°C to 50°C
Pressure Units:	Bar, psi, kg/cm ² , kPa
Range:	0-10.3bar 0-150psi 0-10.5kg/cm ² 0-1034kPa
Resolution:	0.1psi

4. OPERATION

4.1. MEASURING TYRE PRESSURE (FIG.1)

- 4.1.1. Press the ON/OFF button to turn the tyre pressure gauge on. The gauge will display "0.0" on the LCD screen.
- 4.1.2. Place the nozzle of the tyre pressure gauge on the tyre valve you wish to measure. Ensure a good seal to prevent air from escaping.
- 4.1.3. Hold the gauge on the valve until the measurement display locks.
- 4.1.4. Remove the gauge to easily read the pressure reading.
- 4.1.5. To change units press the button to change between the four available units (bar, PSI, kg/cm², kPa)
- 4.1.6. The tyre pressure gauge will automatically turn off shortly after use. Alternatively, hold the ON/OFF button to turn off.

4.2. CHANGING THE BATTERY (FIG.2)

- 4.2.1. Remove the back cover using a screwdriver.
- 4.2.2. Remove the battery and replace with an equivalent. Ensure the battery is placed with the correct polarity.
- 4.2.3. Replace the back cover and screws.




FIG.1



FIG.2



ENVIRONMENT PROTECTION

Recycle unwanted materials instead of disposing of them as waste. All tools, accessories and packaging should be sorted, taken to a recycling centre and disposed of in a manner which is compatible with the environment. When the product becomes completely unserviceable and requires disposal, drain any fluids (if applicable) into approved containers and dispose of the product and fluids according to local regulations.



REGISTER YOUR
PURCHASE HERE



WEEE REGULATIONS

Dispose of this product at the end of its working life in compliance with the EU Directive on Waste Electrical and Electronic Equipment (WEEE). When the product is no longer required, it must be disposed of in an environmentally protective way. Contact your local solid waste authority for recycling information.



BATTERY REMOVAL

Under the Waste Batteries and Accumulators Regulations 2009, Jack Sealey Ltd are required to inform potential purchasers of products containing batteries (as defined within these regulations), that they are registered with Valpak's registered compliance scheme. Jack Sealey Ltd Batteries Producer Registration Number (BPRN) is BPRN00705.

Note: It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice. Please note that other versions of this product are available. If you require documentation for alternative versions, please email or call our technical team on technical@sealey.co.uk or 01284 757505.

Important: No Liability is accepted for incorrect use of this product.

Warranty: Guarantee is 12 months from purchase date, proof of which is required for any claim.

Sealey Group, Kempson Way, Suffolk Business Park, Bury St Edmunds, Suffolk. IP32 7AR



01284 757500



sales@sealey.co.uk



www.sealey.co.uk