How to connect Ofantop Smart Ceiling Fan with Smart Life APP

| Step 1: download Smart Life App	Step 2: register a Smart Life's account and log in
Step 3: Turn off the break box which supply power to the fan. Turn on the break box again and enter app and click "Add Device" button 	Step 4: Turn on Bluetooth
Step 5: scroll the page till you find the "Small Home Appliances", then click "Fan (Wi-Fi)". 	Step 6: select 2.4Ghz wifi network, enter wifi and password.

|	
Step 7: long press 8H button （Reset button） on remote towards the fan for 5s, release the button when you hear beep beep sound, then press "Confirm the indicator is blinking" button.	Step 8: on next page, there are two options: blinks slowly vs blinks rapidly. Please choose ' blinks Quickly'.

Reset the device

Press and hold the RESET button for 5 seconds until the indicator blinks (subject to the user manual).

Confirm the indicator is blinking

Reset Device Step by Step

Reset the device

Press and hold the RESET button for 5 seconds

Select the status of the indicator light or hear the beep:

Blink Slowly   Blink Quickly

Step 9: pls wait the fan to connect the APP. When the tip "Added successfully" comes out, press "Done" button. Congratulations, it was done.

Add Device

1 device(s) being added

Smart Ceiling Fan
Being added

Done

× Add Device

1 device(s) added successfully

Smart Ceiling Fan
Added successfully

0 device(s) being added

Done

==highlighted== *If you fail to add device after step 9, pls try step 9-01 & step 9-02*

Step 9-01: press and hold the remote control "4H" timer button for 5 seconds until the buzzer sounds one long time, release the button and the receiver will chirp at 3 second intervals to indicate WIFI AP pairing mode. Then press "Confirm the indicator is blinking" button.

Reset the device

Press and hold the RESET button for 5 seconds until the indicator blinks (subject to the user manual).

Confirm the indicator is blinking

Reset Device Step by Step

Step 9-02: In next page, pls click "blinkly SLOWLY. After that, you will add device successfully.

Reset the device

Press and hold the RESET button for 5 seconds

Select the status of the indicator light or hear the beep:

Blink Slowly   Blink Quickly

Step 10: below is light setting, including turn on/ off, light's temperature, and dim.

Press the 2nd button at the bottom to shift to fan setting.

Smart Ceiling Fan

Light Switch

Home

100%

fan setting

Home

Step 11: below is fan setting, including turn on/ off running direction (summer mode vs winter mode), speed setting, timer.

Smart Ceiling Fan

Fan Switch

Mode · Fresh   Direction · Forward

Speed · 5

CountdownOff · Closed after 01Hour00Minute

Start

Fan