

Quick Start Guideline

Please read it carefully before usage and save the manual for future use

1.It need to charge 12 hours on the 1st charging 2.Please make sure the button on the bottom of battery have

been turn " on " otherwise, it will not charging or power on for 3. When you charge the battery, the led indicators will be flash

Security Screw

Used to collect ambient light. When luminance is Sensor lower than 2 Lux, turn on the IR LED

Used to collect ambient sound and achieve vocal dialogue

Used to wake up the Equipment to notify the user of any visitor and link to the buzz responder

a signal that is generated and sent to the cell phone

When someone moves in front of the equipment triggers

In the event of inadequate ambient light, turn on the

IR LED to increase the brightness

Equipment is connected to WiFi;

Indicator Ligh —

Lens Used to collect the image and video

dicator When the Blue Indicator Light is blinking, the Equipment is in the configuration status; When the Red Indicator Light is always " ON ", the WiFi connection has failed: When the Blue Indicator Light is always " ON ", the Equipment is successfully connected; When the Red and Blue Indicator Lights are " ON " at the same time, the

eaker Used to send out a system prompting sound and M5 Video Doorbell Power Cable achieve vocal dialogue

Battery introduction

blue. After fully charged the led indicators will be stable blue

Connecting doorbell to your phone Download the APP - XSH Cam setup one at a time

Scan the following the QR code or search " XSH Cam " on the app store to download the app. Note: Allow the app to send notifications to your phone firstly

1. Make sure the Xsh Cam app is installed to your device. 3. Before setup, make sure the device is in configuration long 2.Make sure that your device is connected to a 2.4GHz Wi-Fi

'The camera is now ready to begin pairing ". Then tap " Y 3. Make sure the rechargable battery have been fully charged

4. Please make sure the button on the bottom of battery have been turn " on "otherwise, it will not charging or power on for

network. NOT a 5GHz network.

before connection



2. Tap " Setup Device " Note: If you have multiple devices, only

4. The name of the Wi-Fi network will automatically be filled in, enter the Wi-Fi password. The APP will fill the corresponding password automatically if connected with the same Wi-Fi, and

> If the app don't pick up the wifi name automatically. that mean the app are not get the authority of your phone Please go to the phone setting to allow the app works, if still not work please remove the app and

press the "Reset Button" for 5 seconds with a voice prompt 5. The mobile device will emit sound waves, keep quiet and

download again



you don't need to fill the password again. Then please tap " Next "

make sure about 30cm distance between the phone and the

Connect device to Wi-F

Doorbell Function Instruction all the steps (please see the previous section, and reset the Go to " Device List ", Click " () " on the top right corner, to enter the following basic Settings

6. If your doorbell fails to connect, reset the doorbell andrepeat

8. Setup completed! The APP will be entered the device list

interface automatically. Congratulations! The device is ready

hinese Mainland '

when you " select

the area where the

device is located

" Otherwise, the

cloud video will not

work properly



Push mode:Change Call in:Calling you on every a name and password for your camera.

Step to share

on every doorbell ringing on every doorbell ringing and and every motion alert every motion alert

Notification: Message you Silence Mode: Keep silence

Share QR code: Share doorbell to family or friend

1.Go to " Device list ", Click " (" on the top right corner 2.Click " Share QR code " to get the QR code to share 3. Take your family or friend's phone to download "XSH cam" app 4. Open " XSH cam ", Click " Add a Device " - " Scan QR code 5.To Scan the QR code you have shared. Then the doorbell have added more users

Delete the doorbell, you will not got any notification but the doorbell still work.

Video Or HD video(Standard Video or High Standard video

To get more settings



Settings: More device

doorbell ringing and every

Switch: Enlarged the

Ringing Video and Detection Video will be here Cloud (Only available for Cloud storage but not SD card) Album: Only Saved for the manual recorded Video or Album picture manual Screenshot. Not Used for automatically

Power Status: Checking any battery Status here

Delete device / camera

SD Video/HD Video: Choose Different Resolution: SE And other connected phone still able to get the notificatio

Click " Settings " on Menu - " Device Settings

Checking Recorded Video on Cloud storage Please find the " cloud video " on the live video interface to check all could video

Device name and passwor



Switch Cruise Voice Settings Basic Info

Cloud Storage Settings Cloud Video/Storage: Enable it to get cloud storage service

Note: Cloud Storage is free.7day loop recording

Each record only 8S. couldn't change it SD card Storage Settings

Cloud Video/Storage:

Disable it to get Micro SI card inserted for storage Checking and SD card capacity and Format SD

could download to your phone

Cloud video only 8S.Could Not Change.All cloud video

Checking Recorded Video on SD card

Please drag the timeline to the vellow area to play the recorded video. Yellow area is the recorded Video

SD video could download from SD card Video Length



setup by the active time

then take video and alert at same time

High:doorbell wake up after it detects human at least 1s, then take video and alert at same time

Note:In crowded environment.it is recommended to close

or set the device to low sensitivity to reduce device arousal and call times to extend battery life

Recording time setup. Only available for SD card storage Turn on / off the LED on the doorbell buttor

15S.30S.60S:choose different record time after the PIR motion detection have been triggered for recording

Active Time / Dormancy Time

Alwavs: Alwavs in

Low:doorbell wake up

after it detects human

for 7s, then take video

and alert at same time

recording mode no matter if there is any movement. But it only worked for SD card storage And battery are easy to run out

Medium:doorbell wake up after it detects human for 5s.

Orentiation : Change the PIR detection: Motion Detection Set

Disble:Close the PIR

off the Night IR or back light,

Power frequency: Change the power frequency for the

Disable: Turn off the LED on the doorbell button

Enable: Turn on the LED on the doorbell button

Orentiation of the video

Envoriment:Turn on / turn

hight light compensation to make the video in a better view

www.zhiliaocam.com

vou mount vour camera.

doorbell " to watch it.

1. The device is powered by rechargeable lithium batteries. New

installation. After power off, then you could charge it by connecting

USB cable with usb adpater, power bank, PC or laptop. The

mobile device APP will be prompted while the battery voltage is

2. Keep the camera in range of your router. Make sure to pick a

place within range of your network. Thick or insulated doors

can greatly reduce the strength of your Wi-Fi signal even if

your router is close by, so you should try streaming video before

3. The device is a low power consumption intelligent products

can support remote wake up from the APP, PIR human detection,

press doorbell wake up. The device will be works for 30 seconds

after wake up then be in the resting state automatically and until to

1.Please Scan below QR code to watch the instruction guide

2.Or Please go the voutube, and search " Zhiliao M5 Video

low. Please charge the device after received the reminder.

battery is not fully charged. Please charge it firstly on the 1st

Youtube: Zhiliao Support Instagram: Zhiliaoofficial