

物料名称:		E32Pro手表快速指南 (Stiive Fit App)	成品	尺寸:	70 x 99mm	V2	
时	间:	2024-06-16	材	质:	128g哑粉纸,风琴折	V3	
设	计:		エ	艺:	四色 双面印刷	V3	
料	号:	202-11-SH-E32Pro-V1	备	注:		V4	






All pictures in this guide are for illustration purposes only. Actual product may vary due to product firmware and app upgrades.

Quick Start Guide








0


Turn on the Bluetooth

of your phone.

15:05 □ O ₁₁1 � ■

Bluetooth















Tips:

Find My Phone: Your phone and watch are connected via Bluetooth, you can use the watch to locate your phone by making your phone vibrate or ring.

Note: This feature is not available on

Android phones if the Stiive Fit app is not running on your phone.

Do Not Disturb (DND) mode:

- When the DND mode is enabled, the watch won't ring or vibrate when it receives incoming call alerts, SMS, app notifications.
 And Raise to Wake function will be disabled.
- · DND mode does not affect Alarms.

How to Connect the Bluetooth Call function

1. DND mode must be disabled before using Bluetooth Calling. 2. On your phone, go to "Settings" \rightarrow "Bluetooth" , tap "E32Pro-XXXX(Connected for calls)" to connect.

- To use the Bluetooth Calling feature on the watch, please keep the watch connected to your phone via Bluetooth.
- reminders, but you can use the watch to make calls.
- Ringing or vibration switching can be modified in "Setting" -
- . This feature will reduce the watch's battery life

Important Safety Instructions

- The device contains electrical equipment that may cause injury if not used properly. For example, prolonged contact may contribute to skin allergies for some users. To reduce irritation, please read the safety guidelines on the following pages to ensure proper use and care.

 Do not expose your device to liquid, moisture, humidity or rain while charging; do not charge your device when it is wet, as this may result in electrical shock or the charge your device when it is wet, as this may result in electrical shock or the charge your device when it is wet, as this may result in electrical shock or the charge your device when it is wet, as this may result in electrical shock or the charge your device when it is wet, as this may result in electrical shock or the charge your device when it is wet, as this may result in electrical shock or the charge your device when it is wet, as this may result in electrical shock or the charge your device when it is wet, as this may result in electrical shock or the charge your device when it is wet, as the property of the charge your device when it is wet, as the property of the charge your device when it is well as the property of the charge your device when it is well as the property of the pro

- and injury.

 Consult your doctor before use if you have any preexisting conditions that might be affected by using this device.

 Do not expose your watch to extremely high or low temperatures.

 Do not leave your watch near open flames such as cooking stoves, candles, or fireplaces.
- fireplaces.
 This product is NOT a toy never allow children or pets to play with this product. Always store the product out of the reach of children. The devices themselves or the many small parts they contain may cause choking if ingested.

 Never try to abuse, crush, open, repair or disassemble this device. Doing so will void the warranty and can result in a safety hazard.
- If any parts of your product require replacement for any reason, including normal wear and tear or breakage, please contact us. Do not use your device in a sauna or steam room.

 Dispose of this device, the device's battery and its package in accordance with local regulations.
- local regulations. Do not check any notifications, GPS, or any information on your device's display while driving or in other situations where distractions could cause injury or hazard. Always be aware of your surroundings while exercising.

Battery Warnings

- nium-ion battery is used in this device. If these guidelines are not followed, eries may experience a shortened life span or may cause fire, chemical burn trolyte leakage, and/or injury. NOT disassemble, modify, remanufacture, puncture or damage the device
- Do NOT remove or attempt to remove the non-user-replaceable battery.
- . Do NOT expose the device or batteries to fire, explosion, or other hazards,

- Health Warnings
 If you have a pacemaker or other internal electronic device, consult your physician before using a heart rate monitor.
- The optical wrist heart rate monitor emits green light and flashes occasionall Consult your physician if you have epilepsy or are sensitive to flashing lights.
- Always consult your physician before beginning or modifying any exercise program.

- The heart rate and blood oxygen level readings are for reference only, and no responsibility is accepted for the consequences of any erroneous readings.
- While the optical wrist heart rate monitor technology typically provides the best estimate of a user's heart rate, there are inherent limitations with the technology that may cause some of the heart rate readings to be inaccurate under certain circumstances, including the user's physical characteristics, fit of the device, and type and intensity of activity.
- The smart watch relies on sensors that track your movements and other metrics. The data and information provided by these devices are intended to be a close estimation of your activity and metrics tracked, but may not be completely accurate, including step, sleep, distance, heart rate, blood oxygen stress and calorie data.

FCC ID: 2A2K3-E32PRO

FCC Statement
This equipment has been tested and found to comply with the limits for a Class B
digital device, pursuant to part 15 of the FCC rules. These limits are designed to
provide reasonable protection against harmful interference in a residential
instal lation.

ITATION. equipment generates, uses and can radiate radio frequency energy and, if not lied and used in accordance with the instructions, may cause harmful INTELLIBERATION
TO radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful Interingence to aradio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of

and on, the war and on, the war are the receiving antenna.

-Boortent or relocate the receiving antenna.

-Boortent or relocate the receiving antenna.

-Boortent or relocate the superation between the equipment and receiver.

-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

-Consult the dealer or an experienced radioffly technical on for help.

To assure connected.

To assure connected the receiving any changes or modifications not expressly to assure connecting to To assure continued compilance, any changes or modifications not expressly approved by the party.

Assporable for compilance and void the user's authority to operate this desponsible for compilance only shelded interface cables when connecting to compilate or peripheral devices.

This equipment compiles with Part 15 of the FCC Rules. Operation is subject to the following two countilons:

(1) This device may not cause harmful interference, and the properties of the party of the properties of th

RF warning statement: The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

Important Safety Guide

Some people with allergic skin may react when their skin is exposed to materials used in watches for a long time. This may be caused by allergies, environmental factors, prolonged exposure to irritants such as sweat and soap, or other factors. If you have known skin allergies, please pay special attention when wearing the watch.



Please do not wear your watch too tight.



If your watch gets wet (for example after sweating or showering), clean and dry it thoroughly before putting it



Make sure your skin is dry before you put your watch back



Prolonged rubbing and pressure may irritate the skin, so give your wrist a break by removing the watch regularly.