


## CM9-976 DIGITAL TIMER SWITCH

### Digital Timer Wire Connection Diagram



### Program Digital Timer

1. Use a pin and press “C”, once digital screen is reset.
2. Press “D+” to set current day, “H+” hour, and “M+” minute.
3. Press “G” after finish setting the date and time.
4. Press “P” to select the program setting 1 (total 28 program setting). User should see “1 ON” (opening time). Press “D+” to set the days that needed, “H+” for the hour, and “M+” for the minute.
5. Press “P” again to select the program setting “1 OFF” (closing time). Press “D+” to set the days that needed, “H+” for the hour, and “M+” for the minute.
6. Follow Setp 4 and 5 until finish programed the timer.
7. Press “G” after finish.

**NOTE:** To disable the digital timer, click on “Manual”.