




Dell Speakerphone

SP3022


Quick Start Guide




Front




Back







USB-A



USB-C



www.dell.com/support
www.dell.com/contactdell
www.dell.com/regulatory_compliance
www.dell.com/support/dpem
 Regulatory Model: SP3022