


# Remote Control Using Manual



## Please note:



**NO voice button**



**NO pairing button**



**NO headphone jack**



**NO internal battery**

This product does not have the above buttons, please turn to the second page for details of applicable models.

# Full Compatibility



for TCL Roku TVs



for Hisense Roku TVs



for Onn Roku TVs



for Sharp Roku TVs



for Element Roku TVs



for Westinghouse Roku TVs



for Philips Roku TVs



for Insignia Roku TVs



for JVC Roku TVs



for RCA Roku TVs



for Hitachi Roku TVs



for Sanyo Roku TVs



## Not applicable models



**Not for Roku Stick**

**Not for Roku Ultra**

**Not for Roku Box**

**Not for Roku Game**