

Wireless Earphones User Manual

i12

Pairing name: TWS Bluetooth version: 5.4

1. Pairing method: Press and hold the POWER button for 3 seconds to turn on the device. The two headphones will automatically pair when the red and blue flashing lights turn on. If the red and blue lights in the left and right ears turn off, it indicates that the pairing is successful.

Function key: POWER

2. Power on prompt sound: Power on

3. Shutdown prompt sound: Shutdown

4. Connection prompt sound: Connection successful

5. Disconnect prompt sound: The link has been disconnected

6. Low battery warning sound: Low battery, please charge in a timely manner

7. Key functions: Long press for 3 seconds to turn on/off, click on music playback, pause, answer incoming calls, hang up calls, long press up and down songs, double-click add and subtract, three clicks on SIRI, and four clicks on replay.

FCC WARNING

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

—Reorient or relocate the receiving antenna.

—Increase the separation between the equipment and receiver.

—Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

—Consult the dealer or an experienced radio/TV technician for help.

Note: The Grantee is not responsible for any changes or modifications not expressly approved by the party responsible for compliance. such modifications could void the user's authority to operate the equipment.

The device has been evaluated to meet general RF exposure requirement.

This equipment complies with FCC's RF radiation exposure limits set forth for an uncontrolled environment. This device and its antenna(s) must not be co-located or conjunction with any other antenna or transmitter.

Label:

FCC ID: 2A27V-I12