


型号: GM2 pro

尺寸：73*93

材质：80g铜版纸（折页）

联想 thinkplus LivePods GM2 pro
真无线蓝牙耳机



使用说明书
使用前请阅读使用说明书

Lenovo

产品规格

蓝牙版本: V5.3
传输距离: > 10m
电池容量: 400mAh
使用时间: 约 5-8小时 (耳机)
充电时间: 约 1小时 (耳机)
额定输入: 5V \equiv 35mA


充电盒规格

电池容量: 350mAh
充电时间: 约 1.5小时
额定输入: 5V \equiv 300mA
(所有技术规格均以实际性能为准)

给充电盒充电

Type-C—充电线连接充电盒到5V电源适配器。

(温馨提示: 打开充电盒盖, 把充电盒盖打开区域对准, 请同时使用充电线)



额定输入: 5V \equiv 35mA (耳机)

5V \equiv 300mA (充电盒)

| LED指示状态 | |
|----------|-------------|
| 模式 | 描述 |
| 开机 | 耳机指示灯呈红灯亮1秒 |
| 充电 | |
| 配对 | 耳机呈红灯闪烁 |
| 连接 | 耳机指示灯熄灭 |
| 断开 | 耳机呈红灯闪烁 |
| 耳机充电 | 耳机呈红灯闪烁 |
| 充电结束耳机充电 | 耳机指示灯呈绿灯亮 |
| 充电结束充电 | 耳机呈红灯闪烁 |
| 充电结束充电 | 指示灯呈红灯闪烁 |
| 充电结束充电 | 指示灯呈红灯亮 |

产品使用说明

1. 开机

方式1：长按耳机侧区域5秒

方式2：在耳机充电时打开充电盒上盖，取出耳机自动开机

2. 关机

方式1：耳机状态无连接3分钟后自动关机

方式2：耳机放入充电盒，关闭充电盒盖子后自动关机充电

3. 配对

步骤一：耳机后盖自动进入蓝牙配对

步骤二：打开手机蓝牙和蓝牙配对设备，选择“慧想thinkplus-GM2 Pro”并连接

步骤三：在手机蓝牙和蓝牙配对设备，请重复出厂设置，放回充电仓再打开手机蓝牙配对

步骤四：左右耳机出现不配对时，请重复出厂设置。

出厂设置：长按耳机“+”键

重置耳机：长按耳机“-”键

触控操作

双耳模式

- 语音助手：长按左耳机2秒
- 普鲁加：单击右耳机
- 普鲁加：单击左耳机

音乐播放模式

- 播放/暂停：双击任意耳机触控键
- 上一曲：三击左耳机
- 下一曲：三击右耳机

电话接听

- 接听来电：双击任意耳机触控键
- 挂断电话：双击任意耳机触控键
- 拒接电话：长按任意耳机触控键2秒

游戏模式（语音模式）：已预装设备

- 长按2秒右耳机进入游戏模式
- 长按2秒右耳机进入音乐模式

备注：出厂默认为音乐模式

恢复出厂设置


耳机开机后未与蓝牙耳机配对接状态下，连续单击双耳触控键3次清除对已配对信息内存。

产品中有害物质名称及含量

| 产品中有害物质的名称及含量 | | | | | | | | | |
|---------------|-------|-------|-------|-----------------|---------------|-----------------|--|--|--|
| 部件名称 | 有害物质 | | | | | | | | |
| | 铅(Pb) | 汞(Hg) | 锡(Sn) | 六价铬 (Cr(VI)) | 多溴联苯 (PBB) | 多溴二苯醚 (PBDE) | | | |
| 印刷电路板组件 | ○ | ○ | ○ | ○ | ○ | ○ | | | |
| 外壳等小组件 | ○ | ○ | ○ | ○ | ○ | ○ | | | |

本表格依据 SJ/T 11364 的限定制定。
 ○：表示该有害物质在该部件所有均质材料中的含量均在 GB/T 26572 规定的限量要求以下。
 ×：表示该有害物质至少在该部件的某一均质材料中的含量超出 GB/T 26572 规定的限量要求。
 印刷板记“X”的部件，因目前全球技术发展水平难以完全实现有害物质的替代。

本表格所列组件，包括印刷电路基板及其零部件、电子元件等，根据产品型号不同，您所购买的產品可能不会含有以上所有组件。



在中华人民共和国境内销售的电气产品必须标注此标志，标志中的数字代表在正常的使用状态下的产品的环保使用期限。

保修声明

免责声明
本使用手册没有任何形式的担保、立保或表达其他声明。本使用手册所提到的产品、规格及信息仅供参考，内容亦会随时更新于网页上，恕不另行通知。

保修声明
本文件所描述的产品保修如下：如产品在购买后自起十二（12）个月（“保修期”）内，正常使用状态下出现质量问题，我们将负责维修、更换零件，免费退货；经厂家确认无法修复的，免费退货；保修期自售出之日起算，在保修保修期（最长不超过30天）内维修没有有效，购买及已经发生费用为0；如无法通过退货方式，则保修期自生产日期起至十三（13）个月止。如保修期，请首先致电产品服务热线，并接拨我们的服务热线。申请保修时，您需要提供完整、清晰和准确填写的有效销售发票。

以下保证不适用于下列情况：
1. 产品没有有效的保修；
2. 通过第三方、产品制造商与本产品无关；
3. 故障、损坏由于不当的使用、维修、维护或保管而引起的故障或损坏；
4. 由于不可抗力（如地震、战争、火灾等）或意外导致的使用或损坏；
5. 自损、损坏或受到火灾或损坏；
6. 因使用不当造成损坏或造成损坏；
7. 任何损坏或损坏造成的损坏；
8. 有使用过水电器产品的产品；
9. 因使用不当造成的损坏；
10. 产品在使用过程中发生老化、腐蚀、磨损、变形、损坏及其他损坏。
11. 本产品保修标准将随着法规的变化、法规、标准、更新及其他标准而改变。本使用手册仅供参考，恕不另行通知。

保修声明

产品及随附物料的齐备和外观完好不属于保证范围，应在接收产品时当场检验并对任何不属提出异议。

以上保证是我们产品推出的全部保证，自仅在中能大基地地区内适用。本文件的任何内容均不得将根据法律规定不能得除或限制的消费者权益。

服务热线：400-812-0102


售后邮箱：frank@szeyeslan.cn

“Lenovo”、“thinkplus” 是联想集团所属企业的商标，提及及其他公司、产品和服务名称可能是其他公司的商标。

版权所有 © 2022 联想集团所属企业和/或其许可方保留所有权利。

thinkplus

Lenovo thinkplus LivePods GM2 pro



Manual

Please read this manual
carefully before using the earbuds

Lenovo

Microphone

Touch area indicator status

Sound hole

Charging cable

Charging case LED area

Type-C charging port

Manual assembly card

Type-C charging cable

Product specifications


BT version : V5.3
Transmission distance : $\geq 10\text{m}$
Battery capacity : 40mAh
Playing time : About 5 hours (Headphone)
Charging time : About 1 hours (Headphone)
Rated input : 5V = 35mA

Charging case specifications

Battery capacity : 350mAh
Charging time : About 1.5 hours
Rated input : 5V = 300mA
(All technical information is subject to actual performance)

Charge the charging box
Connect the charging box to the 5V power adapter with the Type-C

Charging cable
(Reminder: Open or close the charging box. When the blue light of the charging box flickers, please charge the charging box in time.)



The diagram illustrates the charging setup. On the left is a white rectangular charging box with a Type-C port on its bottom edge. A black charging cable is connected to this port. The other end of the cable is a USB-A connector, which is plugged into a white power adapter. To the right of the power adapter is a small icon of the power adapter, showing its standard two-prong electrical plug.

Rated input: 5V = 35mA (Headphone) 5V = 300mA (Charging Case)

| LED Indicator Status | Indicator |
|--|--|
| Power On | The headphones indicator light is blue for 3 seconds |
| Power Off | ----- |
| Pairing | The headphones flash in blue |
| Connected | Headphones indicator off |
| Disconnected | The headphones flash in blue |
| Low Battery | The headphones flash in blue |
| The charging case charges the earphone | The headphones indicator is blue and keeps on |
| Charging case low power | indicator flashes |
| Charging case charging | indicator flashes |
| Charging case full | indicator light is on |

Product operation instructions

- Power On**
 - Option 1: Long press the MFB button for 5 seconds.
 - Option 2: The earbuds automatically turn on when they are taken out from the charging case.
- Power Off**
 - Mode 1: There is no connection in the power on state, and it will automatically shut down after 3 minutes.
 - Mode 2: Put the earphone back into the charging box and automatically shut down;
- pairing**
 - Step 1: Automatically enter bluetooth pairing mode after power on.
 - Step 2: Open the list of bluetooth devices, search "Bluetooth-QM9 pro" and connect it.
 - Step 3: When the left and right earphones do not match, please return the factory setting by clicking it back to the charging compartment and then turn on the automatic pairing.

| Touch | Function |
|------------|----------------|
| 1 tap | Play/Pause |
| 2 tap | Next |
| 3 tap | Previous |
| Long press | Volume Up/Down |

Pressing twice: "Voice prompt" "Play/Stop"
 Pressing successively: "Next/previous" "Long play/stop"

Touch key operation

Conventional mode

- Voice assistant: Long press the left earphone 2S
 Volume+ : Click right MFB
 Volume- : Click left MFB
- Music playback mode
- Pause/Play: Double-click on any of the headphone
 Last song : Triple click left MFB
 Next song : Triple click right MFB
- Phone hands-free
- Answer: Double-click the touch area of any headphone
 Hang up : Double-click the touch area of any headphone
 Reject call: Long press any earphone touch button for 2S
- Game/multitask mode switching combined mode

Press right MFB for 2 seconds to enter game mode
 Press right MFB for 2 seconds to enter music mode
 Note: the factory default is music mode

Reset

Headset is not paired with the BT device after it is turned on/click headset/aux function key for 5 times after the pairing information then turn it off.

The name and content of harmful substances in the earbuds

| Part Names | Harmful Substances | | | | | |
|--------------------------------------|--------------------|----|----|--------|-----|------|
| | Pb | Hg | Cd | Cr(VI) | PBB | PBDE |
| Printed circuit assembly | ○ | ○ | ○ | ○ | ○ | ○ |
| Small structural parts such as shell | ○ | ○ | ○ | ○ | ○ | ○ |


This form is compiled in accordance with GB/T 19564.
○ Indicates that the content has no harmful substance in this form of harmful materials of the part is below the limit required by GB/T 26572.

△ Indicates that the hazardous substance is listed in certain harmful materials of the part exceeds the limit requirements specified in GB/T 26572.

The parts marked with "X" on the form are all harmful due to the limitation of global technological development. Substitution of substances. Printed circuit board components.

Printed circuit board components and their particulate/electronic components, except depending on the product model/electronic parts you purchased may not comply with the above components.

Electronic and electrical products sold in the People's Republic of China must mark this LOGO the number in the logo represents the product under normal use Environmental protection use period.



Warranty statement

Disclaimer

This user manual does not have any form of guarantee, position extension or other implication. The mentioned products, specifications and information are for reference only. The content will also be updated on the web at any time, without additional separate notice.

Warranty statement:

The product attached to this statement is guaranteed as follows if the product is used within 12 months from the date of purchase ("Warranty Period", under normal conditions of use due to quality defects damaged), can be repaired free/repair/replace if the product is damaged. If the product is confirmed to be damaged or replaced product. Continue to enjoy the warranty during the period of the warranty period (the shortest not less than 30 days). Purchased by save the ticket date shall prevail; the purchase cannot be determined the warranty period shall be 12 (12) months. If you apply for a warranty, please call the product service hotline first and execute it in the manner instructed by us. When applying for warranty you need to provide an accurate complete and true or filled out valid information.

The above guarantee does not apply to the following situations:

- 1. Exceeding the validity period of the three packs;
- 2. Altering the warranty card and product code does not match the product body;
- 3. Causes caused by misuse/abuse or improper transportation, use, maintenance or storage accidents or damage;
- 4. Natural or damage caused by force majeure (such as earthquake, disaster), or other obstacles;

7. The zipper and tower buckle are damaged due to excessive force;

Warranty statement

6.Disconnection or tearing caused by excessive load;
7.Air damage caused by sharp objects;
8.Damage with signs of burning of foaming;
9.Damage caused by unauthorized disassembly;
10.Aging,discoloration,abrasion,rupture and other losses that occur during the normal use of the product.
11.If the original identification label of the product is changed or damaged,this guarantee will become invalid.

The completeness and appearance of the product and accompanying materials are not within the scope of the guarantee.You should check on the spot and raise objections to any discrepancies.

The above guarantees are all guarantees we make regarding the product and are only valid when mentioned China.Nothing in this document affects consumer rights that cannot be excluded or restricted under the law proff.

Service supervision hotline: 400-812-0120
After-sales mailbox:frank@cszyszyan.cn

"Lenovo" , "thinkplus" is a trademark of a company owned by Lenovo Group. The names of other companies, products and services mentioned may be trademarks of other companies.
Copyright © 2022 Lenovo Group and its licensors. All rights reserved.

thinkplus