


EXPLOSION-DRAWING / SPAREPARTS-OVERVIEW

EXPLOSIONSZEICHNUNG / ERSATZTEILLISTE



SPORTSTECH

ERGOMETER ESX500

Number in explosion drawing	Item number	Description
A	SP_ESX500_A	Console
A-1	SP_ESX500_A-1	Screw for console
A-2	SP_ESX500_A-2	Cable for console
B	SP_ESX500_B	Handlebar
B-1	SP_ESX500_B-1	Foam
B-2	SP_ESX500_B-2	End cap
B-3	SP_ESX500_B-3	Hand pulse sensor
B-4	SP_ESX500_B-4	Screw
B-5	SP_ESX500_B-5	Hand pulse cable
C	SP_ESX500_C	Handrail
C-1	SP_ESX500_C-1	Cable
C-2	SP_ESX500_C-2	Washer
C-3	SP_ESX500_C-3	Sleeve
C-4	SP_ESX500_C-4	Springing disc
C-5	SP_ESX500_C-5	Decorative cap
C-6	SP_ESX500_C-6	T-shaped knob
C-7	SP_ESX500_C-7	Screw for water bottle holder
C-8	SP_ESX500_C-8	Bottle holder
D	SP_ESX500_D	Main frame
D-1	SP_ESX500_D-1	Bearing
D-2	SP_ESX500_D-2	Axis
D-3	SP_ESX500_D-3	Pulley
D-4	SP_ESX500_D-4	Axis
D-5	SP_ESX500_D-5	Hex screw
D-6	SP_ESX500_D-6	Belt
D-7L	SP_ESX500_D-7L	Left chain cover
D-7R	SP_ESX500_D-7R	Right chain cover
D-8	SP_ESX500_D-8	Decorative cap
D-9R	SP_ESX500_D-9R	Right crank
D-9L	SP_ESX500_D-9L	Left crank
D-10	SP_ESX500_D-10	Screw
D-11	SP_ESX500_D-11	Decorative cap for crank
D-12R/L	SP_ESX500_D-12R/L	Right and left pedal
D-13	SP_ESX500_D-13	Screw
D-14	SP_ESX500_D-14	Screw
D-15	SP_ESX500_D-15	Motor
D-16	SP_ESX500_D-16	Tension control knob
D-17	SP_ESX500_D-17	Plastic sleeve
D-18	SP_ESX500_D-18	Handrail cap
D-19	SP_ESX500_D-19	Screw
D-20	SP_ESX500_D-20	Cruded washer
D-21	SP_ESX500_D-21	Sensor rod
D-22	SP_ESX500_D-22	Sensor plate
D-23	SP_ESX500_D-23	Motor wire
D-24	SP_ESX500_D-24	Wire
E	SP_ESX500_E	Magnet fixing plate

Number in explosion drawing	Item number	Description
E-1	SP_ESX500_E-1	Hex screw
E-2	SP_ESX500_E-2	Hex screw
E-3	SP_ESX500_E-3	Hex screw
E-4	SP_ESX500_E-4	Magnetic spring
F	SP_ESX500_F	Rear stabilizer
F-1	SP_ESX500_F-1	End cap
F-2	SP_ESX500_F-2	Front stabilizer
F-3L	SP_ESX500_F-3L	Left nylon roll
F-3R	SP_ESX500_F-3R	Right nylon roll
F-4	SP_ESX500_F-4	Screw
F-5	SP_ESX500_F-5	Screw
G	SP_ESX500_G	Metal plate
G-1	SP_ESX500_G-1	Nylon nut
G-2	SP_ESX500_G-2	Bearing
G-3	SP_ESX500_G-3	Wheel
G-4	SP_ESX500_G-4	Tube
G-5	SP_ESX500_G-5	Tube
G-6	SP_ESX500_G-6	Washer
G-7	SP_ESX500_G-7	Screw
G-8	SP_ESX500_G-8	Spring
G-9	SP_ESX500_G-9	Bearing 6800
H	SP_ESX500_H	Wheel
H-1	SP_ESX500_H-1	Hex nut
H-2	SP_ESX500_H-2	Tube
H-3	SP_ESX500_H-3	Spindle
H-4	SP_ESX500_H-4	Ring
H-5	SP_ESX500_H-5	Ring
H-6	SP_ESX500_H-6	Ring
H-7	SP_ESX500_H-7	Smal role
H-8	SP_ESX500_H-8	Stift
I	SP_ESX500_I	Seat
I-1	SP_ESX500_I-1	Nylon nut
I-2	SP_ESX500_I-2	Sliding tube
I-3	SP_ESX500_I-3	Washer
I-4	SP_ESX500_I-4	Handlebar post
I-5	SP_ESX500_I-5	Knob
I-6	SP_ESX500_I-6	Washer
I-7	SP_ESX500_I-7	Seat pin
I-8	SP_ESX500_I-8	End cap
J	SP_ESX500_J	Adaptor
not in drawing	SP_ESX500_B-6	Handlebar set
not in drawing	SP_ESX500_J-1	UK adaptor
not in drawing	SP_ESX500_K	Sticker
not in drawing	SP_ESX500_Carton	Carton
not in drawing	SP_ESX500_Manual	Manual
not in drawing	SP_ESX500_Screw set	Screw and tool set