英文说明书 BK462S SUNNY

材料:128克铜版纸双面 CMYK+专色双面印刷 风琴折

切线: 封面 折线: SUNNY **O** 4. REMOVE THE INSULATING SHEET BEFORE USING 5. INSTALLATION 1. PRODUCT INTRODUCTION 3. BASIC PARAMETERS 6. APP CONNECT INSTRUCTION SUNNY We thank you for choosing our SunnyFit Bike Cadence. Our product is 6.1 Scan the below QR code to download the SunnyFit APP.
6.2 You can also download the SunnyFit APP from the App Store or Attach the Flat Rubber Mat onto the back of the SunnyFit Bike developed to help track your cycling performance. Please keep this user manual for future reference. Cadence then secure with Small Band or Plastic Cable Tie onto Product Net Weight the pedal crank. SUNNYFIT BIKE CADENCE 2. PRODUCT ACCESSORIES CB110 **USE MANUAL** Power on: Blue/Red light will flash 10 times within 10 seconds after power on Wake up: Blue/Red light will flash 6 times within 3 seconds after wake up. For assistance with parts or troubleshooting, please contact us at 9 Ø it. Please remove the insulating sheet $\,$ before using it, $\,$ then put the support@sunnyhealthfitness.com or 1-877-90SUNNY (877-907-8669). Connect: Blue/Red light will flash once every 15 seconds battery cover back and turn clockwise toward small circle to lock it. WWW.SUNNYHEALTHFITNESS.COM 6.3 Rotate the pedal crank and search for the SunnyFit Bike Cadence NOTE: If you select the "OUTDOOR BIKE" on the SunnyFit APP. the 6.4 Open the Sport page of the SunnyFit APP, go the "workout" tab, 6.5 After clicking the "Retry" button, you could see a scan dialog box, 6.6 Click the "Choose Your Bike" button and choose the equipment 7. DISCLAIMER choose "Indoor" or "Outdoor", click the "Search" botton to connect the SunnyFit Bike Cadence with the SunnyFit APP. SunnyFit Bike Cadence would change to Speed mode. Please remove the SunnyFit Bike Cadence from the pedal crank. Attach the Curved using ANT+ or Bluetooth device. Follow the steps on the SunnyFit accordingly. Then click the "Select" button to confirm. 7.1 The information on this manual is for reference only. This product may be subject to change based on manufacturer's research and WITH US APP choose the bike accordingly. Rubber Mat onto the back of the SunnyFit Bike Cadence, then secure development without notice. 7.2 We shall not make any statement or warranty about this manual 7.3 We shall not bear any legal responsibility for any direct or indirect, accidental or special damages, losses and expenses arising form or it connection with this manual or the product. SF-B1970 Select SF-RB4850 Select OUTDOOR BIKE Select PANTONE 485 C 正面 反面