



Surf's Up RC



- GB POWER F ALIMENTATION
E ALIMENTACIÓN D LEISTUNG
I ENERGIA P ALIMENTAÇÃO ELÉTRICA
NL STROOM

- 1 BATTERIES: 2X AAA (NOT INCLUDED)
PILES : 2X AAA (NON FOURNIES)
BATERÍAS: 2 TIPO AAA
(NO INCLUIDAS)
BATTERIJEN: 2X AAA
(NIET INBEGREPEN)
PILE: 2 AAA (NON INCLUSE)
PILHAS: 2 AAA (NÃO INCLUSAS)
BATTERIEN: 2 AAA
(NICHT ENTHALTEN)

- 2 LED INDICATOR
PAIRING: FAST BLINKING GREEN
POWER ON: GREEN
CHARGING: RED
FULLY CHARGED: GREEN
LOW BATTERY: SLOW BLINKING
GREEN

- LED-ANZEIGE
VERBINDUNG: BLINKT SCHNELL GRÜN
EINGESCHALTET: GRÜN
LÄDT: ROT
VOLLSTÄNDIG GELADEN: GRÜN
NIEDRIGER BATTERIESTATUS: BLINKT
LANGSAM GRÜN



- INDICADOR LED
A EMPARELHAR: VERDE
INTERMITENTE
RÁPIDO
LIGADO: VERDE
A CARREGAR: VERMELHO
CARGA A 100%: VERDE
BATERIA FRACA: VERDE
INTERMITENTE


- INDICADOR LED
VINCULANDO: PARPADEO
RÁPIDO VERDE
ENCENDIDO: VERDE
CARGANDO: ROJO
CARGA COMPLETADA: VERDE
BATERÍA BAJA: PARPADEO
LENTO VERDE

- INDICATEUR LED
APPARIEMENT: VERT CLIGNOTANT
RAPIDEMENT
EN MARCHÉ: VERT
EN CHARGE: ROUGE
COMPLÈTEMENT CHARGÉ: VERT
BATTERIE FAIBLE : VERT
CLIGNOTANT LENTEMENT

- INDICATORE LED
ABBINAMENTO: LAMPEGGIAMENTO
VERDE RAPIDO
ACCENSIONE: VERDE
RICARICA: ROSSO
RICARICA COMPLETA: VERDE
LIVELLO DI BATTERIA BASSO:
LAMPEGGIAMENTO VERDE LENTO



- LED-LAMPJE
KOPPELEN: SNEL GROEN
KNIPPEREND
AAN HET LADEN: GROEN
CHARGING: ROOD
BATTERIJFOUT: GROEN
BATTERIJ BIJNA LEEG: LANGZAAM
GROEN KNIPPEREND

- 3 TURN ON REMOTE AND SKATEBOARD
ALLUMER LA TÉLÉCOMMANDE ET FAIRE DE LA PLANCHE À
ROULETTES
ENCIENDA EL CONTROL REMOTO Y EL MONOPATÍN
FERNBEDIENUNG UND SKATEBOARD EINSCHALTEN
ACCENDI IL TELECOMANDO E LO SKATEBOARD
LIGA O COMANDO E O SKATEBOARD
AFSTANDSBEDIENING EN SKATEBOARD INSCHAKELLEN



- GE REMOTE FUNCTIONS F FONCTIONS DE LA TÉLÉCOMMANDE
E FUNCIONES DEL MANDO D AFSTANDSBEDIENINGSFUNCTIES I FUNZIONI DEL
RADIOCOMANDO P FUNÇÕES DO CONTROLE REMOTO NL FERNSTEUERUNG

- 4 MOVE BOARD SIDE TO SIDE TO TURN
INCLINER LA PLANCHE POUR TOURNER
INCLINE AL TABLA PARA GIRAR
BRETT KIPPEN, UM ES ZU DREHEN
INCLINA LA TAVOLA PER GIRARLA
INCLICA A PLACA PARA VIRAR
KANTEL BORD OM TE KEREN
- 5 PUSH BOARD FORWARD/BACKWARD TO DRIVE
POUSSEZ LE TABLEAU EN AVANT/TIREZ LE TABLEAU EN ARRIÈRE POUR
CONDUIRE
PRESIONE/EMPUJE LA TABLA HACIA DELANTE/ATRÁS PARA
CONDUICIRLA
BEWEGEN SIE DAS BRETT VORWÄRTS/RÜCKWÄRTS, UM ZU FAHREN
SPINGI LA TAVOLA IN AVANTI/INDIETRO PER GUIDARE
EMPURRA A PLACA PARA A FRENTE/TRÁS PARA CONDUZIR
DUW HET BORD VOORUIT/ACHTERUIT OM TE RIJDEN



* ALL INSTRUCTION SHEETS MUST BE RETAINED SINCE IT
CONTAINS IMPORTANT INFORMATION.* TOUTES LES FICHES
D'INSTRUCTIONS CONTIENNENT DES INFORMATIONS
IMPORTANTES ET DOIVENT DONC ÊTRE CONSERVÉES.* DEBE
CONSERVAR TODAS LAS HOJAS DE INSTRUCCIONES PORQUE
CONTIENEN INFORMACIÓN IMPORTANTE.* ALLE ANLEITUNGEN
MÜSSEN AUFBEWAHRT WERDEN, DA SIE WICHTIGE INFORMA-
TIONEN ENTHALTEN.* ALLE INSTRUCTIEBLADEN MOETEN
WORDEN BEWAARD, OMDAT ZE BELANGRIJKE INFORMATIE
BEVATTEN.* TUTTE LE ISTRUZIONI VANNO CONSERVATE, IN
QUANTO CONTENGONO INFORMAZIONI IMPORTANTI.* TODOS
OS MANUAIS DE INSTRUÇÕES DEVEM SER PRESERVADOS, POIS
CONTÊM INFORMAÇÕES IMPORTANTES.

WE RESERVE THE RIGHT TO IMPROVE/AMEND SPECIFICATIONS
AND COLORS WITHOUT NOTICE.
NOUS NOUS RÉSERVONS LE DROIT D'AMÉLIORER OU DE MODIFIER
LES CARACTÉRISTIQUES ET LES COULEURS SANS AVERTISSEMENT.
NOS RESERVAMOS EL DERECHO A MEJORAR/CORREGIR
ESPECIFICACIONES Y COLORES SIN PREVIO AVISO.
WIR BEHALTEN UNS DAS RECHT VOR, SPEZIFIKATIONEN UND
FARBEN OHNE VORANKÜNDIGUNG ZU VERBESSERN/ZU ÄNDERN.
CI RISERVIAMO IL DIRITTO DI MIGLIORARE/RIVEDERE SPECIFICHE
E COLORI SENZA PREAVVISO.
RESERVAMOS O DIREITO DE MELHORAR OU ALTERAR
ESPECIFICAÇÕES E CORES SEM AVISO PRÉVIO.
WE BEHOUDEN ONS HET RECHT VOOR OM SPECIFICATIES EN
KLEUREN ZONDER VOORAFGAANDE KENNISGEVING TE
VERBETEREN/WIJZIGEN.

The USB cable used with the electric toy shall be regularly examined for damage to
the supply cord, plug, enclosure or other parts, and in the event of damage, it shall
not be used until the damage has been repaired.

CAUTION: Risk of Fire and Burns. Do Not Open, Crush, Heat Above 80°C or Incinerate.
Follow Manufacturer's Instructions.

FCC ID : 2AWSR-F71156A /
FCC ID : 2AWSR-F71156B
MODEL : 71156

FCC label compliance statement:

This device complies with part 15 of the FCC rules. Operation is subject to
the following two conditions:

1. This device may not cause harmful interference, and
2. This device must accept any interference received, including
interference that may cause undesired operation. Note: This equipment
has been tested and found to comply with the limits for a Class B digital
device, pursuant to Part 15 of the FCC Rules. These limits are designed to
provide reasonable protection against harmful interference in a residential
installation. This equipment generates, uses and can radiate radio
frequency energy and, if not installed and used in accordance with the
instructions, may cause harmful interference to radio communications.
However, there is no guarantee that interference will not occur in a
particular installation. If this equipment does cause harmful interference
to radio or television reception, which can be determined by turning the
equipment off and on, the user is encouraged to try to correct the
interference by one or more of the following measures:

- Reorient or relocate the receiving antenna
- Increase the separation between the equipment and receiver
- Connect the equipment into an outlet on a circuit different from that
to which the receiver is connected
- Consult the dealer or an experienced radio/TV technician for help

Warning: Changes or modifications to this unit not expressly approved by
the party responsible for compliance could void the user's authority to
operate the equipment.



Distributed by Funrise, Inc.
Sherman Oaks, CA 91403, U.S.A.
1-800-882-3808

NICK.COM/SPONGEBOB www.funrise.com

© 2024 Viacom International Inc. All Rights Reserved.
Nickelodeon, SpongeBob SquarePants and all related titles,
logos and characters are trademarks of Viacom International
Inc. Created by Stephen Hillenburg.

