



V10 3in1


User Manual

产品说明书


ENGLISH / 简体中文

Thank you for choosing PXN products and your support for our brand, please read this manual carefully before starting to enjoy your gaming experience.
感谢您选择 PXN 莱仕达的产品,感谢您对 PXN 莱仕达品牌的支持,在使用之前请仔细阅读本手册。

APPEARANCE / 产品外观



PRODUCT CONTENT / 配件图




SYSTEM REQUIREMENTS / 系统要求

Supported platforms : PC / PS4 / X-ONE / X-Series X|S
Compatible computer operating systems : Windows 7 / 8 / 10 / 11
Note: Original controller should be used for guidance while playing on PS4 and X-ONE / X-Series X|S platforms.
支持平台: PC / PS4 / X-ONE / X-Series X|S
PC 电脑系统要求: Windows 7 / 8 / 10 / 11
注: PS4 和 X-ONE / X-Series X|S 平台使用需要原装手柄进行引导

BACK INTERFACE OF THE STEERING WHEEL / 方向盘背面接口

Back Interface Connection Diagram


【背面接口连接示意图】



STEERING WHEEL INSTALLATION INSTRUCTION / 方向盘安装方法


Assembling of Panel and Base / 组装盘面与基座

Step 1 Align the panel with the panel mounting position of the base, hold the steering wheel dial, and tighten the locking ring.
Step 2 将盘面对准基座的盘面安装位,握住方向盘轂,并旋紧锁圈。




Steering Wheel Fixed Instruction / 固定方向盘

Step 1 Put the steering wheel base in a proper position and install the clamp.
Step 2 Use an Allen key to tighten the screws on the clamp to lock the clamp.
Step 1 将方向盘基座放置到合适位置,并安装夹具。
Step 2 使用内六角扳手拧紧夹具上的螺丝,锁紧夹具。



Steering Wheel Tilt Adjustment Instruction / 方向盘倾角调节


When in use, you can set the inclination of the steering wheel base with 4 gears.
Step 1 Use an Allen key to remove the screws shown in the figure.
Step 2 Adjust the inclination of the base to the corresponding hole position and tighten the screws.
使用时可设置方向盘基座倾角,共 4 档。
Step 1 使用内六角扳手卸下图示螺丝。
Step 2 调整基座倾角至对应的孔位后,锁紧螺丝。



FOOT PEDALS INSTALLATION INSTRUCTION / 脚踏板安装方法


Panel Angle Adjustment of Foot Pedal / 脚踏面板角度调节

Step 1 Use an Allen key to loosen and remove the 2 Allen screws.
Step 2 Adjust the pedal to the desired angle, install and tighten the 2 Allen screws.
Step 1 使用内六角扳手松开并取出 2 颗内六角螺丝。
Step 2 调整脚踏至所需角度,装上并拧紧 2 颗内六角螺丝。




Pedal Strength Adjustment Instruction / 脚踏力度调节

Step 1 Rotate the parts shown in the figure to adjust the pedal strength.
Step 1 旋转图示部件即可调节脚踏力度。
Note: Please adjust the parts within the thread range.
注意: 请在螺纹范围内调节部件。



Foot Pedal Fixed Instruction / 脚踏板固定

Step 1 There are 4 screw holes reserved at the bottom of the foot pedal to fix the pedal to the bracket by combining the corresponding screws.
Step 1 脚踏板底部预留有 4 个螺丝孔,可使用所配螺丝固定在支架上。



INSTRUCTION FOR PLAYING ON PC / PC 电脑使用

Step 1 Connect the gear shift and foot pedals to the steering wheel.
Step 2 Fix the steering wheel and connect it to the power adapter.
Step 3 Plug the USB main cable of the steering wheel to the PC.
Step 4 The steering wheel will be in D-input mode by default if successfully connected, and the red indicator on the steering wheel will be always on.

Mode Switch While Playing on PC

The steering wheel is in D-input mode by default. Press the "D-X" button for 3 seconds to switch to X-input mode and a purple indicator will be always on if successfully switched.
Mode Switch by "D-X" Button

D - input ← Press the "D-X" button for 3 seconds → X - input

D-input mode supports force feedback function (requires the game to support force feedback)
Recommended games: Euro Truck Simulator 2, Forza Horizon 5, Assetto Corsa: Racing, Dirt Rally 2.0, F1 2020.
No forceback feedback function in X-input mode
Recommended games: Forza Horizon 4 (Steam version), Spintires: Snowrunner, Need for Speed: Heat Pursuit.

PC 电脑使用

Step 1 首先将挂挡杆和脚踏板连接至方向盘。
Step 2 将方向盘固定安装好并接入电源适配器供电。
Step 3 将方向盘 USB 主线连接 PC 电脑。
Step 4 连接成功后默认为 D-input 模式,方向盘上红色指示灯长亮。

PC 模式切换

方向盘默认为 D-input 模式,长按 "D-X" 键 3 秒可切换至 X-input 模式,切换成功后方向盘上紫色指示灯长亮。
"D-X" 键切换模式方法:

D - input ← 长按 "D-X" 键 3 秒 → X - input

D-input 模式支持力反馈功能(需游戏支持力反馈)
推荐游戏: 欧洲卡车模拟 2, 极限竞速:地平线 5, 神力科莎:竞速, 尘埃拉力赛 2.0, F1 2020。
X-input 模式无力反馈功能
推荐游戏: 极限竞速:地平线 4 (Steam 版本), 旋转轮胎:雪地奔驰, 极品飞车:热力追踪。

INSTRUCTION FOR PLAYING ON PS4 / PS4 主机使用

Step 1 Connect the gear shift and foot pedals to the steering wheel.
Step 2 Securely install the steering wheel and connect to the power adapter.
Step 3 Turn off the PS4 original controller and use the USB data cable to connect the controller to the controller interface of the steering wheel.
Step 4 Plug the USB main cable of the steering wheel into the USB port of the PS4 host, and turn on the PS4 host.
Step 5 Press the "D-X" button of the steering wheel and the blue indicator of the steering wheel will be always on if connected successfully.

Step 1 首先将挂挡杆和脚踏板连接至方向盘。
Step 2 将方向盘固定安装好并接入电源适配器供电。
Step 3 PS4 原装手柄关机后,使用 USB 数据线将 PS4 原装手柄连接到方向盘手柄引导口。
Step 4 将方向盘 USB 主线插入 PS4 主机 USB 接口,打开 PS4 主机电源。
Step 5 按下方向盘 "D-X" 键,连接成功后方向盘蓝色指示灯长亮。

INSTRUCTION FOR PLAYING ON X-ONE/ X-SERIES X|S / X-ONE/ X-SERIES X|S 主机使用

Step 1 Connect the gear shift and foot pedal to the steering wheel.
Step 2 Fix the steering wheel and connect it to the power adapter.
Step 3 Turn off the X-ONE / X-Series X|S original controller and use the USB data cable to connect the controller to the controller interface of the steering wheel.
Step 4 Plug the steering wheel USB main cable into the USB port of the X-ONE / X-Series X|S host and power on the X-ONE/ X-Series X|S host.
Step 5 Press the "D-X" button of the steering wheel and the green indicator will be always on.

Step 1 首先将挂挡杆和脚踏板连接至方向盘。
Step 2 将方向盘固定安装好并接入电源适配器供电。
Step 3 X-ONE / X-Series X|S 原装手柄关机后,使用 USB 数据线将 X-ONE / X-Series X|S 原装手柄连接到方向盘手柄引导口。
Step 4 将方向盘 USB 主线插入 X-ONE / X-Series X|S 主机 USB 接口,打开 X-ONE / X-Series X|S 主机电源。
Step 5 按下方向盘 "D-X" 键,连接成功后方向盘绿色指示灯长亮。

STEERING WHEEL ADVANCED SETTINGS / 方向盘高阶设置

Download the [PXN Wheel] APP on your mobile phone to get the advanced settings of the steering wheel.

Main Functions of the APP:

- Steering effective rotation degree setting
- Force feedback setting
- Button mapping setting
- Game preset button configuration
- Steering wheel button test

在手机上下载【PXN 方向盘】APP 可探索方向盘高阶设置。

APP 主要功能说明:

- 方向盘转向有效角度设置
- 方向盘力反馈设置调节
- 方向盘按键映射设置
- 游戏预设键位配置
- 方向盘按键测试

PRECAUTIONS / 注意事项

- Please read the manual carefully before using.
- Avoid strong vibration and gravity drop.
- Do not disassemble, modify or repair by yourself.
- Prevent water or other liquids from getting into the product to avoid damage.
- Avoid storing products in some places with humid, high temperature,oily smoke, etc.
- Please use proper power while connecting and removing devices to avoid damage.
- Children can only use this product under the supervision of an adult.

- 操作前请仔细阅读说明书。
- 避免强烈震动及重力跌落。
- 请勿自行分拆、改装及修理。
- 避免水或其它液体进入产品内部,以免造成损坏。
- 避免存放于潮湿、高温、油烟等场所。
- 连接和移除设备时,注意用力适用。
- 儿童需在成年人的监护下使用本产品。

PRODUCT SPECIFICATIONS / 产品规格

Product Model	PXN - V10 (3in1)	产品型号	PXN - V10 (3in1)
Connection Method	USB Wired	连接方式	USB 有线
Working Voltage	Motor Working Power: DC24 V USB Working Power: 5 V	工作电压	电机工作电源: DC24 V USB工作电源: 5 V
Working Current	Motor Working Current: 2A USB Working Current: ≤ 500mA (while using the original controller for guidance)	工作电流	电机工作电流: 2A USB工作电流: 引导时 ≤ 500mA
Package Size	About 435 * 355 * 370 mm	包装尺寸	约 435 * 355 * 370 mm
Product Size	About 270 * 280 * 249 mm (Steering wheel) About 410 * 340 * 220 mm (3 Foot pedals) About 180 * 105 * 200 mm (Gear shift)	本体尺寸	约 270 * 280 * 249 mm (方向盘) 约 410 * 340 * 220 mm (3 脚踏板) 约 180 * 105 * 200 mm (挂挡杆)
Product Weight	About 2940 g (Steering wheel) About 3180 g (3 Foot pedals) About 577g (Gear shift)	本体重量	约 2940 克 (方向盘) 约 3180 克 (3 脚踏板) 约 577 克 (挂挡杆)
Operating Temperature	10-40 °C	使用温度	10-40 °C
Operating Humidity	20~80 %	使用湿度	20~80 %



扫码下载 APP 及查看教程