

ENGLISH

Secure VESA mount bracket with four screws on rear of monitor.

DEUTSCH

VESA-Montagehalterung mit vier Schrauben an der Rückseite des Monitors befestigen.

FRANÇAIS

Vissez la console de montage VESA avec les quatre vis à l'arrière de l'écran.

ESPAÑOL

Fije el bracket de la montura VESA con cuatro tornillos a la parte trasera del monitor.

ITALIANO

Fissare il supporto VESA con quattro viti alla parte posteriore del monitor.

РУССКИЙ

С помощью четырех винтов закрепите монтажный кронштейн VESA на задней панели монитора.

繁體中文

將VESA背板以四顆螺絲鎖固於螢幕後方。

簡體中文


將VESA背板以四顆螺絲鎖固於屏幕後方。

日本語

VESAマウントブラケットをモニター後部にネジで固定します。

한국어


네 개의 나사를 사용하여 VESA 장착 브라켓을 모니터의 후면에 고정합니다.



SILVERSTONE®
Designing Inspiration

PT15

Premium aluminum case for Intel Haswell NUC motherboards



Compatible with most Intel Haswell-based NUC motherboards
Premium aluminum construction & SilverStone styling
Pre-assembled WIFI antenna and Bluetooth for ease of deployment
Super small design at 130mm x 110mm x 41mm
Includes VESA MISC-75 mounting bracket
Supports DIN rail mounting



ENGLISH

Align and push PT15 into the VESA bracket, then push downward to complete installation.

DEUTSCH

PT15 an der VESA-Halterung ausrichten und drücken, dann zum Abschießen der Installation nach unten drücken.

FRANÇAIS

Alignez et poussez le PT15 dans la console VESA, puis poussez vers le bas pour terminer l'installation.

ESPAÑOL

Alinee y presione la PT15 contra el bracket VESA, luego presione hacia abajo para completar la instalación.

ITALIANO

Allineare e spingere PT15 ne supporto VESA, quindi spingere verso il basso per completare l'installazione.

РУССКИЙ

Выровняйте и установите PT15 в кронштейн VESA, затем нажмите вниз для окончательной установки.

繁體中文

先將PT15對齊VESA背板後推入，再往下扣住背板即可完成安裝。

簡體中文


先將PT15對齊VESA背板後推入，再往下扣住背板即可完成安裝。

日本語

PT15をVESAブラケットに合わせて押さえ、下方向に押しつけて装着は完了です。

한국어

PT15를 VESA 브라켓에 맞춰 정렬하여 밀어 넣은 후 아래로 눌러 설치를 완료합니다.



Warranty Information

This product has a limited 3 year warranty in North America, Europe, and Australia.
For information on warranty periods in other regions, please contact your reseller or SilverStone authorized distributor.

Warranty terms & conditions

- Product component defects or damages resulted from defective production is covered under warranty.
Defects or damages with the following conditions will be fixed or replaced under SilverStone Technology's jurisdiction.
a) Usage in accordance with instructions provided in this manual, with no misuse, overuse, or other inappropriate actions.
b) Damage not caused by natural disaster (thunder, fire, earthquake, flood, salt, wind, insect, animals, etc.)
c) Product is not disassembled, modified, or fixed. Components not disassembled or replaced.
d) Warranty mark/stickers are not removed or broken.
Loss or damages resulted from conditions other than ones listed above are not covered under warranty.
- Under warranty, SilverStone Technology's maximum liability is limited to the current market value for the product (depreciated value, excluding shipping, handling, and other fees). SilverStone Technology is not responsible for other damages or loss associated with the use of product.
- Under warranty, SilverStone Technology is obligated to repair or replace its defective products. Under no circumstances will SilverStone Technology be liable for damages in connection with the sale, purchase, or use including but not limited to loss of data, loss of business, loss of profits, loss of use of the product or incidental or consequential damage whether or not foreseeable and whether or not based on breach of warranty, contract or negligence, even if SilverStone Technology has been advised of the possibility of such damage.
- Warranty covers only the original purchase through authorized SilverStone distributors and resellers and is not transferable to a second hand purchaser.
- You must provide sales receipt or invoice with clear indication of purchase date to determine warranty eligibility.
- If a problem develops during the warranty period, please contact your retailer/reseller/SilverStone authorized distributors or SilverStone <http://www.silverstonetek.com>.
Please note that: (i) You must provide proof of original purchase of the product by a dated itemized receipt; (ii) You shall bear the cost of shipping or other transporting the product to SilverStone authorized distributors; SilverStone authorized distributors will bear the cost of shipping (or otherwise transporting) the product back to you after completing the warranty service; (iii) Before you send the product, you must be issued a Return Merchandise Authorization ("RMA") number from SilverStone. Updated warranty information will be posted on SilverStone's official website. Please visit <http://www.silverstonetek.com> for the latest updates.

Additional info & contacts

For North America (support@silverstonetek.com)
SilverStone Technology in North America may repair or replace defective product with refurbished product that is not new but has been functionally tested. Replacement product will be valid for the warranty period or thirty days, whichever is longer. All products should be sent back to the place of purchase if it is within 30 days of purchase, after 30 days, customers need to initiate RMA procedure with SilverStone Technology in USA by first downloading the "USA RMA form for end-users" form from the below link and follow its instructions.
<http://silverstonetek.com/contact-us.php>

For Australia only


(support@silverstonetek.com)
Our goods come with a guarantee that cannot be excluded under the Australian Consumer Law.
You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage.
You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.
Please refer to above "Warranty terms & conditions" for further warranty details.

SilverStone Technology Co., Ltd. 12F No. 168, Jiansheng Rd., Zhonghe Dist., New Taipei City 235 Taiwan R.O.C. +886-2-8228-1238


(standard international call charges apply)

For Europe (support.eu@silverstonetek.de)


For all other regions (support@silverstonetek.com)



PT15-H1D1



PT15-H1D2



PT15-H1T1



PT15-H2

All trademarks are registered to their respective owners.
© 2014 SilverStone Technology Co., Ltd. All Rights Reserved.

NO.G11221090

1

ENGLISH

Loosen two screws from the front and rear of PT15

DEUTSCH

Zwei Schrauben an der Vorder- und Rückseite des PT15 lösen.

FRANÇAIS

Dévissez les deux vis à l'avant et à l'arrière du PT15.

ESPAÑOL

Aloje dos tornillos de la parte frontal y trasera de la PT15

ITALIANO

Allentare le due viti dal pannello anteriore e posteriore di PT15.

РУССКИЙ

Отверните два винта на передней и задней панели корпуса PT15

繁體中文

將PT15後背板兩顆平頭螺絲卸除。

簡體中文


將PT15后背板兩顆平頭螺絲卸除。

日本語

PT15の前面と後面からネジ2本を外します。

한국어

PT15의 전면과 후면에서 2개의 나사를 뺍니다.



2

ENGLISH

Loosen four screws and foot stands from the bottom of PT15 then pull out the bottom tray.

DEUTSCH

Vier Schrauben und Fußständer von der Unterseite des PT15 lösen, dann unteres Fach herausziehen.

FRANÇAIS

Dévissez les quatre vis et les supports de pieds en dessous du PT15, puis retirez le plateau inférieur.

ESPAÑOL

Aloje cuatro tornillos y soportes de la parte inferior de la PT15, luego tire de la bandeja inferior.

ITALIANO

Allentare le quattro viti ed i piedini dal pannello inferiore di PT15, quindi estrarre il cassetto inferiore.

РУССКИЙ

Отверните четыре винта и стойки с нижней части корпуса PT15 и извлеките нижний лоток.

繁體中文

將底部四顆螺絲與腳墊卸除，並將底板抽出。

簡體中文


將底部四顆螺絲與腳墊卸除，並將底板抽出。

日本語

PT15の底部からネジ4本とフットスタンド4個を外してから、底部トレイを引き出します。

한국어

4개의 나사를 풀어 PT15의 하단에서 바닥 받침대를 제거한 후 하단 트레이를 뽑습니다.



3

ENGLISH

Connect WiFi antenna cable to the WiFi module at this point if the motherboard supports it.

DEUTSCH

An diesem Punkt WLAN-Antennenkabel an WLAN-Modul anschließen, falls das Motherboard dies unterstützt.

FRANÇAIS

Branchez ensuite le câble de l'antenne Wi-Fi sur le module Wi-Fi si la carte mère le prend en charge.

ESPAÑOL

Conecte el cable de antena WiFi al módulo WiFi en este momento si la placa base lo soporta.

ITALIANO

A questo punto, collegare il cavo dell'antenna WiFi al modulo WiFi, se la scheda madre lo supporta.

РУССКИЙ

Подключите кабель антенны WiFi к модулю WiFi, если системная плата поддерживает эту функцию.

繁體中文

若有無線網卡，需先接上天線導線。

簡體中文


若有无线网卡，需先接上天线导线。

日本語

マザーボードがWiFi対応であれば、この時点でWiFiアンテナケーブルをWiFiモジュールに接続します。

한국어

이 때 메인보드에 WiFi 모듈을 지원하는 경우 WiFi 안테나 케이블을 WiFi 모듈에 연결합니다.



4

ENGLISH

Install motherboard onto the bottom tray and secure it with four screws.

DEUTSCH

Motherboard am unteren Fach installieren und mit vier Schrauben befestigen.

FRANÇAIS

Installez la carte mère sur le plateau inférieur, puis fixez-le avec quatre vis.

ESPAÑOL

Instale la placa base en la bandeja inferior y fíjela con cuatro tornillos.

ITALIANO

Installare la scheda madre nel cassetto inferiore e fissarla con quattro viti.

РУССКИЙ

Установите системную плату в нижний лоток и закрепите её четырьмя винтами.

繁體中文

將主板用四顆螺絲鎖在底板上。

簡體中文


將主板用四顆螺絲鎖在底板上。

日本語

マザーボードを底部トレイに取り付け、ネジ4本で固定します。

한국어

메인보드를 하단 트레이에 설치하고 4개의 나사를 사용하여 이를 고정합니다.



5

ENGLISH

Insert the installed bottom tray back into the case.

DEUTSCH

Installiertes unteres Fach wieder in das Gehäuse einsetzen.

FRANÇAIS

Remplacez le plateau inférieur dans le boîtier.

ESPAÑOL

Inserte la bandeja inferior instalada de vuelta en la carcasa.

ITALIANO

Inserire nel telaio il cassetto inferiore con la scheda madre installata.

РУССКИЙ

Установите нижний лоток на место в корпус.

繁體中文

將組裝好的底板滑入機殼內。

簡體中文


將組裝好的底板滑入機殼內。

日本語

取り付けられたマザーボードをケースに戻します。

한국어

설치된 하단 트레이를 케이스에 돌려 끼웁니다.



6

ENGLISH

Secure two screws back to the rear of the case.

DEUTSCH

Zwei Schrauben wieder an der Rückseite des Gehäuses befestigen.

FRANÇAIS

Vissez de nouveau les deux vis à l'arrière du boîtier.

ESPAÑOL

Fije de nuevo dos tornillos en la parte trasera de la carcasa.

ITALIANO

Fissare di nuovo le due viti sul pannello posteriore del telaio.

РУССКИЙ

Заверните два винта на заднюю панель корпуса.

繁體中文

鎖上後面板與兩顆平頭螺絲

簡體中文


鎖上后面板与两颗平头螺絲

日本語

ケースにネジ2本を戻します。

한국어

2개의 나사를 케이스의 후면에 도로 고정합니다.



7

ENGLISH

Secure four screws and foot stands back to the bottom of PT15.

DEUTSCH

Vier Schrauben und Fußständer wieder an der Unterseite des PT15 befestigen.

FRANÇAIS

Vissez les quatre vis et les supports de pieds en dessous du PT15.

ESPAÑOL

Fije cuatro tornillos y los soportes de nuevo en la parte inferior de la PT15.

ITALIANO

Fissare di nuovo le quattro viti ed i piedini sul pannello inferiore di PT15.

РУССКИЙ

Заверните четыре винта и стойки в нижней части корпуса PT15

繁體中文

將四顆螺絲與腳墊裝回PT15

簡體中文


將四顆螺絲與腳墊裝回PT15

日本語

PT15の底部に4個のフットスタンドとネジ4本を戻します。

한국어

4개의 나사를 사용하여 PT15의 하단에 바닥 받침대를 도로 고정합니다.



VESA mount installation procedure

1

ENGLISH

Secure anti-vibration rubber gasket with two screws on the bottom of PT15.

DEUTSCH

Vibrationsfeste Gummidichtung mit zwei Schrauben an der Unterseite des PT15 anbringen.

FRANÇAIS

Vissez la rondelle en caoutchouc anti-vibration avec les deux vis au bas du PT15.

ESPAÑOL

Fije la junta de goma anti vibración con dos tornillos en la parte inferior de la PT15.

ITALIANO

Fissare le guarnizioni di gomma anti-vibrazione con due viti sulla parte inferiore di PT15.

РУССКИЙ

С помощью двух винтов закрепите антивибрационную резиновую прокладку на нижней части корпуса PT15.

繁體中文

將防震膠墊以兩顆螺絲鎖固於PT15底部。

簡體中文

將防震膠墊以兩顆螺絲鎖固於PT15底部。

日本語

PT15底部に防震ゴムパッキングをネジ2本で固定します。

한국어

두 개의 나사를 사용하여 진동 방지 고무 가스켓을 PT15의 하단에 고정합니다.

