
## May in Color



**OUTDOOR MOTOR SUN SHADE** 

INSTRUCTION MANUAL

#### **ASSEMBLY INSTRUCTIONS**

Carefully unpack all the components and verify that all the necessary parts are included as listed in the packaging.

Identify each component and refer to the provided assembly diagram or step-by-step instructions.


Assemble the furniture in the order specified to ensure proper alignment and fit.

Use the provided tools or recommended tools for assembly. Do not use excessive force when tight ening screws or bolts.


If any difficulties arise during assembly, consult the troubleshooting section or contact out customer support.

#### **Tools You May Need**

Screwdriver / Measuring Tape / Pencil / Drill bits (Optional)




#### **PACKAGE CONTENTS**




#### **CEILING MOUNTING**


Step 1 Location the driling holes with a measuring tape or straight ruler, Mark the mounting bracket locations through the holes with a pencil.




Step 2 Use the screws to anchor in the (pencil marked) bracket holes to firmly attach the mounting brackets to the surface.




Step 3 Place the top rail under the brackets and touch the plastic plug to the rail's outer ridge, then press inward and lift upward to complete the mount.




Step 4 Operate the shade.




### Step 5








Step 6




#### WALL MOUNTING

Step 1 Location the driling holes with a measuring tape or straight ruler, Mark the mounting bracket locations through the holes with a pencil.




Step 2 Use the screws to anchor in the (pencil marked) bracket holes to firmly attach the mounting brackets to the surface.




#### Step 3


Place the top rail under the brackets and touch the plastic plug to the rail's outer ridge, then press inward and lift upward to complete the mount.




#### Step 4 Operate the shade.



### Step 5




or allowable position.





Step 6



- Please measure your window or wall before you install the zebra shades, you can use a pencil to mark the right position before you install them.
- If the package or product come damaged, please take photos of them and contact us, we will arrange replacement or other solutions according to the situation.
- If you are satisfied with our product, please leave a review for us, your satisfaction is the best motivation to us.
- To clean your shade fabric, simply rinse with water and soap and scrub with a soft brush. remember to unplug your shade before clean, do not allow the motor to get wet, note: using bleach or an abrasive cleaner will void your warranty.
- Roll the shade down to air dry. your shade should be rolled up during high wind conditions.

## QA

**Q**1

Q: How to wash this roller shade

A: Dust with a dry cloth or wipe with damp cloth.

Q2

Q: What if the product can't work and my return window has closed?

A: We offer you 2 years warranty, if you come across with any problems during your usage, please contact us

Q3

Q: How long will it take to use the roller shade after i install it

A: Normally you can use it immediately once it is assembled, but please check if it is fully assembled, it might fall off if the screws are not tightened

## THANK YOU

#### FOR PURCHASING MAY IN COLOR PRODUCTS







Your satisfaction is the best motivation to us, Please leave us your review to help us improve our product and service



Scan QR cord to review your purchase



Scan QR cord to contact us

If you have any problems, please feel free to contact us

Email address: service@heynemo.com

You get 2 years' warranty for May in Color Roller Shades

# This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and.
- (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarant ee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- —Reorient or relocate the receiving antenna.
- —Increase the separation between the equipment and receiver.
- —Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- —Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environm ent. This transmitter must not be co - located or operating in conjunction with any other antenna or transmitter.