

Power Acoustik CP-71W - Wireless Android Auto Update (June 2024)

WARNING: Before attempting this update, please read these instructions carefully and don't skip any steps, and be sure to use a blank flash drive (FAT32 format) from a reputable brand (SanDisk, Samsung, etc). If the flash drive is not empty, be sure to format it. You can find instructions on how to format a flash drive [HERE](#).


A minimum 16GB USB Type-A flash drive with USB 2.0 or 3.0 is required. Using a flash drive with unknown USB specification will diminish data transfer and can corrupt the system processors. Use reliable name-brand USB flash drives. We use and recommend [SanDisk Cruzer](#), available at Walmart.

Download Update Files (71mb): https://downloads.poweracoustik.com/CP-71W_WirelessAndroidAuto_Update.zip

Video Walk Through: https://www.youtube.com/watch?v=BdTMBzv5_3E

USB Update Instructions

1. **Download** the CP-71W Wireless Android Auto update files and save them to your computer.
2. **Unzip** the CP-71W_WirelessAndroidAuto_Update.zip file to an **empty** USB flash drive.
3. The files you extracted to your USB flash drive should look like this:



Name	Size
ISPB000T.BIN	100.3 MB
update	
st25mcu.bin	115 KB

4. With the radio **powered on**, insert the USB flash drive into the **back** USB port.
5. You may get a “**No data can be played**” message, but ignore and go back to the Home screen.
6. Click on the **Settings** button and scroll down the menu and select **Serial & Version**.

7. Click the **Update** button, and you will see a window with **New Firmware Version** pop up and click **Update** to begin the updating process.
8. Please wait approximately 2 minutes, you will see multiple different screens until you finally see the initial setup screen.
9. Once you complete the quick setup, your CP-71W is now fully updated!
10. You can verify that the update was successful by going to the home screen and seeing if the Android Auto icon has now appeared.