

**USER'S MANUAL**  
**Portable keyboard piano**  
**MU10066**

THIS INSTRUCTION BOOKLET CONTAINS **IMPORTANT** SAFETY INFORMATION. PLEASE READ AND KEEP FOR FUTURE REFERENCE.

**Please give us a chance to make it right and do better!**

Contact our friendly customer service department for help first.

Replacements for missing or damaged parts will be shipped ASAP!

**Follow Costway**



# Contact Us!

## Do NOT return this item.

Contact our friendly customer service department for help first.



# Before You Start

Please read all instructions carefully and keep it for future reference.

### Warning!

**Attention:** The Product is not suitable for the children under 3 years

**Danger:** Keep all small parts and packaging materials for this product away from babies and children, otherwise they may pose a choking hazard.




**WARNING:**  
**CHOKING HAZARD**-Small parts.  
Not for children under 3 years.

### General Warnings:

- △ The product must be installed and used under the supervision of an adult.
- △ Read through each step carefully and follow the proper order.
- △ Remove all packaging, separate and count all parts and hardware.
- △ Please ensure that all parts are correctly installed, incorrect installation can lead to a danger.
- △ We recommend that, where possible, all items are assembled near to the area in which they will be placed in use, to avoid moving the product unnecessarily once assembled.
- △ Ensure a secure surface during construction, and place the product always on a flat, steady and stable surface.

## The following interface function diagram:



## Please charge this piano before using.

### ■ Function buttons

Power, Start/Stop, Demo, Chord, OKON, Metronome, Drum kit, Record, Play, Sustain, Vibrato, Vol+, Vol-, Rhy+, Rhy-, Tone+, Tone-, Tempo+, Tempo-, Transpose+(Press this button 1.5 second, adjusting the knocking force of the keys), Transpose-(Press this button in 1.5 second, Switch on LED teaching function if this piano with)

### ■ Charging Indicator

1. When the piano is plugged into USB for charging, the red light will turn on, and when the battery is full, the light will change color.
2. Battery:High-capacity lithium battery, the charging time is about 4h, please charge for more than 5h for the first time.
3. Charging adapter: 5V 1A

### ■ Protection function

If the lithium battery voltage is too low(Below 3.5V),the product will automatically reset Or can not start. The charging reminder is: While playing the piano or music, it is Automatically stop playing and restore the initial setting state.

### ■ MIC function

Fixed reverb function is added to satisfy user's desire of playing and singing at any time and anywhere.

### ■

Can connect external active speaker or audio power amplifier and headphones, enjoy the double channel sound output. Support three line earphone and external speaker, also support four line headphone with microphone. Suggest using 3.5V stereo headphone plug.

■ **Mp3 function**

Connect to MP3 or other external audio sources, double channel surround sound effect.

■ **SUS:** Sustain pedal, prolong the end time of the keys sound.

■ **MICRO\_USB:** Charging interface and MIDI connection function.

■ **MIDI Function:**

1. Connect the computer with MICRO\_USB data cable, and open the corresponding Software to use the MIDI function.

You can install software with MIDI transmission protocol (such as: Everyone Piano) to use with your computer.

**Controlling external devices via piano**

Play the keyboard, the piano will send the MIDI data to the external device through the USB interface, then you will hear the sound from the BXII and the external device.

**Controlling piano through external devices**

Use USB cable to connect external equipment, Select the piano as the external device & apos's MIDI output method. The piano can be used as an external sound source.

2.Blue tooth APP connection(refer to the last page).

■ **Two built-in quality external speakers:**

The sound field effect of speakers can make the user intoxicated in the wonderful music.

■ **Sound effects:**

Two types of sound are built-in: Sustain/Vibration.

In current mode, press Sustain, Vibration again, can exit current mode and return to normal mode.

■ **Hardware:** Built-in amplifier circuit.

■ **Demo:** 20 Demo songs, press demo button to choose.

| Number | Demo songs              | Number | Demo songs                       |
|--------|-------------------------|--------|----------------------------------|
| 01     | Ode to Joy              | 11     | Milk Song                        |
| 02     | Little Star             | 12     | A comme Amour                    |
| 03     | For Alice               | 13     | Les premiers sourires de Vanessa |
| 04     | Dancing girl            | 14     | Snowdreams                       |
| 05     | My Old Classmate        | 15     | Clean sky                        |
| 06     | a decade                | 16     | Edelweiss                        |
| 07     | Clouds Chasing the Moon | 17     | Dance of fireflie                |
| 08     | Come into my dream      | 18     | My Soul                          |
| 09     | Bandari.Crystal.Lake    | 19     | Ballade pour Adeline             |
| 10     | Green sleeves           | 00     | Laputa Castle in the Sky         |

■ **Chord:**

When playing rhythm, press the chord function and then to press the multi-fingering Method within the range of keys A1-F4#, the corresponding chord accompanying Sound can be heard. If press the single-fingering chord fingering, the chord of Single-finger will be played.

Press chord button again then close chord function.

Table of Single-finger chords (example)

|    | M | m | 7 | m7 |
|----|---|---|---|----|
| C  |   |   |   |    |
| C# |   |   |   |    |
| D  |   |   |   |    |
| D# |   |   |   |    |
| E  |   |   |   |    |
| F  |   |   |   |    |
| F# |   |   |   |    |
| G  |   |   |   |    |
| G# |   |   |   |    |
| A  |   |   |   |    |
| A# |   |   |   |    |
| B  |   |   |   |    |

■ **Transpose+/- :**

It starts at level 0, 0\_ --6 and 0--6

Press Transpose- 1.5 second on/off LED teaching function (If this piano with this function)

Press Transpose+ 1.5 second, on/off the function for adjusting knocking force of the keys.

■ **Vol +/- :** It starts at level 14, largest level is 17, minimum is 0.

■ **Tempo+/- :**

The default speed is 120, the maximum can be adjusted to 300, the minimum can be reduced to 30.

Different DEMO songs show different speeds. The actual speed shall prevail.

■ **Tone+/- :**

Press Tone+ or Tone- to select tone. 128 kinds of tone, please refer to the attachment for details.

■ **Rhy+/- :**

Press Rhy+ or Rhy- to select rhythm. 128 kinds of rhythm, please refer to the attachment for details.

■ **OKON:**

Press the OKON button to enter the teaching mode automatically. Demo song accompaniment play in a continues loop and wait for the user to play. Touch any key to play the main theme of the demo song, Press the OKON button again to select the loop. Press Start/Stop make the demo song accompaniment stops playing.

■ **Metronome:**

Press the Metronome function to make a beat sound, and the metronome will play at the current speed. Press Start/Stop function to trun off the metronome.

■ **Recording Function:**

1. Press this button to enter the recording mode and make the sound of the metronome. At this point, press any key to start recording. The maximum number of recordings is 700. When the recording is full, the metronome sound stops. You cannot continue to record any note. When you are recording, you can play it by pressing the "Play" button at any time. Each time you press this button, the last memory will be cleared and the recording mode will be re-entered.
2. Press the "Play" button for the first time to play the recorded notes , and press the "Play" button for the second time to stop playing.
3. Press the "Play" button to exit the recording mode.
4. If no value has been recorded before, there is no action will occur when you press "Play" button.

■ **Drum Kit :**

Press this button to get the drum's tone on the corresponding keys.

88 keys drum kit corresponding table

|                                                                                       |                                                                                       |                                                                                       |                                                                                       |                                                                                       |                                                                                       |                                                                                       |                                                                                       |
|---------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------|
|    |    |    |    |    |    |    |    |
| A 1                                                                                   | A # 1                                                                                 | B 1                                                                                   | C 2                                                                                   | C # 2                                                                                 | D 2                                                                                   | D # 2                                                                                 | E 2                                                                                   |
|    |    |    |    |    |    |    |    |
| F 2                                                                                   | F # 2                                                                                 | G 2                                                                                   | G # 2                                                                                 | A 2                                                                                   | A # 2                                                                                 | B 2                                                                                   | C 3                                                                                   |
|    |    |    |    |    |    |    |    |
| C # 3                                                                                 | D 3                                                                                   | D # 3                                                                                 | E 3                                                                                   | F 3                                                                                   | F # 3                                                                                 | G 3                                                                                   | G # 3                                                                                 |
|    |    |    |    |    |    |    |    |
| A 3                                                                                   | A # 3                                                                                 | B 3                                                                                   | C 4                                                                                   | C # 4                                                                                 | D 4                                                                                   | D # 4                                                                                 | E 4                                                                                   |
|    |    |    |    |    |    |    |    |
| F 4                                                                                   | F # 4                                                                                 | G 4                                                                                   | G # 4                                                                                 | A 4                                                                                   | A # 4                                                                                 | B 4                                                                                   | C 5                                                                                   |
|    |    |    |    |    |    |    |    |
| C # 5                                                                                 | D 5                                                                                   | D # 5                                                                                 | E 5                                                                                   | F 5                                                                                   | F # 5                                                                                 | G 5                                                                                   | G # 5                                                                                 |
|    |    |    |    |    |    |    |    |
| A 5                                                                                   | A # 5                                                                                 | B 5                                                                                   | C 6                                                                                   | C # 6                                                                                 | D 6                                                                                   | D # 6                                                                                 | E 6                                                                                   |
|  |  |  |  |  |  |  |  |
| F 6                                                                                   | F # 6                                                                                 | G 6                                                                                   | G # 6                                                                                 | A 6                                                                                   | A # 6                                                                                 | B 6                                                                                   | C 7                                                                                   |
|  |  |  |  |  |  |  |  |
| C # 7                                                                                 | D 7                                                                                   | D # 7                                                                                 | E 7                                                                                   | F 7                                                                                   | F # 7                                                                                 | G 7                                                                                   | G # 7                                                                                 |
|  |  |  |  |  |  |  |  |
| A 7                                                                                   | A # 7                                                                                 | B 7                                                                                   | C 8                                                                                   | C # 8                                                                                 | D 8                                                                                   | D # 8                                                                                 | E 8                                                                                   |
|  |  |  |  |  |  |  |  |
| F 8                                                                                   | F # 8                                                                                 | G 8                                                                                   | G # 8                                                                                 | A 8                                                                                   | A # 8                                                                                 | B 8                                                                                   | C 9                                                                                   |

## Bluetooth APP functions:

### iPhone connection:

#### POPiano connection:

1. Search and download POPiano APP from App store of the iPhone.
2. Open the POPiano App after turning on the bluetooth of the iPhone, select any song, and choose to start playing after entering.
3. Click on the upper right of the iPhone screen , and then you can choose: connect to the piano through: BlueTooth – Confirmed, next – confirm to connect to the piano.
4. After confirming bluetooth connection, the icon is displayed as blue check mark .

#### GarageBand connection:

1. Open GarageBand App,
2. Turn on bluetooth on your phone.
3. Open GarageBand App and click the Settings icon in the upper right corner of the screen.
4. Connect the piano's bluetooth through the: Song Settings – Advanced – Bluetooth MIDI Devices.

### Perfect Piano and PianoBar connection:

1. Download the Perfect Piano App and PianoBar.
2. Turn on bluetooth on your phone.
3. First connect the GarageBand App. When them is connect successfully, then open the Perfect Piano App and PianoBar can be used directly.

### Android phone connection:

#### POPiano connection:

1. Search and download POPiano APP from App store of the mobile phone.
2. Turn on the bluetooth function, some phones need to turn on the phone location function.
3. Open the POPiano App to select any song, and choose to start playing after entering.
4. Click on the upper right of the mobile phone screen , and then you can choose: connect to the piano through: BlueTooth – Confirmed, next – confirm to connect to the piano.
5. After confirming bluetooth connection, the icon is displayed as blue check mark .

### ■ Lists of Tone:

|                             |                            |                        |
|-----------------------------|----------------------------|------------------------|
| 0. Piano 1                  | 43. Contrabass             | 86. Lead 7 (fifths)    |
| 1. Piano 2                  | 44. Tremolo Strings        | 87. Lead 8 (bass+lead) |
| 2. Piano 3                  | 45. Pizzicato Strings      | 88. Pad 1 (new age)    |
| 3. Honky–Tonk Piano         | 46. Orchestral Harp        | 89. Pad 2 (warm)       |
| 4. Rhodes Piano             | 47. Timpani                | 90. Pad 3 (polysynth)  |
| 5. Chorused Piano           | 48. String Ensemble 1      | 91. Pad 4 (choir)      |
| 6. Harpsichord              | 49. String Ensemble 2      | 92. Pad 5 (bowed)      |
| 7. Clavinet                 | 50. SynthStrings 1         | 93. Pad 6 (metallic)   |
| 8. Celesta                  | 51. SynthStrings 2         | 94. Pad 7 (halo)       |
| 9. Glockenspiel             | 52. Choir Aahs             | 95. Pad 8 (sweep)      |
| 10. Music Box               | 53. Voice Oohs             | 96. FX 1 (rain)        |
| 11. Vibraphone              | 54. Synth Voice            | 97. FX 2 (soundtrack)  |
| 12. Marimba                 | 55. Orchestra Hit          | 98. FX 3 (crystal)     |
| 13. Xylophone               | 56. Trumpet                | 99. FX 4 (atmosphere)  |
| 14. Tubular Bells           | 57. Trombone               | 100. FX 5 (brightness) |
| 15. Santur                  | 58. Tuba                   | 101. FX 6 (goblins)    |
| 16. Hammond Organ           | 59. Muted Trumpet          | 102. FX 7 (echoes)     |
| 17. Percussive Organ        | 60. French Horn            | 103. FX 8 (sci-fi)     |
| 18. Rock Organ              | 61. Brass Section          | 104. Sitar             |
| 19. Church Organ            | 62. Synth Brass 1          | 105. Banjo             |
| 20. Reed Organ              | 63. Synth Brass 2          | 106. Shamisen          |
| 21. Accordion               | 64. Soprano Sax            | 107. Koto              |
| 22. Harmonica               | 65. Alto Sax               | 108. alimba            |
| 23. Bandoneon               | 66. Tenor Sax              | 109. Bagpipe           |
| 24. Acoustic Guitar (nylon) | 67. Baritone Sax           | 110. Fiddle            |
| 25. Acoustic Guitar (steel) | 68. Oboe                   | 111. Shanai            |
| 26. Electric Guitar (jazz)  | 69. English Horn           | 112. Tinkle Bell       |
| 27. Electric Guitar (clean) | 70. Bassoon                | 113. Agogo             |
| 28. Electric Guitar (muted) | 71. Clarinet               | 114. Steel Drums       |
| 29. Overdriven Guitar       | 72. Piccolo                | 115. Woodblock         |
| 30. Distortion Guitar       | 73. Flute                  | 116. Taiko Drum        |
| 31. Guitar Harmonics        | 74. Recorder               | 117. Melodic Tom       |
| 32. Acoustic Bass           | 75. Pan Flute              | 118. Synth Drum        |
| 33. Electric Bass(finger)   | 76. Bottle Blow            | 119. Reverse Cymbal    |
| 34. Electric Bass(pick)     | 77. Skakuhachi             | 120. Guitar Fret Noise |
| 35. Fretless Bass           | 78. Whistle                | 121. Breath Noise      |
| 36. Slap Bass 1             | 79. Ocarina                | 122. Seashore          |
| 37. Slap Bass 2             | 80. Lead 1 (square)        | 123. Bird Tweet        |
| 38. Synth Bass 1            | 81. Lead 2 (sawtooth)      | 124. Telephone Ring    |
| 39. Synth Bass 2            | 82. Lead 3 (calliope lead) | 125. Helicopter        |
| 40. Violin                  | 83. Lead 4 (chiff lead)    | 126. Applause          |
| 41. Viola                   | 84. Lead 5 (charang)       | 127. Gun shot          |
| 42. Cello                   | 85. Lead 6 (voice)         |                        |

■ Lists of rhythm:

|                      |                     |                       |
|----------------------|---------------------|-----------------------|
| 0. 1beguineswing     | 43. 1rock           | 86. 2R.roll           |
| 1. 2beguin           | 44. 2rock           | 87. 1fastbeat         |
| 2. 3beguine          | 45. 3rock           | 88. 2Quickbeat        |
| 3. 1pophit           | 46. 4Airyrock       | 89. 3smoothbeat       |
| 4. 2pop              | 47. 5heartrock      | 90. 4Squarebeat       |
| 5. 3popmalay         | 48. 6rock&roll      | 91. 5eurobeat         |
| 6. Bossanova         | 49. 7urban          | 92. 1Alphadance       |
| 7. 1disco            | 50. 1ballad         | 93. 2Betadance        |
| 8. 2disco            | 51. 2jazzballad     | 94. 3dreamdance       |
| 9. 3Bluegrassdisco   | 52. 3C.ballad       | 95. 4dance1           |
| 10. 1waltzl          | 53. 4J.ballad       | 96. 5dance2           |
| 11. 2waltzl          | 54. 560Slowballad   | 97. 6dance3           |
| 12. 3Trueballadwaltz | 55. 6pianoBallad    | 98. rap               |
| 13. 4bossawaltz      | 56. 750sballad      | 99. 1thevillage       |
| 14. 5Easywaltz       | 57. Snakebase       | 100. 2countryshuffle  |
| 15. 6shufflewaltz    | 58. 1Happyblues     | 101. 1electrickeys    |
| 16. 7Reggaewaltz     | 59. 2Oldblues       | 102. 2darkkeys        |
| 17. 8Rhumbawaltz     | 60. 3bluegras       | 103. 3Easywalk        |
| 18. 1march           | 61. 1boodie         | 104. 4Destiny         |
| 19. 2march           | 62. 2boodie         | 105. 5Comedy          |
| 20. 1rhumba          | 63. 3boodie         | 106. 6drive           |
| 21. 2rhumba          | 64. 1shuffle        | 107. 7Liquidnova      |
| 22. 1slow            | 65. 2shuffle        | 108. 8KIndustrialfolk |
| 23. 2slow            | 66. 3Dreamshuffle   | 109. 9slowpure        |
| 24. 1discocha        | 67. 4countryshuffle | 110. 10simpleJam      |
| 25. 2guaracha        | 68. 5Quickshuffle   | 111. 11synthethix     |
| 26. 3charl           | 69. 6Reggaeshuffle  | 112. 12feel           |
| 27. 1samba           | 70. 1R&B            | 113. 13Accelerate     |
| 28. 2samba           | 71. 1Reggaepulse    | 114. 14Beachnight     |
| 29. 1ubminimal       | 72. 2Reggae         | 115. 15Irish          |
| 30. 18bit            | 73. 3reggae         | 116. 16Tarantella     |
| 31. 28bit            | 74. 1Salsa          | 117. 17bigband        |
| 32. 116bit1          | 75. 2salsa          | 118. 18dandut         |
| 33. 216bit2          | 76. 3salsa          | 119. 19fusion         |
| 34. 3Ballad16T       | 77. 1tecno          | 120. 20horse2         |
| 35. 4country16T      | 78. 2tecno          | 121. 21keron          |
| 36. 1Tango           | 79. 1funky          | 122. 22latin          |
| 37. 2tango           | 80. 2funky          | 123. 23mambo          |
| 38. 1Polka           | 81. 1dixie          | 124. 24newage         |
| 39. 2polka           | 82. 2dixie          | 125. 25slowrc1        |
| 40. 1popswing        | 83. 1foxtrot        | 126. 26soul           |
| 41. 2Easyswing       | 84. 2foxtrot        | 127. 27twist          |
| 42. 3softswing       | 85. 1R.roll         |                       |

Welcome to visit our website and purchase our quality products!

With your inspiring rating, COSTWAY will be more consistent to offer you  
EASY SHOPPING EXPERIENCE, GOOD PRODUCTS and EFFICIENT SERVICE!

US office: Fontana, California

UK office: Ipswich



- \* Reward Points
- \* Exclusive Customer Service
- \* Personalized Recommendations
- \* Permanent Shopping Cart
- \* Order History

*5 Star Rating*



We would like to extend our heartfelt thanks to  
all of our customers for taking time to assemble  
this product and giving us valuable feedbacks.

THANK  
you  
😊