

LED FLASHLIGHT USER MANUAL

Thank you for using this product. Please read the instructions carefully and follow them strictly for use safely. Please keep the manual properly for future reading.



2 Years Warranty

BATTERY INSTALLATION



- ① Open the back cover of the LED flashlight.
- ② Put the battery into the battery tube.
- ③ Install the flashlights properly with the positive side in and the negative side out.
- ④ Turn to close the back of the flashlight.

PRODUCT SPECIFICATIONS

Lamp beads: white laser

Material: Aluminum

Power supply: rechargeable battery

Lighting modes: 7 light modes

Charging method: USB-C charging

Charging time: 3-5 hours or so

Lighting time: 15 hours or so

Charge voltage/current: 5V/1A

Waterproof: IPX7

Irradiation distance: about 3280 feet

Weight: 224 g/7.90oz(with battery) | 181g/6.38oz(without battery)

Dimension: 170mm*40mm*33mm | 6.69in*1.57in*1.30in

3 MAIN LIGHT MODES

Strong mode: Click the power button once.

Middle mode: Click the power button twice.

Strobe mode: Click the power button thrice.

4 COB LIGHT MODES

Just fast double-press the power button.

COB strong mode: Fast click the power button twice.

COB middle mode: Click the power button twice.

COB red light mode: Click the power button thrice.

COB SOS mode: Click the power button fourth.

In any mode long-press the switch for 2-3 seconds to directly turn it off.

Battery indicator: An indicator light represents 25% battery.

NOTE

- ① When inserting the battery, please make "+" face towards the inside and "-" towards the outside.
- ② Before charging, please make sure that the batter is installed in the correct direction, otherwise, the flashlight will be damaged.
- ③ When not using it for a long time, please take out the battery.
- ④ In order to prevent the problem of not being able to charge in the future, please do not run out of electricity before recharging.
- ⑤ Please do not mix old and new batteries, batteries of different batteries and brands.
- ⑥ The head and tail of the flashlight may be loose in transportation, please tighten the flashlight firstly when you receive it.

IN THE BOX

Led Flashlight*2

Rechargeable Battery*2

USB-C Charging Cable*2

AAA Battery Holder and Battery Tube*2

Lanyard*2

User Manual*1

FAQs

Abnormal situation	Reasons	Solution
The flashlight does not work or cannot be charged	① The positive and negative poles of the battery are reversed ② Battery drained	① How to put the battery: the positive pole faces inward, and the negative pole faces outward ② Please charge the flashlight with a USB cable
Flashlight smoking	Charge the flashlight with the battery's positive and negative poles reversed	① Please ensure that the battery is placed in the correct direction ② Recharge the batteries when they are properly placed
The flashlight is not bright or the brightness is very dim	Low battery	Please charge the flashlight before use
The flashlight will not stay on	Flash mode may be on	Please press the switch again to switch to other modes

WARRANTY SERVICE

- 60-day money-back guarantee for any reason. For 60 days after the date of purchase, return your undamaged product and receive a full refund for ANY reason.
- 24-month warranty for quality-related issues. For 24 months after the date of purchase, we take care of all quality-related issues with a REPLACEMENT or REFUND.
- We are not liable for damages or injuries sustained resulting from the usage of the product inconsistent with the warnings in the manual.