




Birdfy

Birdfy Feeder User Manual

EN

ES



Warning

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications made without explicit approval from the responsible party in compliance may result in the user being unauthorized to operate the device.

This device meets the FCC radiation exposure limits for uncontrolled environments. To ensure safe installation and operation, maintain a minimum distance of 20cm between the radiator and your body.

FCC ID: 2AO8RNI-8102W

CE Statement

The information provided on the packaging is allowed to identify geographical areas within the member states where restrictions on use or requirements for authorized use exist, if applicable. The structure of the product allows it to be used in at least one member state without violating applicable requirements for the use of radio spectrum.

Manufacturer information:

Netvue Technologies Co.,Ltd.

Room A502, Shenzhen International Technology Innovation Academy, 10th Kejinan Road,
Shenzhen Science Park, Nanshan District, Shenzhen, P.R.China, 518000


Catalog

1. What's in the Box	P. 1-2
2. Inserting MicroSD Card	P. 3
3. Camera Charging	P. 4
4. How to Turn on & off the Camera	P. 5
5. Read Before Installing	P. 6
6. AI Bird Identification	P. 7

Catalogar

1. Qué hay en la caja	P. 10-11
2. Cómo insertar una tarjeta MicroSD	P. 12
3. Carga de la cámara	P. 13
4. Cómo encender y apagar la cámara	P. 14
5. Leer antes de instalar	P. 15
6. Identificación de aves mediante IA	P. 16


What's in the Box



Black strap




Roof



Mounting bracket



Perch screw




Perch



Drilling template




Tripod adapter




Feeder & camera



User Manual



Type-C charging cable



Connection cable
for solar panel



Quick Guide



Hose clip



Ejector pin



Screws for mounting
on wood




Screws for mounting
on concrete



Anchors

Inserting MicroSD Card




Birdfy Feeder comes with a built-in card slot which supports Class 10 microSD cards with capacities of up to 128GB.

Step 1: Rotate the camera downwards.

Step 2: Open the silicone cover and insert the microSD card. Make sure it is properly positioned with the label facing upward.

Step 3: Put back the silicone cover.

Camera Charging




The camera does not come fully charged due to safety regulations. Before using it for the first time, please charge it for 14 hours with the charging cable inside the box (DC5V / 1A).

Status light is solid yellow: charging

Status light is solid green: fully charged

How to Turn on & off the Camera



Turn on&off the camera:

Long press the power button at the top of the camera.

Read Before Installing

1. Keep Birdfy Feeder and all accessories out of the reach of children and pets.
2. Make sure the camera is fully charged (DC5V / 1A).
3. Working temperature: -10°C to 50°C (14°F to 122°F)
Working relative humidity: 0-95%
4. Please avoid exposing the camera lens to direct sunlight.
5. The camera has an IP65 waterproof rating, which allows it to function properly in rainy or snowy conditions. However, it should not be submerged in water.

Note:

1. Birdfy Feeder only works with 2.4GHz Wi-Fi.
2. Strong light may interfere with the device's ability to scan QR codes.
3. Avoid placing the device behind furniture or near a microwave oven. Please try to keep it in the range of your Wi-Fi signal.

AI Bird Identification

With AI Bird Identification, you can find out in real-time which bird species are visiting your feeder. A subscription is required to access this feature.




Learn more on my.birdfy.com



Scan the QR code to access
the FAQ for the product.

ESPAÑOL


Qué hay en la caja



Correa negra




Techo



Soporte de montaje



Tornillo de la percha




Percha



Plantilla de perforación




Adaptador de trípode




Feeder y cámara




Manual del usuario



Cable de carga Tipo-C



Cable de conexión
para panel solar



Guía rápida



Clip de manguera



Pasador expulsor



Tornillos para montaje
en madera




Tornillos para montaje
en concreto



Anclajes

Cómo insertar una tarjeta MicroSD




Birdfy Feeder viene con una ranura para tarjeta integrada que admite tarjetas microSD de clase 10 con capacidades de hasta 128 GB.

Paso 1: Gire la cámara hacia abajo.

Paso 2: Abra la tapa de silicona e inserte la tarjeta microSD. Asegúrese de que esté correctamente posicionada con la etiqueta hacia arriba.

Paso 3: Vuelva a colocar la tapa de silicona.

Carga de la cámara




La cámara no viene completamente cargada debido a las regulaciones de seguridad. Antes de usarla por primera vez, cárguela durante 14 horas con el cable de carga dentro de la caja (DC5V / 1A).

La luz de estado es amarilla sólida: cargando

La luz de estado es verde sólida: completamente cargada

Cómo encender y apagar la cámara



Encender y apagar la cámara:

Mantenga pulsado el botón de encendido en la parte superior de la cámara.

Leer antes de instalar

1. Mantenga Birdfy Feeder y todos los accesorios fuera del alcance de niños y mascotas.
2. Asegúrese de que la cámara esté completamente cargada (DC5V / 1A).
3. Temperatura de trabajo: -10°C a 50°C (14°F a 122°F) Humedad relativa de trabajo: 0-95%
4. Por favor, evite exponer la lente de la cámara a la luz solar directa.
5. La cámara tiene una clasificación de impermeabilidad IP65, lo que le permite funcionar adecuadamente en condiciones de lluvia o nieve. Sin embargo, no debe sumergirse en agua.

Nota:

1. Birdfy Feeder solo funciona con Wi-Fi de 2.4 GHz.
2. La luz fuerte puede interferir con la capacidad del dispositivo para escanear códigos QR.
3. Evite colocar el dispositivo detrás de muebles o cerca de un horno de microondas. Por favor, trate de mantenerlo dentro del alcance de su señal Wi-Fi.

Identificación de aves mediante IA

Con la Identificación de Aves con IA, puedes descubrir en tiempo real qué especies de aves están visitando tu comedero. Se requiere una suscripción para acceder a esta función.



Obtenga más información en my.birdfy.com



Escanea el código QR para acceder a las preguntas frecuentes del producto.



Contact us at:



support@birdfy.com



In-App Chat



1(886)749-0567
Mon-Fri, 9am-5pm, PST



@Birdfy by Netvue



@netvuebirdfy

www.birdfy.com
© Netvue Inc.

