


BESTÅ



Design and Quality
IKEA of Sweden



English


WARNING









Children have died from furniture tipover. To reduce the risk of furniture tipover:


- ALWAYS install anti-tip device provided.
- NEVER allow children to stand, climb, or hang on any drawers, doors, or shelves.
- ALWAYS secure your television with an anchor device.

English


Read and follow each step of the instruction carefully.









1




2




3




4







5




6




7




8




9




10




11




12








14




15




16



17





18

