

Installation guide


Pressure switch

KPS 31 – KPS 47




060R9302

060R9302




Danfoss
60-436,10



KPS 43, KPS 45, KPS 47

KPS 31 – 47





Danfoss
60-440,11




Danfoss
60-456,12

Type	T ₁ min. [°C]	T ₂ max. [°C]	T ₂ max. [°C]	T ₂ max. [°C]
KPS 31, KPS 33, KPS 35, KPS 37, KPS 39	-40	-40	70	100
KPS 43, KPS 45, KPS 47	-25	-25		


T₂ max. for water and seawater is 80 °C



Danfoss
60-458,9




Danfoss
60-635,10



Danfoss
60-637,11

Type	P [bar]
KPS 31	6
KPS 33	10
KPS 35	12
KPS 37	27
KPS 39	53
KPS 43	180
KPS 45	180
KPS 47	180



10(6) A, 440 V AC L.R. 50A
220V, 12 W DC PILOT

DANFOSS
A60-459.12

Info for UK customers only: Danfoss Ltd., 22 Wycombe End, HP9 1NB, GB

KPS 33 – KPS 47

Type (code no.)	Diff. [bar]
KPS 33	0.2
KPS 35 (060-310866)	0.4

