

MK

Instructions for using Bluetooth microphones



A: Main functions:
1: 2.4G RF with strong anti-interference ability
2: Adopting a dynamic high fidelity cartridge, the sound is full and clear
3: Automatic connection between power on and audio system, easy to operate
4: Built in lithium battery, fully charged and can last for over 15 hours
5: Effective distance between microphone and sound system 10 meters


Microphone operation instructions

1: Power button
Long press for 2 seconds to turn on/off, short press for one key to cancel the original sound
2: Plus key
Short press to increase reverb volume
3: Minus key
Short press to decrease the reverb volume
4: Microphone key (voice change)
Short press to cycle through sound changes (original sound, child sound, male voice, female voice, strange sound)
Long press to enter volume and reverb adjustment mode, and hear a prompt tone
Short press the "+-" button to adjust the corresponding volume increase or decrease


Instructions for using Bluetooth microphones

5: Microphone parameters

Bluetooth version: V5.3
MIC Specification: Dynamic Mark
Power supply method: built-in 500MAH lithium battery
Usage time: approximately 15 hours
Charging time: approximately 2 hours
Charging voltage: 5V-1A
Product size: diameter 38 * height 133MM



1. Key switch
Long press for 2 seconds to turn on/off, short press to cancel the original sound
2. Volume increase button, short press to increase reverb sound
3. Volume down button, short press to reduce reverb sound
4. Microphone button, short press to switch sound and long press to enter volume and reverb adjustment mode.



5. TYPE-C charging interface

matters needing attention

1. Please store and use this product in a room temperature environment
2. Do not expose this product to rain or damp environments;
3. Do not throw to avoid product damage caused by falling
4. Do not disassemble, repair, or modify this product on your own;
5. The product is equipped with a built-in lithium battery. Please do not dispose of it or place it in a fire to avoid danger

Common problem-solving methods	
phenomenon problem	Solution
Multiple unsuccessful connection pairing	1. Check if the speaker is in search mode or restart it 2. There are too many Bluetooth devices around, making it difficult to search. Turn off other Bluetooth devices.
Low or distorted sound	1. Check the volume of the Bluetooth device and adjust it to the appropriate position. 2. If the battery voltage is low, please charge it.
Music breaks	Is it beyond the effective connection distance of the audio system, or is there an obstacle between the speaker and the Bluetooth device.
Bluetooth status indicator light does not light up	1. Indicates that the battery is low. Please fully charge and try again 2. Reboot