

zrhbrg.

USER MANUAL

AUTOMATIC MOVEMENTS



AUTOMATIC WINDING MOVEMENT

{NO DATE}



1 WEARING POSITION / WINDING POSITION

In this position you can wind your watch. To do this, turn the crown clockwise. {However, it is only necessary to wind the watch manually if you do not wear it for a longer period of time, since the movement winds automatically when you wear the watch and move.


2 TIME SETTING POSITION

Pull gently on the crown until it moves outward with a click.

In this position you set the time of your watch. To do this, turn the crown clockwise until you reach the desired time. Then push the crown back in the wearing position.

AUTOMATIC WINDING MOVEMENT

{DATEJUST, NO QUICK SET}



1 WEARING POSITION / WINDING POSITION

In this position you can wind your watch. To do this, turn the crown clockwise. {However, it is only necessary to wind the watch manually if you do not wear it for a longer period of time, since the movement winds automatically when you wear the watch and move.

2 TIME SETTING POSITION | DATE SETTING POSITION

Pull gently on the crown until it moves outward to the second position with a click.

In this position you set the time and date of your watch. To do this, turn the crown forward until you reach the desired time and date and then push the crown back in the wearing position.

{Please note, to change the date on this watch, you must turn the time 24 hours forward. Never turn the time backwards on this movement to avoid damage.}

AUTOMATIC WINDING MOVEMENT

{DATEJUST, WITH QUICK SET}



1 WEARING POSITION / WINDING POSITION

In this position you can wind your watch. To do this, turn the crown clockwise. {However, it is only necessary to wind the watch manually if you do not wear it for a longer period of time, since the movement winds automatically when you wear the watch and move.

2 DATE SETTING POSITION

Pull gently on the crown until it moves outward to the second position with a click.

In this position you set the date of your watch. To do this, turn the crown forward until you reach the desired time. Then push the crown back in the wearing position.

3 TIME SETTING POSITION

Pull gently on the crown until it moves slightly outward to the third position with a click. In this position you set the time of your watch. To do this, turn the crown forward until you reach the desired time and then push the crown back in the wearing position.

{Never turn the time backwards on this movement to avoid damage.}

AUTOMATIC WINDING MOVEMENT

{DAYDATE, WITH QUICK SET}



1 WEARING POSITION / WINDING POSITION

In this position you can wind your watch. To do this, turn the crown clockwise. {However, it is only necessary to wind the watch manually if you do not wear it for a longer period of time, since the movement winds automatically when you wear the watch and move.

2 DATE SETTING POSITION

Pull gently on the crown until it moves outward to the second position with a click.

In this position you set the date of your watch. To do this, turn the crown forward until you reach the desired time. Then push the crown back in the wearing position.

3 TIME SETTING POSITION / WEEKDAY SETTING POSITION

Pull gently on the crown until it moves slightly outward to the third position with a click. In this position you set the time of your watch. To do this, turn the crown forward until you reach the desired time and then push the crown back in the wearing position.

{Never turn the time backwards on this movement to avoid damage.}

! TIP

First set the correct day of the week, the time and last the date.