

104x210mm

SONAX PRO

LADY SHAVER BEAUTY KIT

Model: SN-6977



2in1 USB CHARGER
PROFESSIONAL HIGH-QUALITY ADVANCED SHAVING SYSTEM
FOR HOME, TRAVEL AND GIFT GIVING

INSTRUCTION MANUAL

Read through this entire instruction manual before using the 2 in 1 shaving foil. we're dedicated to bringing you well-designed products that make living fun and easy. We stand behind all our products and warrant this to be free from defects in workmanship and materials for 1 year from the date of purchase.

NAME OF PARTS

Beard trimmer & body shaver

ON/OFF Switch

Shaver for ladies



How TO USE CHARGING

1. Charging 8 hour
2. Rating Voltage: DC 5V 3W
3. Close power switch. Please insert the plug into the power socket. The indicator with flash on that is charging.

INSTRUCTION FOR HEAD REPLACEMENTS

To change attachments, hold the trimmer body with the switch side facing towards you. Turn off the razor head and pull off. Position the replacement head at the top of the trimmer body, then push down and attach.

(A) Shaver for ladies

You can use this head to trim unwanted hair from face, neck, arms and legs.

(B) Beard trimmer & Body shaver

1. Slide the power switch up to the top of "1" Place to turn on the power.
2. Move the razor head on the skin against the main direction of beard growth and make straight and circuitous movements.
3. In order to achieve best shaving effect, Please get washed after a period of time.
4. Turn off the shaver's power after using it.

CLEANING & MAINTENANCE

Clean your personal trimmer regularly. Be sure switch is turned "OFF" before cleaning.

CLEANING WITH BRUSH

To maintain lubrication, use the enclosed brush to clean the unit. Thoroughly brush and blow out hair clippings from the power handle.


CLEANING WITH WATER

Your trimmer's razor head have rust-resistant, stainless steel cutting blades. The cutting heads can be rinsed under running water. Try to separate the head from the body when cleaning. Always keep blade area pointed downward when cleaning. Only after it has dried completely that can be used.

Do not use harsh or corrosive cleaners on the unit or its accessories.
Do not apply pressure or hard objects to accessories.

HOW TO INSTALL YOUR FACIAL HAIR REMOVER HEAD?

1. The facial hair remover head includes 3 parts.
2. Please make the circled 2 parts connect together.
3. Please make sure it is in the middle and you can rotate it with out issue.
4. Put the head main body on and screw it.



104x210mm

SONAXPRO KIT DE BELLEZA AFEITADORA SEÑORA

Modelo: SN-8977



2in1UsB

SISTEMA DE AFEITADO AUMENTADO DE AGUA CALIENTE PROFESIONAL
PARA EL CUIDADO FACIAL Y CORPORAL TOTAL

MANUAL DE INSTRUCCIONES

Lea este manual de instrucciones completo antes de usar la lámina de afeitar 2 en 1. Estamos dedicados a brindarle productos bien diseñados. Productos que hacen que la vida sea divertida y fácil. Resguardamos todos nuestros productos y garantizamos que no tendrán defectos de fabricación ni de materiales durante 1 año a partir de la fecha de compra.

NOMBRE DE LAS PIEZAS

Barbero &
afeitadora corporal

Interruptor encendido / apagado

afeitadora para damas



CÓMO USAR LA CARGA

1. Cargando 8 horas
2. Voltaje nominal: CC 5 V 3 W.
3. Cierre el interruptor de alimentación. Por favor inserte el enchufe en el toma de corriente. El indicador con flash encendido se está cargando.

INSTRUCCIONES PARA EL REEMPLAZO DE CABEZAS

Para cambiar los accesorios, sostenga el cuerpo de la recortadora con el lado del interruptor hacia usted. Apague el cabezal de afeitar y retírelo. Coloque el cabezal de repuesto en la parte superior del cuerpo de la recortadora, luego empujelo hacia abajo y fíjelo.

(A) Afeitadora para damas

Puedes usar este cabezal para recortar el vello no deseado de cara, cuello, brazos y piernas

(B) Recortadora de barba y afeitadora corporal

1. Deslice el interruptor de encendido hasta la parte superior del lugar "1" para encender la alimentación.
2. Mueva el cabezal de afeitar sobre la piel contra el principal dirección del crecimiento de la barba y hacerla recta y movimientos tortuosos
3. Para lograr el mejor efecto de afeitado, obtenga lavado después de un periodo de tiempo
4. Apague la afeitadora después de usarla.

LIMPIEZA Y MANTENIMIENTO

Limpie su recortadora personal con regularidad. Asegúrese de que el interruptor esté en "OFF" antes de limpiar.

LIMPIEZA CON CEPILLO

Para mantener la lubricación, utilice el cepillo incluido para limpiar la unidad. Cepille bien y elimine los recortes de cabello del mango eléctrico.

LIMPIEZA CON AGUA

El cabezal de afeitar de su recortadora tiene hojas de corte de acero inoxidable resistentes al óxido. Los cabezales de corte se pueden enjuagar con agua corriente. Intente separar la cabeza del cuerpo al limpiar. Mantenga siempre el área de la hoja apuntando hacia abajo al limpiar. Sólo después de que haya muerto por completo se podrá utilizar.

No utilice limpiadores fuertes o corrosivos en la unidad o sus accesorios.
No aplique presión ni objetos duros a los accesorios.

¿CÓMO INSTALAR TU CABEZAL REMOVER VELLO FACIAL?

1. El cabezal removedor de vello facial incluye 3 partes.
2. Haga que las 2 partes en círculo se conecten entre sí.
3. Asegúrese de que esté en el medio y puedas girarlo sin problemas.
4. Coloque el cuerpo principal del cabezal y atorníllelo.

