




The Bluetooth® word mark and logos are owned by the Bluetooth SIG, Inc. All other trademarks and trade names are those of their respective owners.

8004081/82

Portable Bluetooth® Speaker



USER GUIDE

Contents

1. Summary	1
2. Speaker Overview	2
3. Package Contents List	2
4. Pairing	2 - 3
5. Charging the Battery	3
6. Battery Information	4
7. Turning Speaker On/Off	4
8. Streaming	5
9. Troubleshooting	5
10. Safety and General Information	5 - 6
11. FCC and IC Statement	6
12. Specifications	7
Warranty	8

1. Summary

The Headrush™ Portable Bluetooth® Speaker is compliant with Bluetooth V3.0 specifications and can be easily connected wirelessly to any Bluetooth enabled device. Use the built-in mic for hands-free calling. For more details, please read the user guide.

1

2. Speaker Overview

- 1) MFB (Indicator) Multi Function Button
- 2) Microphone
- 3) Charging/Line-in Connector
- 4) Power Switch



3. Package Contents List:

- 1) Headrush Portable Speaker
- 2) User Manual
- 3) Charging Cable

4. Pairing

Before you use this speaker for the first time, you must pair the unit with a Bluetooth® enabled device. Pairing is a one-time process and required for the first connection with the Bluetooth host device. This instruction is based on a Bluetooth enabled phone as the host device. Please refer to the following steps to pair the speaker.

PAIR WITH BLUETOOTH PHONE

- 1) Slide the power switch to ON.
Put the speaker close to a Bluetooth-enabled mobile phone (less than 1 meter).
- 2) Ensure the speaker is turned off.
- 3) Press and hold the MFB for 3 seconds, you will hear a beep and the LED indicator will flash in red and blue, speaker is now ready for pairing.

2

- 4) Activate your mobile phone Bluetooth function by referring to your mobile phone's instruction guide for details, search Bluetooth for devices.
- 5) Select "Headrush 8004081 or 8004082" from the new device list.
- 6) For most Bluetooth devices, there is no need to enter the PIN code, if your device requires a PIN code enter "0000" to complete pairing. When pairing is complete the speaker will connect to your phone automatically.

Important: If pairing is not completed within 2 minutes, the speaker will turn off. If this happens, repeat the pairing process.

5. Charging the Battery

The Headrush™ Portable Bluetooth® Speaker has an internal, non-removable, rechargeable battery. Do not attempt to remove the battery from the device as you may damage the device.

- 1) For first time use, please fully charge the speaker.
- 2) Plug the charger into the electrical outlet and put the micro USB plug into the charging socket of the speaker.
- 3) When the charger is connected, the indicator light should be solid red. Charging the battery fully may take up to 2 hours.
- 4) When the battery is fully charged, the red indicator light turns off and the blue indicator turns on. Once the blue indicator is on, disconnect the charger from the speaker and the wall outlet.
- 5) When the speaker is powered on and battery power is low, speaker will notify you by beeping every 20 seconds. The indicator light will turn red.



Important: When the charger is connected, it can function as an AC power supply for the speaker directly.

3

6. Battery Information

The device is equipped with an integrated lithium-polymer battery. The battery cannot be replaced. Do not attempt to remove the battery from the device. The full performance of a new battery is not achieved until after two or three complete charging-discharging cycles. The battery can be charged and discharged several hundred times, but it loses its capacity over time.

Disconnect the speaker from the power supply as soon as the battery is fully charged, overcharging will reduce the life of the battery.

Important: To avoid a complete discharge of the battery, the speaker should be charged at least every 3 months.

7. Turning Speaker On/Off

TURN ON THE SPEAKER

Slide the power switch to ON, then press and hold the MFB for 3 seconds until you hear a tone from low to high, the blue indicator will flash 2 times, the speaker is now on.

CONNECT TO A BLUETOOTH-ENABLED MOBILE PHONE

If the speaker has completed the pairing operation successfully, when the speaker turns on, it will connect to the phone you last connected automatically. Please ensure your phone's Bluetooth function is activated.

TURN OFF THE SPEAKER

At any time after the speaker is powered on, press and hold MFB for 5 seconds, you will hear a tone, and the red indicator will flash in red, the speaker is now powered off.

Important: If the speaker is not in use turn the power off.

- 1) To conserve power, if the speaker is not connected to a device for 20 minutes, the speaker will turn off automatically.

4

8. Using the Bluetooth® Speaker

STREAMING MUSIC

The Headrush Portable Bluetooth® Speaker supports the A2DP profile that allows for wireless streaming of music from a phone or any other Bluetooth enabled device. The music will pause automatically while a call is dialed out/incoming, and resume when the conversation has ended.

ANSWERING A CALL

When you receive an incoming call, press the MFB to answer the incoming call; you can also answer the call directly from your phone.

REJECT AN INCOMING CALL

When you receive an incoming call, press and hold the Answer button for 2 seconds to reject the incoming call.

ENDING A CALL

While on a call, press the MFB to end the call; you can also end the call directly from your phone.

9. Troubleshooting

If you cannot connect the speaker to the mobile phone or other Bluetooth device, please try the following steps:

- 1) Ensure the speaker is charged fully and it is paired with your mobile phone.
- 2) Ensure the speaker is not connected with any other Bluetooth device.
- 3) Ensure your mobile's Bluetooth feature is activated.
- 4) Ensure the speaker is within a maximum of 10 meters of your mobile and there are no obstructions, such as walls or other electronic devices in between.

5

10. Safety and General Information

- 1) Please read this manual carefully and follow all instructions.
- 2) To avoid any damage or malfunction to the unit do not drop unit from high places.
- 3) Keep unit away from humidity, water and any other liquid. If the unit is exposed to water, moisture, or another liquid directly, then do not operate the speaker in order to avoid risk of electrical shock, explosion, or damage to the unit.
- 4) Do not place or keep the unit near heat sources such as direct sunlight, radiators, stoves or other devices which produce heat. This may cause explosion, degrade performance and/or reduce battery life.
- 5) Do not modify, repair, or disassemble unit. Battery may explode.
- 6) Do not place heavy objects on the unit.
- 7) Use only the supplied and approved charger.
- 8) Replacement or service must be done by qualified service center or manufacturer.

CAUTIONS: ELECTRIC SHOCK HAZARD

The battery pack used in this device may present a risk of fire or chemical burn if mistreated. Do not incinerate or disassemble, battery pack may explode and release toxic materials.

11. FCC & IC Statement

This device complies with RSS-210 of Industry Canada. Operation is subject to the following two conditions:

- (1) this device may not cause interference, and
- (2) this device must accept any interference, including interference that may cause undesired operation of the device.

6

This digital apparatus does not exceed the Class B limits for radio noise emissions from digital apparatus set out in the Radio Interference Regulations of Industry Canada.

Industry Canada-ICES-003 CAUTION

To comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules, this device must only be installed on computer equipment certified to comply with the Class B limits.

This Class B digital apparatus complies with Canadian ICES-003.

12. Specifications

Bluetooth specification	V3.0
Operation frequency	2.402-2.48 GHz
Supported profile	HSP, HFP, A2DP
Operation range	Up to 10 meters
Music playback time	2 hours
Battery type	400 mAh, 3.7 V, Polymer Li-ion battery
Standby time	200 hours
Charge time	2 Hours
Overall dimensions	58*55 mm (Max)
Weight	73 g
SNR	>80 dB
Frequency response range	180 HZ-16 kHz
Rated power	RMS 3 W (THD=10%, f=1 kHz)
External power supply	DC 4.5 - 6.0 V
Operating Temp	-0°C to +50°C
Storage Temp	-10°C to +60°C

7



THE SOURCE WARRANTY

The Source warrants that this product will be free from defects in materials and workmanship for a period of one (1) year from the date of purchase. Within this period, simply take the product and your proof of purchase to any The Source store or dealer and the product will be repaired without charge for parts and labour. The Source reserves the right to charge for transportation. Any product which has been subject to misuse or accidental damage is excluded from this warranty.

This warranty is only applicable to a product purchased through The Source company owned stores and dealers and to a product that is presented for repair in a country where The Source offers the product for sale. While this warranty does not confer any legal rights other than those set out above, you may have additional statutory rights which will vary under the laws of the various countries, states, province and other governmental entities in which The Source operates. This warranty is subject to all statutory rights you may have in the country of purchase.

Imported by:
The Source,
Barrie, Ontario, Canada, L4M 4W5
Manufactured in China

For product support please visit
www.thesource.ca



Limited Warranty

© 2012 The Source.
All Rights Reserved.



8