

键 盘 用 户 手 册 **TOP 75B●**

User Manual Benutzerhandbuch





感谢您购买及使用本产品



为了给您带来更好的使用体验。在使用产品前请仔细阅读本说明书、并请妥善保管、以便日后参观。

产品介绍



包装内容



系统需求

Windows®XP / Vista / 7 / 8 / 10或更高版本

安装步骤

将键盘USB连接线插入电脑的USB接口即可开始使用。

指示灯位置

独立指示灯

BT1	按键E灯	蓝灯慢闪	蓝灯快闪	蓝灯常亮2s熄灭				
BT2	按键R灯	蓝灯慢闪	蓝灯快闪	蓝灯常亮2s熄灭				
BT3	按键T灯	蓝灯慢闪	蓝灯快闪	蓝灯常亮2s熄灭				
2.4G	按键Y灯	绿灯慢闪	绿灯快闪	绿灯常亮2s熄灭				
有线	按键U灯	无	无	红灯常亮2s熄灭				
状态	指示灯位置	指示方式						
低电		红灯慢闪						
充电	空格键键位灯		绿灯常亮					
充满		熄灭						
Caps	Caps按键灯位		白灯常亮					
锁WIN	左WIN键灯位	白灯常亮						

回连

配对

连接成功

TOP 75B 组合键功能



	F1		我的电脑		F6	播放/暂停		I	Insert	
	F2		电子邮件		F7	上一首		М	静音	
Fn+	F3	=	Windows搜索	Fn+	F8	下一首	Fn+	٧	音量减小	
	F4		浏览器主页		Р	Prtsc		>	音量增加	
	F5		多媒体播放器		С	计算器		w	将WASD与 ↑↓←→键对调	

TOP 75B 系统功能 (Windows)



锁Win键
Fn + 左Win


恢复出厂设置	
长按 Fn + ~ 5秒	

TOP 75B 系统功能 (Mac)



F1	降低显示屏亮度		F8	播放/	暂停
F2	增加显示屏亮度		F9	Ħ	
F3	开放任务控制		F10	静音	
F4	呼出Siri		F11	调低電	音量
F7	上一曲		F12	调高音	音量
左 Win	Option	Alt Comm	and	右 Alt	Command

TOP 75B 灯光调节



	\rightarrow		灯光方向向右
	-		灯光速度变慢
	=		灯光速度变快
	L		灯光关闭/开启
Fn+	\	=	切换背光致7种单色+RGB循环
	Z		侧边灯光亮度切换,5档,循环
	Х		侧边灯光速度切换,5档,循环
	左Ctrl		侧边灯光模式切换,包括关闭 共6种
	左Alt		侧边灯光模式,调节灯光颜色致7色单色+RGB循环

TOP 75B 连接使用指南



	Е		蓝牙设备1	Н	
	R		蓝牙设备2		短按回连
Fn+	Т	=	蓝牙设备3		长按配对
	Υ		2.4G无线设备	H	
	U		有线模式		

	上: MAC (内置电源开)
	中: Windows (内置电源关)
开关位于CAPS按键右侧	下: Windows (内置电源开)

蓝牙配对

键盘开机后,按下FN+E/R/T进入蓝牙模式,长按FN+E/R/T组合键3S,键盘进入对码状态,蓝色指示灯快闪,连上后指示灯常亮2S,如果没有连上设备指示灯熄灭,键盘进入睡眠。

2.4G配对

键盘开机后,按下FN+Y进入2.4G模式,再按下FN+Y组合键3S进入配对模式后,插入接收器,指示灯快闪,配对成功后退出对码,模式灯常亮2S,找不到配对设备30s后,退出对码模式灯熄灭,键盘进入睡眠。

电量查询

在无线模式下,按Fn+空格组合键可检查电池电量。如果电池电量低于30%,数字1-2键将显示红灯。如果电池电量低于100%,数字1-9键将显示绿灯,电池电量充满则数字1-0键显示绿灯。



亮红灯 亮绿灯

按键/灯光自定义说明和调用说明

- 1. 键盘三种工作模式下均可连接驱动并进行灯光和按键自定义
- 2. 键盘三种工作模式下可搭配驱动实现音乐律动
- 3. 请在我司官网下载"Akko Cloud"驱动
- 4. 驱动下载地址www.akkogear.com

AKKO保修和服务声明

- Akko为中国大陆的客户提供一年保修。对于其他地区。 请联系您的卖家(Akko分销商)以了解具体的保修政策。
- 2 如果保修期到期,客户需要支付维修费用。如果用户喜欢自己修理键盘。 Akko也会提供说明。用户应对自行修复过程中发生的任何损失承担全部责任。
- 3. 由于私自拆卸产品、使用不当和安装不当而导致的缺陷不在保修范围内。
- 4 官方售后服务时间为每周一至周五十午10:00至下午18:00 节假日以国家法定节日休息为准。
- 5 退货和保修政策在不同的平台上可能有所不同。并在购买时取决于具体的经销商。

公司・深圳银富科技有限公司

地址:深圳市宝安区松岗街道碧头第一工业区朗碧路33号

电话: 0755-23216420

网址: www.akkogear.com

产地:中国•深圳

Company: Shenzhen Yinchen Technology Co., Ltd.

Address: 33 Langbi Rd. Bitou First Industrial Zone, Bao'an District, Shenzhen, China









中国制造 / Made in China



instagram.com/akkogea



tiktok.com/@akkogear



人为损坏不局限于键盘进水、高处坠落、过度用力拉扯线材等、键盘为电子产品 请按照电子产品保护方式爱惜使用。



Packing List





Minimum System Requirement

Windows®XP / Vista / 7 / 8 / 10 or higher version

Connectivity Method

Connect the keyboard to your computer by plugging in the USB cable into an available USB-A port to start using it.

LED Indicator Overview

Status	Indicator	Re-Connecting	Pairing	Connected			
Bluetooth device 1	LED for Key E	Blue light blinks slowly	Blue light blinks fast	Blue light stays on for 2 seconds and then turns off			
Bluetooth device 2	LED for Key R	Blue light blinks slowly	Blue light blinks fast	Blue light stays on for 2 seconds and then turns off			
Bluetooth device 3	LED for Key T	Blue light blinks slowly	Blue light blinks fast	Blue light stays on for 2 seconds and then turns off			
2.4G wireless device	LED for Key Y	Green light blinks slowly	Green light blinks fast	Green light stays on for 2 seconds and then turns off			
Wired	LED for Key U	N/A	Red light stays on for 2 seconds and then turns off				
		Indicating Mode					
Status	Indicator		Indicating Mo	ode			
Status Low Battery			Indicating Mo				
	Indicator Independent LED Indicator						
Low Battery	Independent		Red light blinks slov				
Low Battery Charging	Independent LED Indicator		Red light blinks slov Steady Green				

TOP 75B HotKeys



	F1	My Computer			F6	Pause/Playback		1	Insert
	F2	E-mail			F7	Previous Song		М	Mute
Fn+	F3	Windows Search	F	Fn+	F8	Next Song	Fn+	<	Decrease Volume
	F4	Browser Homepage			Р	Print SCR		^	Increase Volume
	F5	Media		ĺ	С	Calculator		W	Swap W A S D with $\uparrow \downarrow \leftarrow \rightarrow$

TOP 75B System Commands (Windows)



Lock Windows Key

Press Fn and

left Win Key

Restore Factory Settings

Hold down Fn and press ~ Key for 5S


TOP 75B System Commands (Mac)



F1	Decrease display brightness						
F2	Increase display brightness						
F3	Open mission control						
F4	Activate Siri						
F7	Skip back (Audio)						
Left Win	Ontion Left Alt Co						

F8	Pause/Play (Audio)	
F9	Skip forward (Audio)	
F10	Mute	
F11	Volume down	
F12	Volume up	
District Alta Commond		

TOP 75B Backlight Settings



	Home		Effect 1-Effect 5
PgUp			Effect 6-Effect 10
	PgDn		Effect 11-Effect 15
Fn+ End =	=	Effect 16-Effect 20	
	1		Bright
	\downarrow		Dim
			Set animation direction to left

→ Set animation direction			Set animation direction to right
	- Slower Animation = Faster Animation		Slower Animation
			Faster Animation
	L		Light Off/On
Fn+	\	This shortcut allows you to set the backlight color to 7 single color with RGB loop effect Adjust side LED brightness (5 levels)	
	Z		
	X Adjust side LED animation speed (5 levels)		Adjust side LED animation speed (5 levels)
	Left Ctrl		Adjust side LED mode, including Lights OFF (6 levels)
	Left Alt		Side LED mode: This shortcut allows you to set the light to 7 single colors with an RGB loop effect

TOP 75B Connection Guide





	Top: Mac (built-in power supply on)
	Middle: Default Windows (built-in power supply off)
The switch is located under the CAPS key	Bottom: Windows (built-in power supply on)

Bluetooth Pairing

After turning on the keyboard, press FN+E/R/T to enter Bluetooth mode. Press and hold the FN+E/R/T Key combination for 3 seconds to enter pairing mode, with the blue indicator light flashing quickly. Once the connection is established, the indicator light will stay on for 2 seconds. If the device fails to connect, the indicator light will turn off and the keyboard will enter sleep mode.

2.4G Pairing

After turning on the keyboard, press FN+Y to enter 2.4G mode. Then press and hold the FN+Y Key combination for 3 seconds to enter pairing mode. Then insert in the receiver, and the indicator light will flash quickly. Once the pairing is successful, the LED indicator will stay on for 2 seconds. If no available device is found within 30 seconds, the LED indicator will turn off and the keyboard will enter sleep mode.

Battery Level Check

Press the Fn * Space Key combination to check the battery level while in wireless mode. If the battery level is below 30%, the LED for number keys 1-2 will turn red. If it's between 30-100%, the LED for number keys 1-9 will show a green light. And when the battery is fully charged, the LED for number keys 1-0 will show a green light.



Red light Green light

Key/Lighting Effects Customization Instruction

- The keys can be remapped and RGB can be programmed in the driver in any of the connection mode
- 2. Keyboard lighting can be coordinated with the driver to achieve audio visualizer
- 3 Please download the Akko Cloud driver on our website
- 4. Users can download the driver via en.akkogear.com

Akko Warranty and Service Statement

- 1. Akko provides One-Year warranty for customers in mainland China. For other regions, please contact your seller (Akko distributor) for specific warranty policy.
- 2. If the warranty window expires, customers need to pay for repairs, Akko will also provide instructions if users prefer to repair the keyboard by themselves.

However, users shall take full responsibility for any loss happened during self-repair.

- 3. Defects resulting from disassembly of our product, improper usage and incorrect installation are not covered by warranty.
- 4. The return and warranty policy may vary in different platforms and are subject to the specific distributor at the time of purchase.

Company: Shenzhen Yinchen Technology Co., Ltd

Address: 33 Langbi Rd. Bitou Community 1st Industrial Zone, Bao'an District, Shenzhen, China

Tel: 0755-23216420 Website: www.akkogear.com Origin: Shenzhen, China













中国制造 / Made in China













@akkogear





扫描关注官方微博