

SCANPAL™ EDA52 MOBILE COMPUTER

Accessories Guide (6PIN)

Honeywell

TABLE OF CONTENTS

2 CHARGERS

BASIC CHARGERS

NON-BOOTED UNIVERSAL DOCKS

BATTERY CHARGERS

3 MOBILE

MOBILE ACCESSORIES

4 POWER SUPPLY

BATTERY

POWER ADAPTER AND PLUGS

CHARGERS

Basic Chargers



EDA50-HB-R



EDA52-HB-0
EDA52-HB-1
EDA52-HB-2
EDA52-HB-3
EDA52-HB-5



EDA52-CB-0
EDA52-CB-1
EDA52-CB-2
EDA52-CB-3
EDA52-CB-5

Single Charging Dock

Charging dock for ScanPal™ EDA50/EDA50HC/EDA51, EDA52/EDA52HC charging needs to be worked with EDA52-ADC. Compatible with EDA51 scan handle. Does not include charging cable; cable (CBL-500-120-S00) and power adapter and plugs (50130570-001) must be ordered separately.

Single Charging Home Base

Single charging home base for ScanPal EDA52 terminal and battery. Kit contains power supply and power cord. (-0 no power cord, -1 for U.S., -2 for Europe, -3 for UK, and -5 for AU). Compatible with EDA52 scan handle.

Quad Bay Charging Base

Quad bay charging base for ScanPal EDA52/EDA52HC (-0 no power cord, -1 for U.S., -2 for Europe, -3 for UK, and -5 for AU). Kit contains power supply and power cord. Compatible with EDA52 scan handle.

Non-Booted Universal Docks (for 6-pin models only)



EDA52-NB-UVN-0
EDA52-NB-UVN-2



EDA52-EB-UN-0
EDA52-EB-UN-2



EDA52-DB-UVN-0
EDA52-DB-UVN-2

EDA52 Non-booted Net Base

EDA52 non-booted net base for Ethernet communications and recharging up to four computers. Kit includes net base and power cord (-0 no power cord, -2 for Europe).

EDA52 Non-booted Ethernet Base

EDA52 Non-booted
Ethernet base for recharging one computer and one battery, Ethernet communications. Kit includes Ethernet home base and power cord (-0 no power cord, -2 for Europe)

EDA52 Non-booted Display Dock

EDA52 non-booted display dock for recharging one computer, connection with an external display, extending I/O for HDMI, Ethernet communications. Kit includes display base and power cord (-0 no power cord, -2 for Europe).

Battery Chargers



EDA52-QBC-1
EDA52-QBC-2
EDA52-QBC-3
EDA52-QBC-5

Quad Battery Charger

Quad battery charger for ScanPal EDA52/52HC batteries (-1 for U.S., -2 for Europe, -3 for UK, and -5 for AU). Kit contains power supply and power cord.

MOBILE

Mobile Accessories



EDA52-WS-10PK

Wrist Strap

Wrist strap for ScanPal EDA52 (10pcs/kit).



EDA52-HS-10PK

Hand Strap

Hand strap for ScanPal EDA52 (10pcs/kit).



EDA52-SP-10PK

Screen Film

Screen film for ScanPal EDA52 (10pcs/kit).



EDA52-RB-0

Rubber Boot

Rubber boot for ScanPal EDA52.



EDA52-SH-R

Scan Handle

Scan handle for ScanPal EDA52.
Compatible with EDA52 hand strap.



EDA52-ADC

Backwards Adapter Cup

EDA52 backwards adapter to work
with EDA50-HB-R accessories.



EDA52-SN-USB-0

USB Cup (6-pin models only)

EDA52 snap-on USB cup for standard USB port.



EDA52-UCP-N

Universal Cup (6-pin models only)

EDA52 Universal Cup to be worked
with CT40 series universal docks.



IH25-BR-5

RFID Brackets

IH25 bracket for ScanPal EDA52
terminal without rubber boot.

POWER SUPPLY

Battery



50172021-001

Standard Battery Pack

Standard battery pack for ScanPal EDA52 (Li-ion, 3.8 V, 4500 mAh) (included with each terminal).

Power Adapter and Plugs



50136024-001

Power Adapter and Plugs

KIT, 5V/2A Power supply, Scanpal EDA 50k/51/52/60/61K/70/71. Mobility Edge CT40 / CT60. Includes 5 PLUGS
PACKED US, UK, AU, EU, IN adapters.

For more information

sps.honeywell.com

**Honeywell Safety and
Productivity Solutions**

855 S Mint Street,
Charlotte, NC 28202
800-582-4263
www.honeywell.com

ScanPal EDA52 (6PIN) Accessories Guide | Rev C | 05/22
© 2022 Honeywell International Inc.

Honeywell