





Dell Premier Rechargeable Wireless Mouse MS7421W


Quick Start Guide




1



3




4




2

1




2




2



1





2




3




①





③




①



②




Type C



Type



<https://www.dell.com/support/drivers>






Dell Peripheral Manager

<https://www.dell.com/support>

https://www.dell.com/regulatory_compliance



①



Raheen Business Park, Limerick Ireland
www.dell.com/regulatory_compliance
For UK only: Cain Road, Bracknell, RG12 1L

②

