





Dell Premier Rechargeable Wireless Mouse MS7421W

Quick Start Guide




1




2

1




2




2*


1




2




3




4



3




3




3✂

1

2





3




1

2




<https://www.dell.com/support/drivers>



<https://www.dell.com/support>
https://www.dell.com/regulatory_compliance



1



2

