

HONITURE

型号: S13

Type: 操作指南

工艺材质: 350g单粉裱K9, 过哑膜 尺寸: 145*210mm, 正反面印刷

设计: Ada

颜色: 4C印刷

备注:

日期: 2022/10/24

S13 CORDELESS VACUUM CLEANER QUICK START GUIDE




Email to Honiture Official Customer Service:

support01@honiture.com


We are always here to help you for any questions.



1. Installing Desired Cleaning Accessory




2. Start & Adjustment




- Boot into “” Mode
- Touch the “” Key Set to “” Mode
- Touch the “” Key Again Switch to “” Mode

S13 CORDELESS VACUUM CLEANER QUICK START GUIDE


3. Emptying and Cleaning the Dust Cup



4. Cleaning Rolling Brush



5. Charge and Store



Blue light flashing (Charging)
Blue light (Fully Charged)