



1

FR - CHARGER


EN - CHARGE

DE - AUFLADEN


NL - OPLADEN

ES - CARGAR


IT - CARICARE




EARPHONES



CASE



LED STATUS



ON

OFF

PAIRING

CONNECTED

DISCONNECTED

BATTERY 5%



2

FR - JUMELER


EN - PAIR

DE - PAAREN

NL - KOPPELEN

ES - SINCRONIZAR

IT - ACCOPPIARE



3

FR - POSITIONNER


EN - POSITION

DE - STELLEN

NL - POSITIONEREN

ES - POSICIONAR

IT - POSIZIONARE



4

FR - UTILISER

EN - HOW TO USE


DE - VERWENDEN

NL - GEBRUIKEN




ES - UTILIZAR

IT - USARE

CONTROLS



- TOUCH ZONE
- TOUCH 1x
- TOUCH 2x
- TOUCH 3x
- TOUCH 2s
- TOUCH 3s
- TOUCH 5s
- TOUCH 10s



5

FR - ATTENTION

EN - WARNING

DE - WARNUNG

NL - WAARSCHUWING

ES - ADVERTENCIA

IT - AVERTENZA

FR. Écouter de la musique avec un volume élevé peut gravement nuire à l'audition.


EN. Listening at high volume levels for long periods can lead to permanent hearing defects.

DE. Das Hören mit Kopfhörern bei sehr hohen Lautstärken, vor allem über längere Zeit, kann Gehörschäden verursachen.

NL. Het langdurig luisteren naar muziek op hoog volume kan schade aan het gehoor veroorzaken.

ES. Un volumen excesivo durante un periodo prolongado de tiempo puede causar años auditivos permanentes.

IT. L'esposizione prolungata a un volume elevato può provocare danni permanenti all'udito.



6

FR - ANC / TRANSPARENCY / NORMAL


EN - ANC / TRANSPARENCY / NORMAL

DE - ANC / TRANSPARENZ / NORMAL

NL - ANC / TRANSPARENCY / NORMAAL

ES - ANC / TRANSPARENCIA / NORMAL

IT - ANC / TRASPARENZA / NORMALE



7

FR - RÉINITIALISER

EN - RESET

DE - ZURÜCKSETZEN

NL - RESETTEN

ES - REINICIAR


IT - RESET

1




SUPPRIMER
DELETE
BESEITIGEN
VERWIJDEREN
SUPPRIMIR
RIMUOVERE

2




DÉSACTIVER
DISABLE
DEAKTIVIEREN
UITSCHAKELLEN
DESACTIVAR
DISATTIVARE

3




10s = 1sec

4



3s = 2sec

5



FERMER
CLOSE
SCHLIEßEN
SLUITEN
CERRAR
CHIUDERE