



MB01

Stroller

GB Instruction Manual

ES Manual de instrucciones



IMPORTANT, RETAIN FOR FUTURE REFERENCE: READ CAREFULLY

Welcome to the family


Your trust in our product means the world to us, and we're thrilled to be a part of your parenting journey. Our team has worked tirelessly to ensure that the MB01 provides comfort, safety, and style for you and your little one. We're confident it will exceed your expectations. Should you have any questions or require assistance in the future, please don't hesitate to reach out. Thank you for choosing My Babiie; we wish you and your family countless wonderful journeys ahead.

Get to know your MB01 Stroller

Scan the QR code below on your camera app to be linked off to our page to get all the information you need for using your pushchair. From setting it up to how to fold it down, it's all there!



SCAN ME



Warranty

We provide a 1 year warranty against manufacturing or material defects.

The warranty period is effective from the day of purchase and applicable to the UK and Ireland. If you made your purchase from an authorised retailer, please return your product to them.

If you bought your product via our website; mybabiie.com, please contact our Customer Service team via email (info@mybabiie.com). We are happy to refund any product if you change your mind about your purchase (if purchased from our website, mybabiie.com.) As long as you tell us within 30 days of receiving your goods. They must be returned in an unused condition, in the original, undamaged packaging and complete with all original parts and accessories. Proof of purchase is required.

What is not covered by the Guarantee?

- Failure to follow My Babiie user guide and maintenance instructions.
- Damage caused by non domestic use
- General wear and tear, for example: worn wheels, damaged rain covers, worn/torn fabric.
- Deliberate damage, misuse or neglect.
- Product which has been modified, undergone an unauthorised repair or used a non approved spare part.
- Cosmetic damage.
- Parts subject to normal wear and tear, foam handles, rubber elements of wheels, signs of fabric wear.
- Loss incurred as a result of not being able to use a product whilst waiting for a spare part or repair.

A repair service is available for any item that sustains accidental damage at any point during its lifespan. If the damages are not covered by our guarantee, we will provide a quote for the repair costs on an individual basis. If you find yourself in need of spare parts that are not covered by the warranty, you can purchase each spare part on our website (subject to availability).

To read more about your guarantee, please visit mybabiie.com/guarantee.

Our guarantee is provided by My Babiie Retail Ltd, Registered address: Suite 188, Stockiie Business Centre, Unit A, St. James Business Park, Henwood Ind. Estate, Ashford TN24 8DH
Your statutory rights are not affected by the guarantee.

Registering your Warranty

To register your warranty please visit www.mybabiie.com/warranties

Registering for your product warranty allows you to claim repairs or replacements if your product develops a fault. It will also help us contact you in the event of a product issue that you may need to be made aware of.

Problems or Questions

If you have any questions about your product then please drop us an email at info@mybabiie.com and we will get back to to you as soon as possible. Alternatively, you can chat to us on our Live Support Chat on our website mybabiie.com or contact us via our social media channels.

Pushchair warnings

IMPORTANT, RETAIN FOR FUTURE REFERENCE: READ CAREFULLY

Please read these instructions carefully before use and keep them for later reference.

Remove all packaging and non-permanent labels and dispose of safely before using this product. The safety of your child could be put at risk if you do not follow these instructions.

This stroller is designed for 1 child from 0 months up to a weight of 15 kg.

WARNING: Never leave your child unattended.

WARNING: Uneven or excessive loading of items on or in the stroller may cause the product to tip and may cause injury.

WARNING: Maximum intended weight within the shopping basket is 3kg.

WARNING: Ensure that all the locking devices are engaged before use.

WARNING: To avoid injury ensure that your child is kept away when unfolding and folding this stroller.

WARNING: Do not let your child play with this stroller.

WARNING: Always use the restraint system.

WARNING: Check that the pram body or seat attachment devices are correctly engaged before use.

WARNING: Do not put hot drinks or liquids in the cup holder.

WARNING: This product is not suitable for running or skating.

WARNING: Do not insert any additional mattresses into the stroller.

WARNING: Accessories which are not approved by the manufacturer shall not be used.

WARNING: This pushchair has been designed for one child and shall be used for the transport for only one child!

WARNING: Always use the crotch strap in combination with the waist belt.

WARNING: This stroller does not replace a cot or a bed. Should your child need to sleep, then it should be placed in a suitable cot or bed.

WARNING: Only replacement parts supplied or recommended by My Babiie shall be used.

WARNING: Any load attached to the handle and on the back of the backrest and on the sides of the stroller will affect the stability of the stroller.

WARNING: The parking device shall be engaged when placing and removing the children.


EN1888-1:2018+A1:2022

Parts


Frame & front wheels



Canopy





Rear wheel set



Open the pushchair

Unhook the side fold lock and pull open the stroller from the handles. Once partially open, press down the pedal on the back with your foot to lock out the stroller in its fully open state. You will hear a click when it's fully opened up.



Attach the front wheels

1


Push on each of the two front wheels until they click securely in place.



Using the brake

1


Step down the pedal to engage the brake. Lift the pedal to release the brake.



Front swivel wheels

1


Lift the level on the front wheel housing to lock the wheels into the forward facing position. Push the lever down to release them to full swivel.



Canopy

1 **Attach canopy**


Click the canopy onto the stroller frame on each side.



2 **Adjust canopy**


To retract the canopy, lift the hinge on either side of the canopy and pull the hood back.

To extend the canopy, push the canopy forward and then push the hinge down to lock the canopy into place.




Seat recline

- 1** Pull the lever on the back of the seat to lower the position of the seat.




- 2** To raise the seat position, simply push the seat up to raise the recline position.



Leg rest adjustment

1

Pull the levers on either side of the leg rest (1) to move the leg rest to the desired position.




Safety harness

1

Harness

Attach the side belts to both vertical straps, and push these to the centre buckle until you hear a **CLICK** (a). The safety harness can be adjusted to fit the comfort of your child.


To release the seat belt, press the center button (b).



Folding the stroller

1


To retract the canopy, lift the hinge on either side of the canopy and pull the hood back.



2


Lift the lever at the back of the stroller with your foot (1) then push down on the side lever (2).

Push the stroller forward from the handles.



3

Once fully folded, use the latch on the side of the stroller to hold it shut.



Warning

- 1 Ensure the brake is engaged before putting the child in or out of the stroller.



Care and maintenance

- Please check on a regular basis that the brakes, wheels, latches, connecting elements, belt systems and seams are properly functional.
- Do not expose the stroller to strong sunshine.
- Sponge clean only.
- After use in rain or snow, the wheels should be lubricated and the stroller dried to prevent rust.
- Care for, clean and check this stroller regularly.
- Do not use accessories that have not been approved by the manufacturer.

Your child's safety is your responsibility

If you have a problem with this product or require replacement parts, please visit www.mybabiie.com/support


Register your product at: www.mybabiie.com/warranties

Pushchair Do's & Don'ts



Do use your brakes!

Ensure the parking brake is engaged during the loading and unloading of children & when the pushchair is stationary.



Do always use the restraint system!

Ensure that the child restraint system is correctly fitted at all times.



Do keep your pushchair clean and dirt free.

Use a clean white cloth, warm water and a mild detergent to keep your pushchair clean.



Do always keep two hands on the handles when pushing.

You could lose control of your pushchair if not steering with both hands.



Do follow manufacturers instructions when assembling and using your pushchair.

For safety, please refer to our instruction manuals or contact customer support if you're unsure.



Don't use your pushchair up and down stairs!

Don't use your pushchair up or down stairs or to bump kerbs.



Don't hang bags off the handles!

Bags and other items should not be hung from the handles as this can affect the stability of the pushchair.



Don't run or skate with your pushchair!

Our products are not suitable for running or skating.



Don't carry the stroller with baby inside!

Our pushchairs are not designed to be carried with your baby inside them.



Don't put hot drinks in the cup holder.

Hot drinks burn and can easily spill from the bottle holder.



Don't jetwash your pushchair.

Some jet washers are very powerful and could damage parts of your pushchair!



Don't leave your child un-attended in their pushchair.

Always keep your child and pushchair in view to avoid accidents.



Don't treat your pushchair like a trolley.

Don't load your pushchair up with all your shopping as they are not built for this purpose and could cause damage.



Don't use your pushchair as a bumper cart!

Damage can easily occur if your pushchair is knocked into other things.



Don't smoke around your pushchair.

We wouldn't want your pushchair or little one getting hurt or damaged!



Don't leave your pushchair unattended on extreme gradients.

Even with your brakes on your pushchair is at risk from tipping or sliding on extreme gradients!



Don't sit in the pushchair unless the user is under the guideline weight.

Our pushchairs are designed to hold a maximum weight. If exceeded this will cause damage!



Do enjoy your My Babiie product!

Go out and have fun adventures with your little one!

Notas de seguridad y cuidado

IMPORTANTE - LEA CUIDADOSAMENTE Y GUARDE ESTAS INSTRUCCIONES PARA FUTURAS CONSULTAS

Retire todo el embalaje y las etiquetas no permanentes y deséchelos de manera segura antes de usar este producto. La seguridad de su hijo podría correr peligro si no sigue estas instrucciones. Este cochecito está diseñado para 1 niño desde 0 meses hasta un peso de 15 kg.

ADVERTENCIA: Nunca deje al niño desatendido.

ADVERTENCIA: La carga desigual o excesiva de artículos sobre o dentro de la carriola puede hacer que el producto se vuelque y cause lesiones.

ADVERTENCIA: El peso máximo previsto dentro de la cesta de la compra es de 3 kg.

ADVERTENCIA: Asegúrese de que todos los dispositivos de bloqueo estén activados antes de su uso.

ADVERTENCIA: Para evitar lesiones, asegúrese de que el niño se mantenga alejado al desplegar y plegar este cochecito.

ADVERTENCIA: No permita que el niño juegue con este producto.

ADVERTENCIA: Utilice siempre el sistema de retención.

ADVERTENCIA: Verifique que el cuerpo del cochecito esté correctamente acoplado antes de su uso.

ADVERTENCIA: No coloque bebidas o líquidos calientes en el portavasos.

ADVERTENCIA: Este producto no es apto para correr o patinar.

ADVERTENCIA: No inserte colchones adicionales en la carriola.

ADVERTENCIA: No se deben utilizar accesorios que no estén aprobados por el fabricante.

ADVERTENCIA: ¡Este cochecito ha sido diseñado para un niño y debe usarse para el transporte de un solo niño!

ADVERTENCIA: Utilice siempre la correa de la entrepierna en combinación con el cinturón.

ADVERTENCIA: Este cochecito no reemplaza una cuna o una cama. Si su hijo necesita dormir, debe colocarlo en una cuna o cama adecuada.

ADVERTENCIA: Solo se deben utilizar piezas de repuesto suministradas o recomendadas por My Babiie.

ADVERTENCIA: Cualquier carga adherida a la manija y en la parte posterior del respaldo y en los costados de la carriola afectará la estabilidad de la carriola.

ADVERTENCIA: El dispositivo de estacionamiento debe estar activado al colocar y retirar a los niños.

EN1888-1:2018+A1:2022

Cuidado y mantenimiento

- Compruebe periódicamente que los frenos, las ruedas, los pestillos, los elementos de conexión, el cinturón
los sistemas y las costuras funcionan correctamente.
- No exponga el cochecito a la luz solar intensa.
- Solo limpie con esponja.
- Después de su uso bajo la lluvia o la nieve, se deben lubricar las ruedas y secar la carriola para evitar la oxidación.
- Cuide, limpie y revise este cochecito regularmente.

La seguridad de tu hijo es tu responsabilidad

Si tiene un problema con este producto o necesita piezas de repuesto, visite www.mybabiie.com/support


Registre su producto en: www.mybabiie.com/warranties

Piezas de cochecitos


Bastidor y ruedas delanteras



Pabellón





Juego de ruedas traseras



Abra el cochecito

Desenganche el cierre lateral y abra la carriola por las asas. Una vez parcialmente abierta, presione el pedal trasero con el pie para bloquear la carriola en su posición completamente abierta. Oirá un clic cuando esté completamente abierta.



Coloque las ruedas delanteras

1


Empuje cada una de las dos ruedas delanteras hasta que encajen firmemente en su lugar.



Usando el freno

1


Pise el pedal para frenar.
Levante el pedal para soltar el freno.



Ruedas delanteras giratorias

1


Levante la palanca del alojamiento de la rueda delantera para bloquear las ruedas en la posición orientada hacia adelante. Baje la palanca para liberarlas y que giren completamente.



Pabellón

1 Coloque el dosel


Coloque el toldo en el marco del cochecito a cada lado.



2 Ajustar el dosel


Para retraer la capota, levante la bisagra a cada lado y tire de la capota hacia atrás.

Para extender la capota, empújela hacia adelante y luego baje la bisagra para bloquearla.




Reclinación del asiento

- 1** Tire de la palanca situada en la parte posterior del asiento para bajar la posición del asiento.




- 2** Para elevar la posición del asiento, simplemente empújelo hacia arriba para elevar la posición reclinada.



Ajuste del reposapiernas

1

Tire de las palancas a cada lado del reposapiernas (1) para moverlo a la posición deseada.




Arnés de seguridad

1

Arnés

Enganche los cinturones laterales a ambas correas verticales y presiónelos hasta la hebilla central hasta que oiga un clic (a). El arnés de seguridad se puede ajustar para la comodidad de su hijo.


Para soltar el cinturón de seguridad, presione el botón central (b).



Plegado del cochecito

1


Para retraer la capota, levante la bisagra a cada lado y tire de la capota hacia atrás.



2


Levante la palanca trasera del cochecito con el pie (1) y luego presione la palanca lateral (2).

Empuje el cochecito hacia adelante desde las asas.



3

Una vez que esté completamente plegado, use el pestillo en el costado del cochecito para mantenerlo cerrado.



Advertencia

- 1 Asegúrese de que el freno esté puesto antes de colocar o sacar al niño del cochecito.




Care and maintenance

- Compruebe periódicamente el correcto funcionamiento de los frenos, las ruedas, los cierres, los elementos de conexión, los cinturones y las costuras.
- No exponga la carriola a la luz solar directa.
- Límpiela únicamente con una esponja.
- Después de usarla bajo la lluvia o la nieve, lubrique las ruedas y seque la carriola para evitar la oxidación.
- Cuide, limpie y revise esta carriola periódicamente.
- No utilice accesorios no aprobados por el fabricante.

La seguridad de su hijo es su responsabilidad.

Si tiene algún problema con este producto o necesita piezas de repuesto, visite www.mybabiie.com/support

Registre su producto en: www.mybabiie.com/warranties



Register your product



www.mybabiie.com/warranties



www.mybabiie.com/registro

In the first instance of needing assistance please
contact your original place of purchase.

This product qualifies for 12 month warranty
when registered through our website

mybabiie.com



My Babiie



@MyBabiieOfficial



My Babiie



@mybabiie_official