















ELECTRONIC DRUM KIT SERIES

DD500 / DD500BL / DD520

SET-UP GUIDE

CONTENTS CHECKLIST


1  X4	2  X2 400MM	3  X1 550MM
4  X1 350MM	5  X2 700MM	6  X2 785MM
A  (DD520 ONLY) X1	B  X4 for DD520 X3	C  X1
D  X3 for DD520 X2	E  X2	F  X7
G  X2	H  X1	J  X4 for DD520 X3

STEP 1


1.




2.




3.




4.







5.



6.






STEP 2

1.




(DD520 ONLY)

2.




(DD520 ONLY)


3.




4.





5.




6.






STEP 3

1.




2.




3.




4.




5.




6.







7.




8.





STEP 4






5.





STEP 5






STEP 6




STEP 7


1.





2.




3.




STEP 8




Sound Module



Hi-Hat Pedal
Kick



Tom1
Tom 2
Tom 3
Snare



Hi-Hat
Crash 1
Crash 2
Ride

KETTLESTRING LANE | YORK | YO30 4XF | UNITED KINGDOM
METALLVÄGEN 45A | 195 72 ROSERSBERG | STOCKHOLM | SVERIGE
LAHNSTRASSE 27 | 45478 MÜLHEIM AN DER RUHR | DEUTSCHLAND

If you have any more questions about this product, please do not hesitate to contact the Gear4music Customer Service Team on: **+44 (0) 330 365 4444** or **info@gear4music.com**