

anko

Instruction manual

43033027

Phone stand 360 degree

User instructions

•Switch horizontally and vertically

Loosen the phone holder and rotate it to horizontal or vertical mode, then install the phone.



•How to use

Long press: power on/off

Short press: pause/start rotation

1.Download APP

Go to APP store or Google Play, search: "Live 360 Assistant"  to download.




Note: Please refer to the latest version of the APP; if there is any update.

2.Connect the device

- Unscrew the bottom cover of the phone stand and insert the 3X1.5V AA batteries.
- Long press the phone stand until the indicator light is on.
- Open the phone holder and slide the phone into the phone holder according to the front direction of the phone lens to make the phone modulate properly.

- Turn on the Bluetooth of the mobile phone and open the Live360 APP without manual Bluetooth pairing. Follow the prompts to select the camera to broadcast, choose a live broadcast platform, approve the privacy notice.



- Short press the switch on the phone stand into the background to run, it will stop until the face is visible on the camera Range, the device will be in the following state at this time, and the phone and device will follow the position of the face.

•Shooting tips

- 1.The phone stand effect may be affected by the shooting environment. Please select a shooting environment with suitable light and keep a moderate distance from the phone stand.
- 2.The moving speed of the tracking target is too fast, or the target may be lost. In this situation, the gimbal will continue to rotate to retrieve the tracking target, such as if you want the phone stand to stop rotating, you can short press the switch button to pause the rotation.
- 3.Do not hold the phone clip to stop the gimbal from rotating, so as not to damage the motor and affect the service life of the gimbal.

Phone clip

Mechanical angle:
360° horizontal rotation.
Product Size: 100x100x170mm
Support phone size: 56-100mm
Power supply: 3X AA batteries (not included)
Support system: ios 10.0 and higher, Android 8.1 and higher

