



SOUND MATES

Bluetooth® 5.0 (BC)

USER MANUAL

WHAT IS INCLUDED

- 1x Charging Box
- 2x Earbud (Left and Right)
- 1x Charging Cable
- 1x Instruction Manual

BLUETOOTH PAIRING INSTRUCTION

- FIRST** - Remove both earbuds from the charging case. They will begin auto-pairing to each other. You will hear 2 beeps to confirm a successful pairing.
- SECOND** - Keep the earbuds within 10 meters of your smart device (for Bluetooth pairing only). Enable your device's Bluetooth function from your device's Settings menu. Select "Tzumi Soundmates" from the Bluetooth device list to pair the earbuds to your device.
- THIRD** - You will hear "Device Connected." Your Soundmates are now ready to use!

RESETTING YOUR EARBUDS

If your Soundmates won't pair to each other, place them back in the charging case. When you remove them from the case again, they will auto-pair.

SOUNDMATES FUNCTIONS

Power ON: Remove your earbuds from the charging case.

Power OFF: Place your earbuds back into the charging case.

Reset Master Earbud: Press and hold the multifunction button on both earbuds until the LEDs flash RED and BLUE alternately. Choose an earbud to designate as the master and press twice. That earbud's LED will flash and the other LED will remain steady on.

MUSIC/CALLING

NEXT/PREVIOUS SONG - While music is playing, tap the LEFT earbud's LED 3 times to skip to the previous song. Tap the RIGHT earbud's LED 3 times to skip ahead to the next song.

PLAY/PAUSE - Tap the RIGHT earbud's LED twice to play or pause your music.

ANSWER/END INCOMING CALL - Tap the RIGHT or LEFT earbud LED twice to answer an incoming call. Tap the RIGHT or LEFT earbud LED twice again to end the call.

ACTIVATE VOICE ASSISTANT

Tap the LEFT earbud's LED twice. You will hear a beeping sound to indicate that your Voice Assistant/Siri is "awake" and awaiting your commands.

CHARGING YOUR SOUNDMATES

NOTE: Be sure to fully charge your Soundmates before using for the first time.

CHARGING THE CASE - Plug the standard Micro-USB charging cable into the port on the case and connect the USB head to a power source, such as an AC wall adapter or computer. The case's LED indicators will remain solid GREEN while charging. When the LEDs stop flashing and turn off completely, the case is fully charged.

CHARGING THE EARBUDS - Place the earbuds into their respective slots in the charging case. The earbuds' LED indicators will turn RED while charging. When the earbuds are fully charged, both LEDs will turn off.

SPECIFICATIONS

Bluetooth Technology: Version 5.0
Battery (Earbuds): 45 mAh (x2), 3.7V
Battery (Charging Case): 500 mAh, 3.7V
Power Output: 6mW
Earbuds Charging Time (Est): 1 hr
Charging Case Time (Est): 2 hr
Music Playback Time: Approx. 3 hours at max. volume
Talking Time: Approx. 3 hours
Frequency: 20 - 20KHz
Dimensions in Case: 51.5 x 44 x 21 mm (2.0 x 1.7 x 0.8 in)

SoundMates Distributed by tzumi® Inc. NY, NY, 10016. ©Copyright 2018 tzumi Inc. All Rights Reserved. Made in China. All other trademarks and tradenames are the property of their respectful owners. Subject to change without prior notice.

