

WIFI CAMERA

Quick Manual

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Information to User

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Important: Change or modifications not expressly approved by the manufacturer responsible for compliance could void the user's authority to operate the equipment.

Quick Operation Guide

Step 1 Download and install the App

Tips one: Scan the QR code below to download the “iCSee”App.



Tips two: Search “iCSee” in the App store and download.

Step 2 Turn on the power

Power on the camera, turn on the device, it will send “system starting up, wait be configured, Wait for the connection, please configure the network according to the Instructions” prompt after several seconds, If the camera does not have a prompt sound for a long time, you can press and hold the camera Reset button until you hear the prompt “ Restore factory settings, please do not power off ”and release it to restore the camera to factory settings and then configure the network.

Note:

If you need local storage, please install the memory card firstly, and then power on the device (the memory card does not support hot swapping, please plug and unplug the memory card when the device is powered off). Cloud storage is recommended, which is safe and convenient. Details See "Step 4" for operation.


Step 3 Configure the network of the camera

Bluetooth network configuration

Note: If the device supports Bluetooth network configuration, please configure it as follows.

1. Connect your phone to WiFi network and turn on Bluetooth.
2. Open the iCSee app, register an account and login(Figure 1).

Figure 1



3. After successful login, Click the “+” button in the top right corner of the screen (Figure 2).
4. Click on the main interface to search for found devices (Figure 3)
(if the camera is not searched please turn the phone Bluetooth off for 5 seconds and turn it back on, then search again or long press the camera Reset button to reset Search again).

Figure 2





Figure 3



5. Enter the wireless router password and click “Confirm” (Figure 4).
6. Wait for the camera network configuration, when the camera emits the voice message “connecting, please wait, connect router successfully”, the network configuration is successful (Figure 5).

Figure 4





Figure 5



7. After the network configuration is successful, set the camera name (Figure 6).
8. Follow the APP interface to guide you through the setup. After the configuration is completed, the device is displayed in the device list interface. Click to open the real-time preview screen, and carry out relevant operations and settings (Figure 7).

Figure 6





Figure 7



WiFi network configuration

Note: If the device does not support Bluetooth network configuration or Bluetooth network configuration fails, please configure it as follows.

1. Connect your phone to WiFi network .
2. Login to iCSee App, click "+" to add devices (Figure 8), and select "WiFi Camera" (Figure 9).
3. Set network configuration according to the camera's voice prompts and the APP interface step-by-step guide. When the camera emits a "Connect router successfully" prompt, it means that the camera has successfully configured the network.

Figure 8






Figure 9



4. After the network configuration is successful, follow the instructions on the APP interface to set the camera password and name.

5. After the configuration is completed, the device is displayed in the device list interface. Click to open the real-time preview screen, and carry out relevant operations and settings (Figure 10).

Figure 10



Step 4 Cloud Storage

Steps to open cloud storage: click the "cloud" icon in the device list interface (Figure 11), and follow the guidance of the app interface to understand and open the cloud storage package, with a variety of packages available.

Figure 11

