

Jackery's warranty does not apply to (i) any product that is misused, abused, modified, damaged by accident, or used for anything other than normal consumer use as authorized in Jackery's current product literature, or (ii) any product purchased through an online auction house. Jackery's warranty does not apply to the battery cell unless the battery cell is fully charged by

The information contained herein is subject to change without notice. The only warranties for Jackery products and services are set forth in the warranty statements accompanying such products and services. Jackery shall not be liable for technical or editorial errors or omissions contained herein. First Edition: December 2019. Document Part Number: J1000-UM-001. This user guide describes features that are common to most models.

you within seven days after you purchase the product and at least every 6 months thereafter.

© Copyright 2012-2020 Jackery Inc. All trademarks cited herein are the property of their respective owners.


To obtain warranty service, contact our customer service team at hello@jackery.com

How to Receive Service

Press button for LED flashlight, hold on button for 2-3

to turn off.

seconds for SOS function, press button one more time




USB Output

Technical

www.jackery.com hello@jackery.com

correctly.



jackery.inc


1-888-502-2236

Mon-Fri 9:00AM - 5:00PM (PST)



USER MANUAL


FEATURES • TECHNICAL SPECIFICATIONS • HOW TO CHARGE • FAQs • WHAT' S IN THE BOX



Congratulations on your new Jackery Explorer 1000!

CHARGE FIRST! Before using your new Jackery Explorer, plug it into a suitable power outlet until it is fully charged. Then you can start your exciting journey with it.







AC Output


USB Output

Car Port





 \bullet DO NOT move the unit if it is recharging or * Serious injuries include blindness, burns, electric shock, fractures, poisoning, etc., which can lead to complications, hospitalization or permanent treatment. **Injuries include burns, electric shock, etc., which do not lead to hospitalization or permanent treatment ***Property damage: includes buildings, belongings and pets, etc.



DISCLAIMER Our company cannot be held liable for damages caused by fire, earthquake, use by a third party, other accidents,

other abnormal conditions.

Do not repair any damage to the AC plug or power supply on

intentional misconduct on the part of the customer, abuse or

The warranty covers all terms and conditions of the warranty. Contents that are not specified in the warranty terms and conditions are beyond our responsibility.

Our company assumes no liability for damages caused by

incorrect use or non-compliance with this instruction manual.

Intended use: The Jackery Explorer 1000 portable power unit is intended as a power supply for electronic devices with a maximum power consumption of 1000W. Our product is not suitable to be used with equipment that relates to one's own personal safety and relies heavily on electricity, such as medical devices, equipment for nuclear facilities, the manufacture of air and spacecraft, etc. We therefore assume no liability for accidents involving personal safety, fires, or machine failures, caused by using our product with the aforementioned devices.



This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interfeence. (2) This device must accept any interference received, including interference that may cause undesired operation.