



Originale	Sostituto
	Power
	Menu / Home
	Sound / Title
	AV / Input / RDS
	1
	2
	3
	4
	5
	6
	7
	8
	9
	0
	Guide / EPG / -/--
	Fav / Marker / PC
	Display / Media

Originale	Sostituto
	Subtitle / EQ
	Pause / Step / Freeze
	TV/Radio /
	Picture / Format
	Audio / Lang I/II
	Mute / Dimmer
	Green / APP / Repeat
	Yellow / YouTube / Repeat
	Up
	Text / Goto
	Play / Slow
	Left
	OK
	Right
	Stop / Hold
	Back / Return
	Down



