

























Remote Control Setting



Button	Functional
 Normal Mode	Press the "ON/OFF" button, the light goes to constant on/off mode, sensor is disable ; turn off then turn on the light goes to constant on mode. Short press the "Sensor Mode" button, the sensor starts to work.
 Sensor Mode	Short press the "Sensor Mode" button, the light quit to constant on/off mode. the sensor starts to work, all parameters back to the last settings.
    	Hold Time Set hold time: 5S/30S/1min/5min/10min
    	Set up high sensitivity To enter the highly sensitive detection, first press the key  and then select the detection range Detection Area:    
    	Set up low sensitivity To enter the highly sensitive detection, first press the key  and then select the detection range Detection Area: 