

SUZUKI

PARTS CATALOGUE

DL1000 (X) AL8

(JS1VU51A)

DL1000A
DL1000XA



V-STROM 1000 ABS

E03/E28/E33

2017-1

1ST EDITION

DL1000AL8



YU1

DL1000AL8



YVB

DL1000AL8



YWW

DL1000XAL8



YU1

DL1000XAL8



YWW

PREFACE

When it becomes necessary to replace parts on SUZUKI MOTORCYCLES, always use SUZUKI GENUINE PARTS which have passed a strict inspection which guarantees quality and performance.

This parts catalogue covers the list of all service parts for SUZUKI DL1000AL8, DL1000XAL8.

INSTRUCTIONS FOR QUOTING THE CATALOGUE

1. DIMENSIONS

Dimensions of the parts in this catalogue are indicated in unit millimeters.

2. ABBREVIATIONS

Abbreviations used in this catalogue are as follows:

AR	: As required	NT	: Number of teeth
ASSY	: Assembly	OPT	: Optional
E.NO.	: Engine number	OS	: Over size
F.NO.	: Frame number	STD	: Standard
D	: Diameter of material	T	: Thickness
ID	: Inside diameter	US	: Under size
OD	: Outside diameter	W	: Width
L	: Length	E28	: Canada specification
LH	: Left hand side	E3	: Federal specification
RH	: Right hand side	E33	: California specification
~100045	: Up to F.NO.100045		
100046~	: From F.NO.100046		
12 x 34 x 5.6	: Figures in the description column		
	show the dimensions of parts.		
ID	OD	T(or W,L)	

3. INNER PARTS OF ASSEMBLY

Part name with a dot (.) in front as shown in the description column indicates the component of the assembly also available individually.

4. MODIFICATION NOTICE

A parts bulletin will be sent to you on all occasions when changes in parts occur, including interchangeable modifications between new parts and old ones.

5. NOTE

- 5-1. There are some different parts from those of production models among spare parts for the administrative reasons and common use of them with other models.
- 5-2. In respect of rubber hoses and vinyl tubes, please be sure to use them by cutting off according to the length mentioned on parts catalogue or what is actually required on the vehicle.
- 5-3. Note that the drawings on the illustration page are for ready reference of spare parts number, not to be used as an assembly manual.
When assembling, use "SUZUKI SERVICE MANUAL".

6. SERIAL FRAME NUMBER

DL1000AL8 : JS1VU51A J2100001~
DL1000XAL8 : JS1VU51A J2100001~

PREFACE

Quand il devient nécessaire de remplacer des pièces sur SUZUKI MOTOCYCLETTES toujours utiliser les PIECES D'ORIGINE SUZUKI qui ont été soumises à des contrôles de qualité sévères leur garantissant qualité et performance impeccables.

Ce catalogue de pièces détachées couvre la liste de toutes les pièces de rechange pour SUZUKI DL1000AL8,DL1000XAL8.

INSTRUCTIONS POUR UTILISER LE CATALOGUE

1. DIMENSIONS

Les dimensions des pièces dans ce catalogue sont indiquées en unités de millimètres.

2. ABREVIATIONS

Les abréviations utilisées dans ce catalogue sont les suivantes:

AR	: Comme requis	NT	: Nombre de dents
ASSY	: Assemblage	OPT	: Sur option
E.NO.	: Numéro du moteur	OS	: Sur-dimensionné
F.NO.	: Numéro du châssis	T	: Epaisseur
ID	: Diamètre intérieur	US	: Sous-dimensionné
OD	: Diamètre extérieur	W	: Largeur
L	: Longueur	E28	: Spécifications du Canada
LH	: Côté gauche	E3	: Spécifications fédérales des Etats Unis
RH	: Côté droit	E33	: Spécifications de la Californie

~100045 : Jusqu'à F.No.100045

100046~ : Depuis F.No.100046

12 x 34 x 5.6..... Les chiffres dans la colonne
| | | remarques montrent les dimensions
ID OD T(or W,L) des pièces comme suit.

3. PIECES INTERNES DE L'ASSEMBLAGE

Les numéros de pièces qui comportent un point (.) avant la désignation de pièce détachée indique la pièce interne se rapportant à l'assemblage.

4. AVIS DE MODIFICATION

Un bulletin de pièces détachées vous sera envoyé à tout moment opportun quand des changements de pièces ont lieu, y compris les modifications de pièces interchangeables entre les nouvelles et anciennes pièces.

5. A NOTER

5-1. Il existe certaines pièces différentes de celles de rechange pour les modèles de production vu des raisons administratives et dont l'usage est commun avec celles d'autres modèles.

5-2. Concernant les durites en caoutchouc et les tuyaux en vinyle, ne pas manquer de les couper à la bonne longueur comme indiqué dans le catalogue des pièces détachées ou selon ce qui est utile pour le véhicule affecté.

5-3. Noter que les dessins à la page d'illustration servent à titre de référence pour les numéros de pièces détachées, et non pas comme référence pour l'assemblage. Pour cette dernière opération, se reporter au "MANUEL D'ENTRETIEN SUZUKI".

6. NUMERO DE SERIE DU CADRE

DL1000AL8 : JS1VU51A J2100001~

DL1000XAL8 : JS1VU51A J2100001~

[illegible]

COLOR NO. NO DE COULEUR	COLOR DESCRIPTION DESCRIPTION DE COULEUR	COLOR NO. NO DE COULEUR	COLOR DESCRIPTION DESCRIPTION DE COULEUR
AA3	YLF,YVB	YKS	FIERY RED
BGQ	QJ3,U6B,742,QJ7	YKV	MET.MAT BLACK NO.2
BGR	QJ4,U6B,742,QJ7	YLF	THUNDER GRAY METALLIC
BGZ	YLF,YWW	YMD	MISTIC SILVER METALLIC
BG4	YWW,1ZY,YU8,YLF,YMU,019,YKV	YMU	MICRO METAL RED
BG5	YM2,17U,YHF,YU1	YM2	PEARL FROSTY WHITE
BG6	YWW,17U,YHF,YVB	YTA	SATIN BLACK
BG7	YM2,17U,YHF,1ZY,YU1	YUS	MAT MOON SILVER METALLIC
BG8	YWW,17U,YHF,1ZY,YMD	YU1	CHAMPION YELLOW
BG9	YAP,YMU,YMD,PGZ	YU8	FLINT GRAY METALLIC
BHA	YM2,1ZY,17U,019,YU1,YKV	YVB	GLASS SPARKLE BLACK
BKK	QJ3,U6B,742	YWW	PEARL GLACIER WHITE
BKL	QJ4,U6B,742	019	BLACK
GWM	1ZY,YKV	1ZY	URBAN LIGHT GRAY METALLIC
GY8	YU1,019	17U	GRAY METALLIC
PGZ	MET.MAT FIBROIN GRAY	291	BLACK (SEMI-GLOSS)
QJ3	LTHR.NOBLE GRAY	4TX	MAT BLACK METALLIC NO.2
QJ4	LTHR.CHAMPION YELLOW NO.2	5JX	MISTIC SILVER METALLIC
QJ7	STITCH GRAY	5PK	BLACK
U6B	BLACK (LEATHER)	742	SILVER METALLIC
YAP	SHADOW BLACK METALLIC		
YHF	PHANTOM GRAY METALLIC		

MILLIMETER → INCH CONVERSION CHART
TABLEAU DE CONVERSION DE MILLIMETRES → POUCES

	0	1	2	3	4	5	6	7	8	9
00	.000	.039	.079	.118	.157	.197	.236	.276	.315	.354
10	.394	.433	.472	.512	.551	.591	.630	.669	.709	.748
20	.787	.827	.866	.906	.945	.984	1.024	1.063	1.102	1.142
30	1.181	1.220	1.260	1.299	1.339	1.378	1.417	1.457	1.496	1.535
40	1.575	1.614	1.654	1.693	1.732	1.772	1.811	1.850	1.890	1.929
50	1.969	2.008	2.047	2.087	2.126	2.165	2.205	2.244	2.283	2.323
60	2.362	2.402	2.441	2.480	2.520	2.559	2.598	2.638	2.677	2.717
70	2.756	2.795	2.835	2.874	2.913	2.953	2.992	3.031	3.071	3.110
80	3.150	3.189	3.228	3.268	3.307	3.346	3.386	3.425	3.465	3.504
90	3.543	3.583	3.622	3.661	3.701	3.740	3.780	3.819	3.858	3.898

How to read
Mode de lecture


	0	1	2	3	4
00	...	...	...	...	...
10	...	...	...	...	...
20	...	...	...	0.906	...
30	...	...	...	...	...

23 millimeters equal 0.906 in
23 millimètres égalent 0.906 pouce

Contents are subject to change without notice or obligation.


Les matières traitées sont susceptibles d'être modifiées sans préavis obligation de notre part.

FIG.101A




OL 1000A/L E&S E&B 101A
CRANKSET SET

FIG.104A




OL 1000A/L E&S E&B 104A
CYLINDER HEAD (FRONT)

FIG.105A




OL 1000A/L E&S E&B 105A
CYLINDER HEAD (REAR)

FIG.107A




OL 1000A/L E&S E&B 107A
CYLINDER

FIG.108A




OL 1000A/L E&S E&B 108A
CRANKCASE

FIG.112A




OL 1000A/L E&S E&B 112A
CRANKCASE COVER

FIG.120A




OL 1000A/L E&S E&B 120A
CRANKSHAFT

FIG.122A




OL 1000A/L E&S E&B 122A
STARTER CLUTCH

FIG.126A




IN ORIGINAL ECU FOR 1004
CRASH/CHUCKLE

FIG.127A




IN ORIGINAL ECU FOR 1074
CRASH/CHUCKLE

FIG.140A




IN ORIGINAL ECU FOR 1404
THROTTLE-SECV

FIG.140B




IN ORIGINAL ECU FOR 140F
THROTTLE-SECV

FIG.140C




IN ORIGINAL ECU FOR 140C
THROTTLE-SECV

FIG.140D




IN ORIGINAL ECU FOR 140D
THROTTLE-SECV

FIG.140E




IN ORIGINAL ECU FOR 140E
THROTTLE-SECV

FIG.140F




IN ORIGINAL ECU FOR 140F
THROTTLE-SECV

FIG.155A




IN ORIGINAL E&S FOR 1054
W/ CLEANER

FIG.163A




IN ORIGINAL E&S FOR 1054
W/ CLEANER

FIG.170A




IN ORIGINAL E&S FOR 1074
W/ CLEANER

FIG.172A




IN ORIGINAL E&S FOR 1074
W/ CLEANER

FIG.180A




IN ORIGINAL E&S FOR 1054
W/ CLEANER

FIG.185A




IN ORIGINAL E&S FOR 1054
W/ CLEANER

FIG.187A




IN ORIGINAL E&S FOR 1074
W/ CLEANER

FIG.201A




IN ORIGINAL E&S FOR 1074
W/ CLEANER

FIG.206A




IN ORIGINAL E&S ESR_206A
770438280201

FIG.212A




IN ORIGINAL E&S ESR_212A
654404P782

FIG.301A




IN ORIGINAL E&S ESR_301A
2746378280202

FIG.303A




IN ORIGINAL E&S ESR_303A
64636272

FIG.310A




IN ORIGINAL E&S ESR_310A
BATTERY

FIG.312A




IN ORIGINAL E&S ESR_312A
ELECTRICAL

FIG.312B




IN ORIGINAL E&S ESR_312B
ELECTRICAL

FIG.312C




IN ORIGINAL E&S ESR_312C
ELECTRICAL

FIG.312D




IN ORIGINAL ECU FOR 312D
ELECTRONIC

FIG.312E




IN ORIGINAL ECU FOR 312E
ELECTRONIC

FIG.312F




IN ORIGINAL ECU FOR 312F
ELECTRONIC

FIG.330A




IN ORIGINAL ECU FOR 330A
SPRECHONITEP

FIG.330B




IN ORIGINAL ECU FOR 330B
SPRECHONITEP

FIG.330C




IN ORIGINAL ECU FOR 330C
SPRECHONITEP

FIG.330D




IN ORIGINAL ECU FOR 330D
SPRECHONITEP

FIG.330E




IN ORIGINAL ECU FOR 330E
SPRECHONITEP

FIG.330F




IL 0000041.ESL.FOR.300F
DRECKSTREIFEN

FIG.333A




IL 0000041.ESL.FOR.303A
HEADLAMP

FIG.334A




IL 0000041.ESL.FOR.304A
TÜRSCHWINGENLAMP

FIG.339A




IL 0000041.ESL.FOR.309A
REAR COMBINATION LAMP

FIG.350A




IL 0000041.ESL.FOR.300A
BRIDGING HARNESS?

FIG.350B




IL 0000041.ESL.FOR.300B
BRIDGING HARNESS?

FIG.350C




IL 0000041.ESL.FOR.300C
BRIDGING HARNESS?

FIG.350D




IL 0000041.ESL.FOR.300D
BRIDGING HARNESS?

FIG.350E




ON ORIGINAL E&S FOR 300P
WIRING HARNESS

FIG.350F




ON ORIGINAL E&S FOR 300P
WIRING HARNESS

FIG.352A




ON ORIGINAL E&S FOR 300A
LOCK SET

FIG.352B




ON ORIGINAL E&S FOR 300P
LOCK SET

FIG.355A




ON ORIGINAL E&S FOR 300A
HANDLE SWITCH

FIG.401A




ON ORIGINAL E&S FOR 401A
FRAME

FIG.406A




ON ORIGINAL E&S FOR 406A
HOLDER

FIG.407A




ON ORIGINAL E&S FOR 407A
STAND

FIG.412A




DL 0030A1, EA1, EA2, 410A
CARRIERS

FIG.412B




DL 0030A1, EA1, EA2, 410B
CARRIERS

FIG.412C




DL 0030A1, EA1, EA2, 410C
CARRIERS

FIG.412D




DL 0030A1, EA1, EA2, 410D
CARRIERS

FIG.412E




DL 0030A1, EA1, EA2, 410E
CARRIERS

FIG.412F




DL 0030A1, EA1, EA2, 410F
CARRIERS

FIG.415A




DL 0030A1, EA1, EA2, 415A
FOOTREST

FIG.420A




DL 0030A1, EA1, EA2, 420A
FUEL TANK

FIG.420B




IN ORIGINAL E&S FOR 420F
FILES: 7AWW

FIG.420C




IN ORIGINAL E&S FOR 420C
FILES: 7AWW

FIG.420D




IN ORIGINAL E&S FOR 420D
FILES: 7AWW

FIG.420E




IN ORIGINAL E&S FOR 420E
FILES: 7AWW

FIG.420F




IN ORIGINAL E&S FOR 420F
FILES: 7AWW

FIG.420G




IN ORIGINAL E&S FOR 420G
FILES: 7AWW

FIG.420H




IN ORIGINAL E&S FOR 420H
FILES: 7AWW

FIG.420J




IN ORIGINAL E&S FOR 420J
FILES: 7AWW

FIG.423A




ON ORIGINAL ECU FOR 4024
FILE: TWIN COVER

FIG.423B




ON ORIGINAL ECU FOR 4025
FILE: TWIN COVER

FIG.423C




ON ORIGINAL ECU FOR 4027
FILE: TWIN COVER

FIG.423D




ON ORIGINAL ECU FOR 4027
FILE: TWIN COVER

FIG.423E




ON ORIGINAL ECU FOR 4026
FILE: TWIN COVER

FIG.423F




ON ORIGINAL ECU FOR 4026
FILE: TWIN COVER

FIG.423G




ON ORIGINAL ECU FOR 4026
FILE: TWIN COVER

FIG.423H




ON ORIGINAL ECU FOR 4026
FILE: TWIN COVER

FIG.423J




DL 0030A/L E&L E&R 423J
FUEL TANK COVER

FIG.427A




DL 0030A/L E&L E&R 427A
FUEL TANK COVER

FIG.427B




DL 0030A/L E&L E&R 427B
FUEL TANK COVER

FIG.444A




DL 0030A/L E&L E&R 444A
FRONT BRACKET

FIG.444B




DL 0030A/L E&L E&R 444B
FRONT BRACKET

FIG.444C




DL 0030A/L E&L E&R 444C
FRONT BRACKET

FIG.444D




DL 0030A/L E&L E&R 444D
FRONT BRACKET

FIG.444E




DL 0030A/L E&L E&R 444E
FRONT BRACKET

FIG.444F




DL 000M/L EQL EBL 444F
FRONT BRACKET

FIG.444G




DL 000M/L EQL EBL 444G
FRONT BRACKET

FIG.444H




DL 000M/L EQL EBL 444H
FRONT BRACKET

FIG.444J




DL 000M/L EQL EBL 444J
FRONT BRACKET

FIG.445A




DL 000M/L EQL EBL 445A
FRONT BRACKET

FIG.460A




DL 000M/L EQL EBL 460A
FRONT BRACKET

FIG.460B




DL 000M/L EQL EBL 460B
FRONT BRACKET

FIG.460C




DL 000M/L EQL EBL 460C
FRONT BRACKET

FIG.460D




1/1 (0030A) L, R, L, R, H, H
FRONT FENDER

FIG.460E




1/1 (0030A) L, R, L, R, H, H
FRONT FENDER

FIG.460F




1/1 (0030A) L, R, L, R, H, H
FRONT FENDER

FIG.460G




1/1 (0030A) L, R, L, R, H, H
FRONT FENDER

FIG.460H




1/1 (0030A) L, R, L, R, H, H
FRONT FENDER

FIG.460J




1/1 (0030A) L, R, L, R, H, H
FRONT FENDER

FIG.462A




1/1 (0030A) L, R, L, R, H, H
HANDLEBAR

FIG.462B




1/1 (0030A) L, R, L, R, H, H
HANDLEBAR

FIG.462C




ON 1000ML E82 E8R, H82P
HANDLEL840

FIG.462D




ON 1000ML E82 E8R, H82P
HANDLEL840

FIG.462E




ON 1000ML E82 E8R, H82P
HANDLEL840

FIG.462F




ON 1000ML E82 E8R, H82P
HANDLEL840

FIG.467A




ON 1000ML E82 E8R, H87A
HANDLE L871

FIG.472A




ON 1000ML E82 E8R, H72A
HANDLE COVER

FIG.474A




ON 1000ML E82 E8R, H74A
HANDLE FENDER

FIG.481A




ON 1000ML E82 E8R, H81A
COVERING BR201

FIG.482A




IN ORIGINAL ECU FOR 40N
COULD BE INSTALLED IN PARTS

FIG.483A




IN ORIGINAL ECU FOR 40N
UNDERCOVERING

FIG.496A




IN ORIGINAL ECU FOR 40N
LARGE

FIG.496B




IN ORIGINAL ECU FOR 40N
LARGE

FIG.496C




IN ORIGINAL ECU FOR 40N
LARGE

FIG.496D




IN ORIGINAL ECU FOR 40N
LARGE

FIG.496E




IN ORIGINAL ECU FOR 40N
LARGE

FIG.496F




IN ORIGINAL ECU FOR 40N
LARGE

FIG.505A




ON ORIGINAL ERS FOR 3014
SEAT

FIG.521A




ON ORIGINAL ERS FOR 3014
FRONT FOAM CHAIRS

FIG.524A




ON ORIGINAL ERS FOR 3014
STEERING STEM

FIG.524B




ON ORIGINAL ERS FOR 3014
STEERING STEM

FIG.524C




ON ORIGINAL ERS FOR 3014
STEERING STEM

FIG.524D




ON ORIGINAL ERS FOR 3014
STEERING STEM

FIG.524E




ON ORIGINAL ERS FOR 3014
STEERING STEM

FIG.524F




ON ORIGINAL ERS FOR 3014
STEERING STEM

FIG.530A




IN ORIGINAL E&S FOR 3004
FRONT WHEEL

FIG.530B




IN ORIGINAL E&S FOR 3005
FRONT WHEEL

FIG.530C




IN ORIGINAL E&S FOR 3006
FRONT WHEEL

FIG.530D




IN ORIGINAL E&S FOR 3007
FRONT WHEEL

FIG.530E




IN ORIGINAL E&S FOR 3005
FRONT WHEEL

FIG.530F




IN ORIGINAL E&S FOR 3005
FRONT WHEEL

FIG.533A




IN ORIGINAL E&S FOR 3004
HYDRAULIC UNIT

FIG.534A




IN ORIGINAL E&S FOR 3004
FRONT ELECTRICAL

FIG.535A




IN ORIGINAL EQUIPMENT
FRONT BRAKE HOSE

FIG.536A




IN ORIGINAL EQUIPMENT
FRONT BRAKE HOSE

FIG.537A




IN ORIGINAL EQUIPMENT
FRONT MASTER CYLINDER

FIG.539A




IN ORIGINAL EQUIPMENT
CLUTCH MASTER CYLINDER

FIG.541A




IN ORIGINAL EQUIPMENT
REAR SWAY BAR

FIG.543A




IN ORIGINAL EQUIPMENT
REAR SHOCK LEVER

FIG.550A




IN ORIGINAL EQUIPMENT
REAR WHEEL

FIG.550B




IN ORIGINAL EQUIPMENT
REAR WHEEL

FIG.550C




ON 100MM L EAS FOR 300°
65-60 (HUBS)

FIG.550D




ON 100MM L EAS FOR 300°
65-60 (HUBS)

FIG.550E




ON 100MM L EAS FOR 300°
65-60 (HUBS)

FIG.550F




ON 100MM L EAS FOR 300°
65-60 (HUBS)

FIG.555A




ON 100MM L EAS FOR 300°
65-60 (HUBS)

FIG.558A




ON 100MM L EAS FOR 300°
65-60 (HUBS)

FIG.901A




ON 100MM L EAS FOR 300°
65-60 (HUBS)

FIG.970A




ON 100MM L EAS FOR 300°
65-60 (HUBS)

FIG.970B




DL 000AAL, EAS, EBR, INTD
OPTIONAL

FIG.970C




DL 000AAL, EAS, EBR, INTD
OPTIONAL

FIG.970D




DL 000AAL, EAS, EBR, INTD
OPTIONAL

FIG.970E




DL 000AAL, EAS, EBR, INTD
OPTIONAL

FIG.970F




DL 000AAL, EAS, EBR, INTD
OPTIONAL

FIG.970G



DL 000AAL, EAS, EBR, INTD
OPTIONAL

FIG.970H



DL 000AAL, EAS, EBR, INTD
OPTIONAL

FIG.101A




FIG.101A (1-B-2) GASKET SET

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	11401-31820	GASKET SET	1	OPT
2	11141-31J00	.GASKET, CYLINDER HEAD	2	NOT ILLUSTRATED
3	11173-02F00	.GASKET, CYLINDER HEAD COVER NO.1	2	NOT ILLUSTRATED
4	11178-17E00	.GASKET, CYLINDER HEAD COVER NO.2	2	NOT ILLUSTRATED
5	11241-31J00	.GASKET, CYLINDER FRONT	1	NOT ILLUSTRATED
6	11242-31J00	.GASKET, CYLINDER REAR	1	NOT ILLUSTRATED
7	11482-06G10	.GASKET, CLUTCH COVER	1	NOT ILLUSTRATED
8	11483-02F10	.GASKET, MAGNETO COVER	1	NOT ILLUSTRATED
9	11485-02F10	.GASKET, GEAR SHIFT COVER	1	NOT ILLUSTRATED
10	12837-19B10	.GASKET, TENSIONER ADJUSTER	1	NOT ILLUSTRATED
11	12837-24A10	.GASKET, TENSIONER ADJUSTER	1	NOT ILLUSTRATED
12	14181-31D00	.GASKET, EXHAUST PIPE	2	NOT ILLUSTRATED
13	14771-42F40	.CONNECTOR, EXHAUST	2	NOT ILLUSTRATED
14	15201-35F00	.O RING, FUEL PUMP	1	NOT ILLUSTRATED
15	09168-14002	.GASKET (13.8X18.8X4.8)	2	NOT ILLUSTRATED
16	09280-33004	.O RING (D:3.1,ID:32.7)	1	NOT ILLUSTRATED
17	09280-55005	.O RING (D:2.4,ID:55.6)	2	NOT ILLUSTRATED
18	17435-02F00	.O RING	1	NOT ILLUSTRATED

FIG.104A




FIG.104A (1-B-3) CYLINDER HEAD (FRONT)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	11100-31J00	HEAD ASSY, CYLINDER FRONT	1	
2	09206-08001	.PIN (8X11)	4	
3	09103-06266	.BOLT (6X40)	8	
4	11115-32E70	GUIDE, VALVE (OS:0.3)	4	OPT
5	11141-31J00	GASKET, CYLINDER HEAD	1	
6	04211-13189	PIN	2	
7	09108-08143	STUD BOLT	1	
8	08316-1008A	NUT	1	
9	11117-33H00	BOLT (10X175)	4	
10	09108-06096	STUD BOLT	2	
11	08316-1006A	NUT	2	
12	01550-0612A	BOLT	1	
13	09168-06023	GASKET (5.8X13X1.2)	1	
14	09103-06220	BOLT (6X60)	2	
15	09482-00635	SPARK PLUG (LMAR8BI-9)	2	NGK
16	13101-31J00	PIPE, INTAKE FRONT	1	
17	09280-55005	.O RING (D:2.4,ID:55.6)	1	
18	02122-0616B	SCREW	2	
19	13170-40H01	CLAMP	1	
20	11171-31J40	COVER, CYLINDER HEAD	1	
21	11173-02F00	GASKET, CYLINDER HEAD COVER NO.1	1	
22	11178-17E00	GASKET, CYLINDER HEAD COVER NO.2	1	
23	09106-07021	BOLT (7X17.5)	4	
24	11191-27E00	WASHER	4	
25	01550-1050A	BOLT	1	RH
26	01550-1070A	BOLT	1	LH
27	11134-31J00	COVER, CYLINDER HEAD NO.2	1	
28	09106-06075	BOLT (6X12)	2	
29	09280-19005	O RING (D:2.4,ID:19)	1	

FIG.105A




FIG.105A (1-B-4) CYLINDER HEAD (REAR)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	11100-31J00	HEAD ASSY, CYLINDER REAR	1	
2	09206-08001	.PIN (8X11)	4	
3	09103-06266	.BOLT (6X40)	8	
4	11115-32E70	GUIDE, VALVE (OS:0.3)	4	OPT
5	11141-31J00	GASKET, CYLINDER HEAD	1	
6	04211-13189	PIN	2	
7	09108-08143	STUD BOLT	1	
8	08316-1008A	NUT	1	
9	11117-33H00	BOLT (10X175)	4	
10	09103-06220	BOLT (6X60)	2	
11	09108-06096	STUD BOLT	2	
12	08316-1006A	NUT	2	
13	01550-0612A	BOLT	1	
14	09168-06023	GASKET (5.8X13X1.2)	1	
15	09482-00635	SPARK PLUG (LMAR8BI-9)	2	NGK
16	13102-31J00	PIPE, INTAKE REAR	1	
17	09280-55005	.O RING (D:2.4,ID:55.6)	1	
18	02122-0616B	SCREW	2	
19	13170-40H01	CLAMP	1	
20	11172-31J20	COVER, CYLINDER HEAD	1	
21	11173-02F00	GASKET, CYLINDER HEAD COVER NO.1	1	
22	11178-17E00	GASKET, CYLINDER HEAD COVER NO.2	1	
23	09106-07021	BOLT (7X17.5)	4	
24	11191-27E00	WASHER	4	
25	11134-31J00	COVER, CYLINDER HEAD NO.2	1	
26	09106-06075	BOLT (6X12)	2	
27	09280-19005	O RING (D:2.4,ID:19)	1	

FIG.107A




FIG.107A (1-B-5) CYLINDER

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	11211-31J00-0F0	CYLINDER, FRONT	1	
2	11221-31J00-0F0	CYLINDER, REAR	1	
3	11241-31J00	GASKET, CYLINDER FRONT	1	
4	11242-31J00	GASKET, CYLINDER REAR	1	
5	04211-13189	PIN	4	
6	09108-06124	STUD BOLT	1	
7	01421-0620A	STUD BOLT	5	
8	08316-1006A	NUT	6	

FIG.108A




FIG.108A (1-B-6) CRANKCASE

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	11306-06831	CRANKCASE SET	1	
2	11319-33E00	.PIN	2	
3	09106-08142	.BOLT (8X110)	2	
4	01547-0630A	.BOLT	4	
5	01547-0670A	.BOLT	7	
6	01547-0685A	.BOLT	1	
7	07120-0890A	.BOLT	4	
8	09106-08136	.BOLT (8X125)	1	
9	08322-0108A	.WASHER	1	
10	09493-28010	.JET, AIR (14)	2	
11	09280-04004	.O RING (D:1.2,ID:4)	2	
12	16591-06B01	.UNION, OIL FILTER STAND	1	
13	09280-12009	O RING (D:1.9,ID:12.6)	1	
14	09493-20014	JET, OIL GALLERY	1	
15	09280-04004	O RING (D:1.2,ID:4)	1	
16	09106-06075	BOLT (6X12)	2	
17	09280-05007	O RING (D:1.2,ID:4.7)	2	
18	11390-06G10	JET, PISTON COOLING	2	
19	01550-0812A	BOLT	4	
20	09168-08016	GASKET (8.2X14X1)	4	
21	09248-16012	PLUG (16X8)	1	
22	09168-16002	GASKET (16X22X2)	1	
23	09247-14036	PLUG (14X20)	1	OIL DRAIN
24	09168-14002	GASKET (13.8X18.8X4.8)	1	
25	09103-10205	BOLT (10X225)	1	
26	09103-10226	BOLT (10X265)	1	
27	09103-12016	BOLT (12X300)	1	
28	08319-3110A	NUT	1	
29	09159-12056	NUT	1	
30	37820-33D10	SWITCH ASSY, OIL PRESSURE	1	
31	37822-33D00	.BOLT	1	

FIG.112A




FIG.112A (1-B-7) CRANKCASE COVER

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	11340-06G40	COVER, CLUTCH	1	
2	11971-33210	.LENS, OIL LEVEL CHECK	1	
3	11482-06G10	GASKET, CLUTCH COVER	1	
4	04211-09149	PIN	2	
5	09103-06213	BOLT (6X30)	9	
6	09103-06257	BOLT (6X75)	2	
7	11342-06G00	SEPARATOR, OIL	1	
8	02112-0612A	SCREW	4	
9	01550-0610A	BOLT	1	
10	09168-06026	GASKET (6.4X11.5X0.8)	1	
11	11351-31J10	COVER, MAGNETO	1	
12	11483-02F10	GASKET, MAGNETO COVER	1	
13	04211-09149	PIN	1	
14	09103-06214	BOLT (6X35)	9	
15	09103-06263	BOLT (6X80)	2	
16	09259-36027	PLUG	1	
17	09280-33004	O RING (D:3.1,ID:32.7)	1	
18	09248-14011	PLUG (14X12)	1	
19	09168-14002	GASKET (13.8X18.8X4.8)	1	
20	11360-31J00	COVER, ENGINE SPROCKET	1	
21	11362-31J00	.SHEET, SPROCKET COVER	1	
22	09103-06214	BOLT (6X35)	2	
23	09103-06261	BOLT (6X60)	1	
24	11381-06G00	COVER, GEAR SHIFT	1	
25	11485-02F10	GASKET	1	
26	09103-06314	BOLT (6X105)	1	
27	01547-0625A	BOLT	2	
28	01547-0635A	BOLT	2	
29	04211-09149	PIN	2	
30	11971-25D00	PLUG, OIL FILLER	1	
31	09280-17003	O RING (D:3.1,ID:16.8)	1	

FIG.120A




FIG.120A (1-B-8) CRANKSHAFT

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	12220-31J00	CRANKSHAFT	1	
2-1	12229-31J00-0A0	BEARING, LOWER (GREEN)	4	
2-2	12229-31J00-0B0	BEARING, LOWER (BLACK)	4	
2-3	12229-31J00-0C0	BEARING, LOWER (BROWN)	4	
3	12652-38B00	WASHER, CRANK THRUST	1	
4	12160-06G10	CONNECTING ROD ASSY	2	
5	12163-06G00	.BOLT	4	
6	12165-27A50	.PIN	4	
7-1	12164-31J00-0A0	BEARING, CRANK PIN (GREEN)	4	
7-2	12164-31J00-0B0	BEARING, CRANK PIN (BLACK)	4	
7-3	12164-31J00-0C0	BEARING, CRANK PIN (BROWN)	4	
7-4	12164-31J00-0D0	BEARING, CRANK PIN (YELLOW)	4	
8	12111-31J10-0F0	PISTON	2	
9	12140-31J00	RING SET, PISTON	2	
10	12151-02F10	PIN, PISTON	2	
11	09381-22002	CIRCLIP	4	
12	21111-02F11	GEAR, PRIMARY DRIVE (NT:31)	1	
13	21112-02F00	GEAR, PRIMARY DRIVE SCISSORS (NT:31)	1	
14	21114-02F00	WASHER	1	
15	08331-31409	CIRCLIP	1	
16	09440-07001	SPRING	3	
17	09140-22012	NUT	1	
18	09164-22007	WASHER	1	
19	09420-06001	KEY	1	

FIG.122A




FIG.122A (1-B-9) STARTER CLUTCH

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	12612-06G00	GEAR, STARTER IDLE (NT:27)	1	
2	09206-12002	PIN (7X12X50.5)	1	
3	09180-12140	SPACER (12.5X19X17.5)	1	
4	12600-06811	CLUTCH SET, STARTER (NT:72)	1	
5	09106-08106	BOLT (8X20)	6	
6	12600-06G01	LIMITER ASSY, STARTER IDLE GEAR (NT:44)	1	
7	12618-31G00	BUSH	2	
8	09181-10195	SHIM (10X20X1)	2	

FIG.126A




FIG.126A (1-B-10) CAMSHAFT/VALVE

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	12701-06G00	CAMSHAFT ASSY, INTAKE FRONT	1	
2	12702-06G00	CAMSHAFT ASSY, EXHAUST FRONT	1	
3	12703-06G00	CAMSHAFT ASSY, INTAKE REAR	1	
4	12704-06G00	CAMSHAFT ASSY, EXHAUST REAR	1	
5	12911-16G00	VALVE, INTAKE	4	
6	12912-02F10	VALVE, EXHAUST	4	
7	12921-06G00	SPRING VALVE	8	
8	12931-06G00	RETAINER, VALVE SPRING	8	
9	12933-06G00	SEAT, VALVE SPRING	8	
10	09289-05015	OIL SEAL (5.5X11X8.2)	8	
11	12932-24400	COTTER, VALVE	16	
12	12891-02F00	TAPPET	8	
13-1	12892-41C00-230	SHIM, TAPPET (T:2.30)	8	
13-2	12892-41C00-235	SHIM, TAPPET (T:2.35)	8	
13-3	12892-41C00-240	SHIM, TAPPET (T:2.40)	8	
13-4	12892-41C00-245	SHIM, TAPPET (T:2.45)	8	
13-5	12892-41C00-250	SHIM, TAPPET (T:2.50)	8	
13-6	12892-41C00-255	SHIM, TAPPET (T:2.55)	8	
13-7	12892-41C00-260	SHIM, TAPPET (T:2.60)	8	
13-8	12892-41C00-265	SHIM, TAPPET (T:2.65)	8	
13-9	12892-41C00-270	SHIM, TAPPET (T:2.70)	8	
13-10	12892-41C00-275	SHIM, TAPPET (T:2.75)	8	
13-11	12892-41C00-280	SHIM, TAPPET (T:2.80)	8	
13-12	12892-41C00-285	SHIM, TAPPET (T:2.85)	8	
13-13	12892-41C00-290	SHIM, TAPPET (T:2.90)	8	
13-14	12892-41C00-295	SHIM, TAPPET (T:2.95)	8	
13-15	12892-41C00-300	SHIM, TAPPET (T:3.00)	8	
13-16	12892-41C00-305	SHIM, TAPPET (T:3.05)	8	
13-17	12892-41C00-310	SHIM, TAPPET (T:3.10)	8	
13-18	12892-41C00-315	SHIM, TAPPET (T:3.15)	8	
13-19	12892-41C00-320	SHIM, TAPPET (T:3.20)	8	
13-20	12892-41C00-325	SHIM, TAPPET (T:3.25)	8	
13-21	12892-41C00-330	SHIM, TAPPET (T:3.30)	8	
13-22	12892-41C00-335	SHIM, TAPPET (T:3.35)	8	

FIG.126A





FIG.126A (1-B-11) CAMSHAFT/VALVE

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
13-23	12892-41C00-340	SHIM, TAPPET (T:3.40)	8	
13-24	12892-41C00-345	SHIM, TAPPET (T:3.45)	8	
13-25	12892-41C00-350	SHIM, TAPPET (T:3.50)	8	
14	12800-41810	SHIM SET, TAPPET T:2.50, 2.55...3.45, 3.50 (5PCS.EACH) & CASE	1	OPT NOT ILLUSTRATED
15	99000-69471	.CASE, TAPPET SHIM	1	OPT NOT ILLUSTRATED

FIG.127A



DL1000AL8_E03_E28_127A
CAM CHAIN

FIG.127A (1-B-12) CAM CHAIN

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	12760-23F20	CHAIN, CAM SHAFT DRIVE	2	
2	12771-06G00	GUIDE, CAM CHAIN	2	
3	12810-06G00	TENSIONER, FRONT CAM CHAIN	1	
4	12815-06G00	TENSIONER, REAR CAM CHAIN	1	
5	07120-0612A	BOLT	2	
6	12832-05A10	ADJUSTER ASSY, FRONT TENSIONER	1	
7	09168-12018	.GASKET (12X21X2)	1	
8	12830-30A01	ADJUSTER ASSY, REAR TENSIONER	1	
9	12832-02A00	.O RING	1	
10	12833-30A01	.SPRING	1	
11	12834-02A00	.PLUG	1	
12	12837-19B10	GASKET	1	
13	12837-24A10	GASKET	1	
14	07130-0625A	BOLT	2	
15	07130-0620A	BOLT	2	
16	12750-31J10	GEAR, CAM CHAIN IDLER NO.2 (NT:31/41)	2	
17	12755-31J00	SHAFT, IDLER NO.2	2	
18	09421-04004	KEY	1	
19	12716-06G00	SHAFT, IDLER	1	
20	09140-16001	NUT	1	
21	09181-16212	SHIM (16X26X1.5)	1	
22	08112-63030	BEARING	1	RH
23	09262-25006	BEARING (25X47X8)	1	LH
24	24741-20A00	RETAINER, BEARING	1	
25	09126-06011	SCREW (6X12)	1	
26	12731-06G01	SPROCKET, IDLER NO.1 (NT:36)	1	

DL1000AL8_E03_E28

FIG.140A




FIG.140A (1-B-13) THROTTLE BODY (DL1000AL8 E03)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13405-31J00	THROTTLE BODY	1	
2	13580-27G21	.SENSOR ASSY	2	
3	13575-29G00	.O RING	2	
4	13605-02F00	.SCREW	2	
5	13662-22J00	.ADJUSTER	2	
6	13453-36F00	.O RING	2	
7	15710-31J00	INJECTOR ASSY	2	
8	15717-58B00	.O RING	2	
9	15722-14J00	SEAL	2	
10	13683-48G10	HOSE	1	
11	13683-31J20	HOSE	1	
12	15731-11J00	DELIVERY PIPE	1	
13	15732-11J00	DELIVERY PIPE	1	
14	13601-11J00	SCREW, DELIVERY PIPE	4	
15	13602-29G00	PACKING	4	



FIG.140B




FIG.140B (1-B-14) THROTTLE BODY (DL1000AL8 E28)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13405-31J00	THROTTLE BODY	1	
2	13580-27G21	.SENSOR ASSY	2	
3	13575-29G00	.O RING	2	
4	13605-02F00	.SCREW	2	
5	13662-22J00	.ADJUSTER	2	
6	13453-36F00	.O RING	2	
7	15710-31J00	INJECTOR ASSY	2	
8	15717-58B00	.O RING	2	
9	15722-14J00	SEAL	2	
10	13683-48G10	HOSE	1	
11	13683-31J20	HOSE	1	
12	15731-11J00	DELIVERY PIPE	1	
13	15732-11J00	DELIVERY PIPE	1	
14	13601-11J00	SCREW, DELIVERY PIPE	4	
15	13602-29G00	PACKING	4	

FIG.140C




FIG.140C (1-B-15) THROTTLE BODY (DL1000AL8 E33)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13405-31J10	THROTTLE BODY	1	
2	13580-27G21	.SENSOR ASSY	2	
3	13575-29G00	.O RING	2	
4	13605-02F00	.SCREW	2	
5	13662-22J00	.ADJUSTER	2	
6	13453-36F00	.O RING	2	
7	15710-31J00	INJECTOR ASSY	2	
8	15717-58B00	.O RING	2	
9	15722-14J00	SEAL	2	
10	13683-48G10	HOSE	1	
11	13683-31J20	HOSE	1	
12	15731-11J00	DELIVERY PIPE	1	
13	15732-11J00	DELIVERY PIPE	1	
14	13601-11J00	SCREW, DELIVERY PIPE	4	
15	13602-29G00	PACKING	4	
16	13681-06G40	HOSE	1	
17	13683-31J00	HOSE	1	
18	13683-31J10	HOSE	1	
19	13685-04F10	NIPPLE	1	
20	09401-06101	CLIP	4	
21	09401-10410	CLIP	2	
22	18117-52G10	VALVE, CANISTER PURGE	1	
23	08316-1006A	NUT	1	
24	09408-00200	CLIP	1	
25	13627-31J00	BRACKET	1	
26	13602-06128	SCREW	1	

FIG.140D





FIG.140D (1-C-2) THROTTLE BODY (DL1000AL8 E03)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13405-31J00	THROTTLE BODY	1	
2	13580-27G21	.SENSOR ASSY	2	
3	13575-29G00	.O RING	2	
4	13605-02F00	.SCREW	2	
5	13662-22J00	.ADJUSTER	2	
6	13453-36F00	.O RING	2	
7	15710-31J00	INJECTOR ASSY	2	
8	15717-58B00	.O RING	2	
9	15722-14J00	SEAL	2	
10	13683-48G10	HOSE	1	
11	13683-31J20	HOSE	1	
12	15731-11J00	DELIVERY PIPE	1	
13	15732-11J00	DELIVERY PIPE	1	
14	13601-11J00	SCREW, DELIVERY PIPE	4	
15	13602-29G00	PACKING	4	

FIG.140E



DL1000AL8_E03_E28_140E
THROTTLE BODY

FIG.140E (1-C-3) THROTTLE BODY (DL1000XAL8 E28)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13405-31J00	THROTTLE BODY	1	
2	13580-27G21	.SENSOR ASSY	2	
3	13575-29G00	.O RING	2	
4	13605-02F00	.SCREW	2	
5	13662-22J00	.ADJUSTER	2	
6	13453-36F00	.O RING	2	
7	15710-31J00	INJECTOR ASSY	2	
8	15717-58B00	.O RING	2	
9	15722-14J00	SEAL	2	
10	13683-48G10	HOSE	1	
11	13683-31J20	HOSE	1	
12	15731-11J00	DELIVERY PIPE	1	
13	15732-11J00	DELIVERY PIPE	1	
14	13601-11J00	SCREW, DELIVERY PIPE	4	
15	13602-29G00	PACKING	4	

FIG.140F




FIG.140F (1-C-4) THROTTLE BODY (DL1000XAL8 E33)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13405-31J10	THROTTLE BODY	1	
2	13580-27G21	.SENSOR ASSY	2	
3	13575-29G00	.O RING	2	
4	13605-02F00	.SCREW	2	
5	13662-22J00	.ADJUSTER	2	
6	13453-36F00	.O RING	2	
7	15710-31J00	INJECTOR ASSY	2	
8	15717-58B00	.O RING	2	
9	15722-14J00	SEAL	2	
10	13683-48G10	HOSE	1	
11	13683-31J20	HOSE	1	
12	15731-11J00	DELIVERY PIPE	1	
13	15732-11J00	DELIVERY PIPE	1	
14	13601-11J00	SCREW, DELIVERY PIPE	4	
15	13602-29G00	PACKING	4	
16	13681-06G40	HOSE	1	
17	13683-31J00	HOSE	1	
18	13683-31J10	HOSE	1	
19	13685-04F10	NIPPLE	1	
20	09401-06101	CLIP	4	
21	09401-10410	CLIP	2	
22	18117-52G10	VALVE, CANISTER PURGE	1	
23	08316-1006A	NUT	1	
24	09408-00200	CLIP	1	
25	13627-31J00	BRACKET	1	
26	13602-06128	SCREW	1	

FIG.155A




FIG.155A (1-C-5) AIR CLEANER

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13700-31J00	CLEANER ASSY, AIR	1	
2	13881-31J00	.TUBE, OUTLET FR	1	
3	13741-31J00	.CAP, AIR CLEANER	1	
4	13891-31J00	.TUBE, INLET	1	
5	13780-31J00	.FILTER, AIR CLEANER	1	
6	13746-31J00	.GASKET, AIR CLEANER	1	
7	13827-31J00	.CLAMP, OUTLET TUBE	2	
8	03541-0520B	.SCREW	6	
9	13878-10G00	.PLUG	1	
10	09401-14301	.CLIP	1	
11	13746-31J10	.GASKET, AIR CLEANER	1	
12	13882-31J00	.TUBE, OUTLET RR	1	
13	18590-18K00	SENSOR, BOOST	2	
14	18595-04K00	HOLDER, SENSOR	2	
15	13650-41F10	SENSOR, AIR TEMP	1	
16	13655-41F10	.O RING	1	
17	03511-0516A	SCREW	1	
18	13738-31J00	SHEET, AIR CLEANER INLET	1	
19	13850-31J00	TUBE, BREATHER	1	
20	09401-22405	CLIP	2	

FIG.163A




FIG.163A (1-C-6) MUFFLER

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	14150-31J00	PIPE, EXHAUST RR	1	
2	14160-31J00	PIPE, EXHAUST FR	1	
3	14181-31D00	GASKET, EXHAUST PIPE	2	
4	09106-08178	BOLT (8X25)	2	
5	07130-0825A	BOLT	2	
6	09118-08152-A05	BOLT (8X45)	2	
7	09180-08152	SPACER (8.6X12X24.2)	2	
8	09320-12077	CUSHION	2	
9	14771-42F40	CONNECTOR, EXHAUST	2	
10	09106-08197	BOLT (8X35)	2	
11	14205-31J02	PIPE, EXHAUST CENTER	1	
12	14310-31J30-H01	BODY, MUFFLER	1	
13	14780-31J00	COVER, MUFFLER FR	1	
14	09320-08066	.CUSHION	1	
15	09139-06128	SCREW (6X12)	1	
16	14791-31J10	COVER, MUFFLER RR	1	
17	14795-10FA0	GROMMET, MUFFLER COVER	1	
18	09106-06078	BOLT (6X15)	3	
19	09160-06055	WASHER (7X12X1)	3	
20	09106-08164	BOLT (8X45)	1	
21	09180-08156	SPACER (8.6X12X25.5)	1	
22	09320-12049	CUSHION	1	
23	09160-08146	WASHER (8.5X33X1.5)	1	
24	08316-1008A	NUT	1	
25	09106-08162	BOLT (8X40)	1	
26	09403-11307	CLAMP	1	
27	11269-18G01	PULLEY, CONTROLLER	1	
28	11276-31J10	CABLE, EXHAUST VALVE NO.1	1	
29	11277-31J10	CABLE, EXHAUST VALVE NO.2	1	
30	14250-21H00	BRACKET, EXHAUST VALVE CABLE	1	
31	14252-14J00	GUIDE, EXHAUST VALVE CABLE	1	
32	14280-08J00	COVER, EXHAUST VALVE	1	
33	09159-06100	NUT	2	

FIG.163A




FIG.163A (1-C-7) MUFFLER

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
34	01547-0516A	BOLT	1	
35	07120-0612A	BOLT	1	
36	08316-1006A	NUT	1	
37	14459-31J10	CLAMP, MUFFLER CONNECTOR	1	
38	14771-18H00	CONNECTOR, MUFFLER	1	
39	09320-04009	BUSH	1	
40	18213-16H10	SENSOR, OXYGEN	1	
41	18213-18H20	SENSOR, OXYGEN	1	
42	09407-14407	CLAMP (L:145)	2	

FIG.170A




FIG.170A (1-C-8) OIL PUMP

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	16400-02FB0	PUMP ASSY, ENGINE OIL	1	
2	07130-0625A	BOLT	3	
3	16331-02F00	GEAR, OIL PUMP DRIVEN (NT:29)	1	
4	09181-10158	SHIM (10X18X0.5)	1	
5	09261-04009	PIN (4X15.8)	1	
6	08331-31109	CIRCLIP	1	
7	16440-24F00	VALVE ASSY, OIL RELIEF	1	
8	09280-13004	.O RING (D:1.9,ID:13)	1	
9	16510-07J00	FILTER ASSY, ENGINE OIL	1	
10	16520-32E00	STRAINER, ENGINE OIL	1	
11	16321-02F00	GEAR, OIL PUMP DRIVE (NT:41)	1	
12	09261-06002	PIN (6X6)	1	
13	08331-31509	CIRCLIP	1	



FIG.172A




FIG.172A (1-C-9) FUEL PUMP

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	15100-31J01	PUMP ASSY, FUEL	1	
2	15420-05H00	.STRAINER	1	
3	15111-27G00	.CUP, RESERVOIR	1	
4	15112-05H00	.JOINT	1	
5	15113-05H00	.O RING	2	
6	15113-35F00	.O RING	1	
7	15610-14J00	.REGULATOR	1	
8	15114-14J00	.WIRE, EARTH	1	
9	15115-08J00	.WIRE, LEAD	1	
10	15181-31J00	.BRACKET, FUEL GAUGE	1	
11	34810-31J00	.GAUGE ASSY	1	
12	15116-10F00	.SCREW	2	
13	15116-31J00	.SCREW	1	
14	15151-31J00	.BINDER	1	
15	15201-35F00	O RING, FUEL PUMP	1	
16	07120-0612A	BOLT	5	
17	15810-31J00	HOSE, FUEL	1	

FIG.180A




FIG.180A (1-C-10) WATER PUMP

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	17410-31J10	CASE, WATER PUMP	1	
2	17491-16G00	IMPELLER	1	
3	17470-02F10	SEAL, MECHANICAL	1	
4	09283-10005	OIL SEAL (10X20X5)	1	
5	17435-02F00	O RING	1	
6	09262-10016	BEARING (10X22X5)	2	
7	08332-1108A	E RING	1	
8	09103-06213	BOLT (6X30)	2	
9	09103-06239	BOLT (6X65)	3	
10	04211-09149	PIN	1	
11	09352-42703-600	HOSE (4.2X7X600)	1	L:600->140
12	09404-06429	CLAMP (L:45)	1	

FIG.185A




FIG.185A (1-C-11) RADIATOR

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	17710-31J00	RADIATOR ASSY, WATER	1	
2	17800-31J00	FAN ASSY	1	
3	09320-10051	CUSHION	3	
4	09180-06290	SPACER (6.5X10X12)	3	
5	09118-06097	BOLT (6X25)	3	
6	17771-31J00	SHIELD, RADIATOR HEAT	1	
7	01550-0616A	BOLT	3	
8	17802-14F00	NUT	3	
9	09329-18001	CUSHION	4	
10	09409-06314-5PK	CLIP (BLACK)	1	
11	09407-10404	CLAMP (L:100)	1	

FIG.187A





FIG.187A (1-C-12) RADIATOR HOSE


REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	17730-14G00	CAP, RADIATOR (1.1)	1	
2	17851-31J00	HOSE, RADIATOR INLET	1	
3	17852-31J00	HOSE, RADIATOR OUTLET	1	
4	09402-28513	CLAMP	4	
5	09402-35501	CLAMP	4	
6	17853-02F10	HOSE, CONNECTOR INLET	2	
7	17890-06G20	UNION, CONNECTOR HOSE	1	
8	17890-06G20	UNION, CONNECTOR HOSE	1	
9	09280-18008	O RING (D:3.2,ID:17.8)	2	
10	07130-0612A	BOLT	2	
11	17910-31J00	TANK ASSY, RESERVOIR	1	
12	17931-31J00	.CAP	1	
13	09111-06085	BOLT (6X12)	1	
14	17982-31J00	HOSE, RESERVOIR TANK OVFL	1	
15	09401-08411	CLIP	2	
16	17981-31J00	HOSE, RESERVOIR TANK INLET	1	
17	17662-02F11	CONNECTOR, THERMOSTAT INLET	1	
18	17670-06G50	THERMOSTAT	1	
19	17663-42E00	CAP, THERMOSTAT CONNECTOR	1	
20	01550-0616A	BOLT	2	
21	17856-16G10	HOSE, WATER BYPASS	1	
22	09401-12414	CLIP	2	
23	13650-49X00	SENSOR, WATER TEMP	1	
24	09168-12017	GASKET (12X17X1)	1	
25	17920-31J00	BRACKET, RESERVOIR TANK	1	
26	01550-0610A	BOLT	2	



1000AL8_E03_E28

REF NO.	PART NO.	DESCRIPTION	QTY	REMARKS
1	21200-31Y11	GEAR ASSY, PRIMARY DRIVEN (NT:57)	1	
2	09160-25074	WASHER (25X52X2.5)	1	
3	09263-35013	BEARING (35X40X39.8)	1	
4	21411-31J10	HUB, CLUTCH SLEEVE	1	
5	21412-31J00	BOLT, SPRING SUPPORT	3	
6	21413-31J00	SPRING, CLUTCH	3	
7	21414-31J00	WASHER	1	
8	21441-31J00	PLATE, CLUTCH DRIVE NO.1 (T:3.8)	6	
9	21442-31J00	PLATE, CLUTCH DRIVE NO.2 (T:3.8)	3	
10	21451-24F00	PLATE, CLUTCH DRIVEN (T:2.0)	7	
11	21452-31J00	PLATE, CLUTCH DRIVEN (T:2.0)	1	
12	21462-31J10	DISC, CLUTCH PRESSURE	1	
13	21471-24F00	SEAT, WAVE WASHER	1	
14	21472-24F00	WASHER, CLUTCH PLATE WAVE	1	
15	09159-24010	NUT	1	
16	09160-25056	WASHER (25X50X2.5)	1	
17	09164-24008	WASHER	1	
18	09181-25223	SHIM (25X38X1)	1	
19	23110-27A00	ROD, CLUTCH PUSH RH	1	
20	23111-26D00	ROD, CLUTCH PUSH LH	1	
21	23121-31E00	PIECE, CLUTCH PUSH	1	

FIG.201A



DL1000AL8_E03_E28_201A
CLUTCH

FIG.201A (1-C-14) CLUTCH

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
22	23160-06G20	CYLINDER, CLUTCH RELEASE	1	
23	23163-06B00	.CUP	1	
24	23164-05A00	.SPRING	1	
25	59121-01A00	.BLEEDER	1	
26	59122-46H00	.CAP, BLEEDER	1	
27	23166-06G10	COVER, DUST	1	
28	04221-08149	PIN	1	
29	07130-0665A	BOLT	1	
30	07130-0670A	BOLT	1	
31	09160-15045	WASHER (15.5X28X1)	1	
32	23171-06G00	SPACER, CLUTCH RELEASE	1	
33	09263-15003	BEARING (15X28X2)	1	
34	09283-06008	OIL SEAL (6X34X10.5)	1	
35	21415-31J00	SEAT, CLUTCH SPRING	3	

DL1000AL8_E03_E28

FIG.206A




FIG.206A (1-C-15) TRANSMISSION

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	24120-06G00	SHAFT, COUNTER (NT:12)	1	
2	24221-02F01	GEAR, 2ND DRIVE (NT:15)	1	
3	24231-02F30	GEAR, 3RD & 4TH DRIVE (NT:18/22)	1	
4	24251-02F11	GEAR, 5TH DRIVE (NT:23)	1	
5	24252-02F10	BUSH, 5TH DRIVE GEAR	1	
6	24261-02F20	GEAR, 6TH DRIVE (NT:24)	1	
7	24262-02F00	BUSH, 6TH DRIVE GEAR	1	
8	09181-22167	SHIM (22X30X1)	1	
9	09262-20139	BEARING (20X47X14)	1	LH
10	09262-25073	BEARING (25X62X17)	1	RH
11	09280-17004	O RING (D:1.9,ID:16.6)	1	
12	09380-27001	CIRCLIP	1	
13	24130-02F20	SHAFT, DRIVE	1	
14	24311-06G00	GEAR, 1ST DRIVEN (NT:36)	1	
15	09263-22068	BEARING (22X26X11)	1	
16	24321-02F11	GEAR, 2ND DRIVEN (NT:29)	1	
17	24322-02F01	BUSH, 2ND DRIVEN	1	
18	24331-02F20	GEAR, 3RD DRIVEN (NT:27)	1	
19	24332-17E20	BUSH, 3RD DRIVEN GEAR	1	
20	24341-02F20	GEAR, 4TH DRIVEN (NT:27)	1	
21	24332-17E20	BUSH, 4TH DRIVEN GEAR	1	
22	24351-02F20	GEAR, 5TH DRIVEN (NT:25)	1	
23	24361-02F30	GEAR, 6TH DRIVEN (NT:24)	1	
24	09160-27008	WASHER (27X36X1)	1	
25	24333-02F00	WASHER, 3RD DRIVEN	1	

FIG.206A




FIG.206A (1-D-2) TRANSMISSION

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
26	24333-02F00	WASHER, 4TH DRIVEN	1	
27	24333-02F10	WASHER, 3RD & 4TH DRIVEN GEAR	1	
28	09181-20251	SHIM (20X34X1)	1	RH
29	09181-22223	SHIM (22X34X1)	1	LH
30	09262-20082	BEARING (20X52X15)	1	RH
31	09262-28053	BEARING (28X68X18)	1	LH
32	09283-38028	OIL SEAL (38X52X8)	1	LH
33	09380-27001	CIRCLIP	1	
34	09380-27001	CIRCLIP	1	
35	09380-27001	CIRCLIP	1	
36	24741-06G00	RETAINER, DRIVE SHAFT	1	
37	24741-21A00	RETAINER, CENTER SHAFT	1	
38	24751-06G00	RETAINER, DRIVE SHAFT	1	
39	09126-06011	SCREW (6X12)	2	
40	02112-0612A	SCREW	1	
41	07130-0612A	BOLT	2	
42	27510-20A40	SPROCKET, ENGINE (NT:17)	1	
43	27531-31J00	SPACER, SPROCKET	1	
44	27600-06G40-120	CHAIN ASSY (RK525SMOZ8)	1	L:120->116
45	27620-06G40	.JOINT SET, CHAIN	1	
46	09159-20004	NUT	1	
47	09160-25009	WASHER (25X41X3)	1	
48	09280-24010	O RING (D:2.4,ID:23.7)	1	

FIG.212A




FIG.212A (1-D-3) GEAR SHIFTING

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	25211-17E02	FORK, GEAR SHIFT	2	
2	25231-35F00	FORK, GEAR SHIFT	1	
3	25411-02F20	SHAFT, GEAR SHIFT FORK NO.2	1	
4	25411-02F20	SHAFT, GEAR SHIFT FORK NO.1	1	
5	24741-21A00	RETAINER, SHIFT CAM	2	
6	25310-31J00	CAM, GEAR SHIFT	1	
7	04221-04089	.PIN	1	
8	25312-42F01	BOLT, GEAR SHIFT CAM PLATE	1	
9	25381-13E30	PLATE, GEAR SHIFT	1	
10	09125-06122	SCREW (6X12)	2	
11	08113-69050	BEARING	1	
12	25350-06G00	STOPPER, SHIFT CAM	1	
13	25355-38F00	SPRING, STOPPER ARM	1	
14	09111-06041	BOLT (6X14.3)	1	
15	08211-06141	WASHER	1	
16	25510-06G10	SHAFT, GEAR SHIFT	1	
17	25512-06G10	PLATE, GEAR SHIFT	1	
18	25671-01011	STOPPER, GEAR SHIFT	1	
19	09181-14167	SHIM (14X22X1)	3	
20	09283-14005	OIL SEAL (14X22X7.3)	1	
21	09440-17009	SPRING	1	
22	09444-20001	SPRING	1	
23	08331-3114A	CIRCLIP	2	
24	25520-16G00	ARM, GEAR SHIFT LINK	1	
25	25526-47000	.COVER, DUST	1	
26	25525-11C00	ROD, GEAR SHIFT LINK	1	

FIG.212A




FIG.212A (1-D-4) GEAR SHIFTING

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
27	25600-31J00	LEVER ASSY, GEAR SHIFT	1	
28	25526-47000	.COVER, DUST	1	
29	25652-20C00	.RUBBER	1	
30	25617-03F10	SHAFT, GEAR SHIFT LEVER	1	
31	09140-06025	NUT	1	
32	09160-12011	WASHER (12.5X20X1)	1	
33	01547-0625A	BOLT	1	
34	08310-0006A	NUT	1	
35	08331-3112A	CIRCLIP	1	
36	37730-31J00	SENSOR ASSY, GEAR POSITION	1	
37	31497-45000	CLAMP, GEAR SHIFT	1	
38	07130-0510A	BOLT	1	
39	09106-05023	BOLT (5X16)	2	

FIG.301A




FIG.301A (1-D-5) STARTING MOTOR

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	31100-06G01	MOTOR ASSY, STARTING	1	
2	31132-45C00	.HOLDER SET, BRUSH	1	
3	31143-38300	.O RING	1	
4	31150-44B10	.HOUSING	1	
5	31170-02F10	.FRAME	1	
6	31170-43400	.SHIM SET	1	
7	31172-38300	.BUSHING	1	
8	31173-88C00	.BUSHING	1	
9	31264-44110	.O RING	2	
10	31281-24B10	.BOLT	2	
11	31156-48B00	.O RING	1	
12	08310-00067	.NUT	1	
13	08361-3506A	.NUT	1	
14	01547-0625A	BOLT	2	
15	08361-3506A	NUT	1	

FIG.303A




FIG.303A (1-D-6) MAGNETO

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	32101-31J00	STATOR ASSY	1	
2	32102-31J00	ROTOR ASSY	1	
3	32371-13E30	CLAMP, MAGNETO	1	
4	09103-14001	BOLT (14X43)	1	
5	09420-04008	KEY	1	
6	07130-0512A	BOLT	3	
7	09106-06120	BOLT (6X40)	3	



FIG.310A




FIG.310A (1-D-7) BATTERY

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	33620-31J00	BATTERY ASSY (FTZ14S,12V/11.2AH)	1	
2	33652-16G00	PROTECTOR. BATTERY	2	
3	33652-28C00	PROTECTOR	1	
4	33652-31J00	PROTECTOR, BATTERY	1	
5	51553-15D40	CUSHION (50X42X2.0)	2	
6	33810-31J10	WIRE, STARTER MOTOR LEAD	1	
7	33860-31J10	WIRE, BATTERY MINUS	1	
8	09407-14407	CLAMP (L:145)	1	
9	36651-48E00	CLAMP (L:63)	1	

FIG.312A




FIG.312A (1-D-8) ELECTRICAL (DL1000AL8 E03)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	31800-06G00	RELAY ASSY, STARTING MOTER	1	
2	31861-47E00	.COVER, RELAY ASSY	1	
3	09481-30101	.FUSE (30A)	2	
4	09128-06013	SCREW (6X8)	2	
5	32800-31J00	RECTIFIER ASSY	1	
6	08316-1006A	NUT	2	
7	33414-31J00	BRACKET, IGNITION COIL	1	
8	33424-31J00	BRACKET, IGNITION COIL	1	
9	01550-0620A	BOLT	4	
10	09180-06195	SPACER (6.4X10X18)	8	
11	09103-06231	BOLT (6X35)	8	
12	09159-06096	NUT	8	
13	33410-06G00	COIL ASSY, IGNITION	1	
14	33410-17G00	COIL ASSY, IGNITION	1	
15	33410-20H00	COIL ASSY, IGNITION	1	
16	33410-26G00	COIL ASSY, IGNITION	1	
17	33510-31G00	CAP ASSY, SPARK PLUG	2	
18	33510-31G10	CAP ASSY, SPARK PLUG	2	
19	33542-06G00	SEAL, HIGH TENSION CORD, RR	1	
20	33542-06G10	SEAL, HIGH TENSION CORD, FR	1	
21	33542-38B00	SEAL, HIGH TENSION CORD	2	
22	32920-31J12	CONTROL UNIT, FI	1	
23	33960-06G10	SENSOR ASSY, FUEL CUT	1	
24	09280-85001	O RING (D:3.5,I:D:85)	1	
25	33970-47H01	ACTUATOR ASSY, EXHAUST CONTROL	1	
26	09180-06345	SPACER (6.2X14.5X26)	2	
27	09116-06183	BOLT (6X55)	2	
28	44534-24F00	CUSHION	1	

FIG.312B




FIG.312B (1-D-9) ELECTRICAL (DL1000AL8 E28)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	31800-06G00	RELAY ASSY, STARTING MOTER	1	
2	31861-47E00	.COVER, RELAY ASSY	1	
3	09481-30101	.FUSE (30A)	2	
4	09128-06013	SCREW (6X8)	2	
5	32800-31J00	RECTIFIER ASSY	1	
6	08316-1006A	NUT	2	
7	33414-31J00	BRACKET, IGNITION COIL	1	
8	33424-31J00	BRACKET, IGNITION COIL	1	
9	01550-0620A	BOLT	4	
10	09180-06195	SPACER (6.4X10X18)	8	
11	09103-06231	BOLT (6X35)	8	
12	09159-06096	NUT	8	
13	33410-06G00	COIL ASSY, IGNITION	1	
14	33410-17G00	COIL ASSY, IGNITION	1	
15	33410-20H00	COIL ASSY, IGNITION	1	
16	33410-26G00	COIL ASSY, IGNITION	1	
17	33510-31G00	CAP ASSY, SPARK PLUG	2	
18	33510-31G10	CAP ASSY, SPARK PLUG	2	
19	33542-06G00	SEAL, HIGH TENSION CORD, RR	1	
20	33542-06G10	SEAL, HIGH TENSION CORD, FR	1	
21	33542-38B00	SEAL, HIGH TENSION CORD	2	
22	32920-31J12	CONTROL UNIT, FI	1	
23	33960-06G10	SENSOR ASSY, FUEL CUT	1	
24	09280-85001	O RING (D:3.5,I:D:85)	1	
25	33970-47H01	ACTUATOR ASSY, EXHAUST CONTROL	1	
26	09180-06345	SPACER (6.2X14.5X26)	2	
27	09116-06183	BOLT (6X55)	2	
28	44534-24F00	CUSHION	1	

FIG.312C




FIG.312C (1-D-10) ELECTRICAL (DL1000AL8 E33)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	31800-06G00	RELAY ASSY, STARTING MOTER	1	
2	31861-47E00	.COVER, RELAY ASSY	1	
3	09481-30101	.FUSE (30A)	2	
4	09128-06013	SCREW (6X8)	2	
5	32800-31J00	RECTIFIER ASSY	1	
6	08316-1006A	NUT	2	
7	33414-31J00	BRACKET, IGNITION COIL	1	
8	33424-31J00	BRACKET, IGNITION COIL	1	
9	01550-0620A	BOLT	4	
10	09180-06195	SPACER (6.4X10X18)	8	
11	09103-06231	BOLT (6X35)	8	
12	09159-06096	NUT	8	
13	33410-06G00	COIL ASSY, IGNITION	1	
14	33410-17G00	COIL ASSY, IGNITION	1	
15	33410-20H00	COIL ASSY, IGNITION	1	
16	33410-26G00	COIL ASSY, IGNITION	1	
17	33510-31G00	CAP ASSY, SPARK PLUG	2	
18	33510-31G10	CAP ASSY, SPARK PLUG	2	
19	33542-06G00	SEAL, HIGH TENSION CORD, RR	1	
20	33542-06G10	SEAL, HIGH TENSION CORD, FR	1	
21	33542-38B00	SEAL, HIGH TENSION CORD	2	
22	32920-31J22	CONTROL UNIT, FI	1	
23	33960-06G10	SENSOR ASSY, FUEL CUT	1	
24	09280-85001	O RING (D:3.5,I:D:85)	1	
25	33970-47H01	ACTUATOR ASSY, EXHAUST CONTROL	1	
26	09180-06345	SPACER (6.2X14.5X26)	2	
27	09116-06183	BOLT (6X55)	2	
28	44534-24F00	CUSHION	1	

FIG.312D




FIG.312D (1-D-11) ELECTRICAL (DL1000XAL8 E03)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	31800-06G00	RELAY ASSY, STARTING MOTER	1	
2	31861-47E00	.COVER, RELAY ASSY	1	
3	09481-30101	.FUSE (30A)	2	
4	09128-06013	SCREW (6X8)	2	
5	32800-31J00	RECTIFIER ASSY	1	
6	08316-1006A	NUT	2	
7	33414-31J00	BRACKET, IGNITION COIL	1	
8	33424-31J00	BRACKET, IGNITION COIL	1	
9	01550-0620A	BOLT	4	
10	09180-06195	SPACER (6.4X10X18)	8	
11	09103-06231	BOLT (6X35)	8	
12	09159-06096	NUT	8	
13	33410-06G00	COIL ASSY, IGNITION	1	
14	33410-17G00	COIL ASSY, IGNITION	1	
15	33410-20H00	COIL ASSY, IGNITION	1	
16	33410-26G00	COIL ASSY, IGNITION	1	
17	33510-31G00	CAP ASSY, SPARK PLUG	2	
18	33510-31G10	CAP ASSY, SPARK PLUG	2	
19	33542-06G00	SEAL, HIGH TENSION CORD, RR	1	
20	33542-06G10	SEAL, HIGH TENSION CORD, FR	1	
21	33542-38B00	SEAL, HIGH TENSION CORD	2	
22	32920-31J12	CONTROL UNIT, FI	1	
23	33960-06G10	SENSOR ASSY, FUEL CUT	1	
24	09280-85001	O RING (D:3.5,I:D:85)	1	
25	33970-47H01	ACTUATOR ASSY, EXHAUST CONTROL	1	
26	09180-06345	SPACER (6.2X14.5X26)	2	
27	09116-06183	BOLT (6X55)	2	
28	44534-24F00	CUSHION	1	

FIG.312E




FIG.312E (1-D-12) ELECTRICAL (DL1000XAL8 E28)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	31800-06G00	RELAY ASSY, STARTING MOTER	1	
2	31861-47E00	.COVER, RELAY ASSY	1	
3	09481-30101	.FUSE (30A)	2	
4	09128-06013	SCREW (6X8)	2	
5	32800-31J00	RECTIFIER ASSY	1	
6	08316-1006A	NUT	2	
7	33414-31J00	BRACKET, IGNITION COIL	1	
8	33424-31J00	BRACKET, IGNITION COIL	1	
9	01550-0620A	BOLT	4	
10	09180-06195	SPACER (6.4X10X18)	8	
11	09103-06231	BOLT (6X35)	8	
12	09159-06096	NUT	8	
13	33410-06G00	COIL ASSY, IGNITION	1	
14	33410-17G00	COIL ASSY, IGNITION	1	
15	33410-20H00	COIL ASSY, IGNITION	1	
16	33410-26G00	COIL ASSY, IGNITION	1	
17	33510-31G00	CAP ASSY, SPARK PLUG	2	
18	33510-31G10	CAP ASSY, SPARK PLUG	2	
19	33542-06G00	SEAL, HIGH TENSION CORD, RR	1	
20	33542-06G10	SEAL, HIGH TENSION CORD, FR	1	
21	33542-38B00	SEAL, HIGH TENSION CORD	2	
22	32920-31J12	CONTROL UNIT, FI	1	
23	33960-06G10	SENSOR ASSY, FUEL CUT	1	
24	09280-85001	O RING (D:3.5,I:D:85)	1	
25	33970-47H01	ACTUATOR ASSY, EXHAUST CONTROL	1	
26	09180-06345	SPACER (6.2X14.5X26)	2	
27	09116-06183	BOLT (6X55)	2	
28	44534-24F00	CUSHION	1	

FIG.312F




FIG.312F (1-D-13) ELECTRICAL (DL1000XAL8 E33)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	31800-06G00	RELAY ASSY, STARTING MOTER	1	
2	31861-47E00	.COVER, RELAY ASSY	1	
3	09481-30101	.FUSE (30A)	2	
4	09128-06013	SCREW (6X8)	2	
5	32800-31J00	RECTIFIER ASSY	1	
6	08316-1006A	NUT	2	
7	33414-31J00	BRACKET, IGNITION COIL	1	
8	33424-31J00	BRACKET, IGNITION COIL	1	
9	01550-0620A	BOLT	4	
10	09180-06195	SPACER (6.4X10X18)	8	
11	09103-06231	BOLT (6X35)	8	
12	09159-06096	NUT	8	
13	33410-06G00	COIL ASSY, IGNITION	1	
14	33410-17G00	COIL ASSY, IGNITION	1	
15	33410-20H00	COIL ASSY, IGNITION	1	
16	33410-26G00	COIL ASSY, IGNITION	1	
17	33510-31G00	CAP ASSY, SPARK PLUG	2	
18	33510-31G10	CAP ASSY, SPARK PLUG	2	
19	33542-06G00	SEAL, HIGH TENSION CORD, RR	1	
20	33542-06G10	SEAL, HIGH TENSION CORD, FR	1	
21	33542-38B00	SEAL, HIGH TENSION CORD	2	
22	32920-31J22	CONTROL UNIT, FI	1	
23	33960-06G10	SENSOR ASSY, FUEL CUT	1	
24	09280-85001	O RING (D:3.5,I:D:85)	1	
25	33970-47H01	ACTUATOR ASSY, EXHAUST CONTROL	1	
26	09180-06345	SPACER (6.2X14.5X26)	2	
27	09116-06183	BOLT (6X55)	2	
28	44534-24F00	CUSHION	1	

FIG.330A



FIG.330A (1-D-14) SPEEDOMETER (DL1000AL8 E03)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	34120-31JB0	SPEEDOMETER	1	
2	34150-28K00	CASE, UPPER	1	
3	34126-31J00	.RUBBER SWITCH	1	
4	34124-31J00	KNOB	1	
5	34152-28K00	CASE, LOWER	1	
6	34183-29F00	SCREW (3X12)	6	
7	34189-08J00	CUSHION	2	
8	95643-58J00	SENSOR, AIR TEMP	1	




FIG.330B



FIG.330B (1-D-15) SPEEDOMETER (DL1000AL8 E28)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	34120-31JD0	SPEEDOMETER	1	
2	34150-28K00	CASE, UPPER	1	
3	34126-31J00	.RUBBER SWITCH	1	
4	34124-31J00	KNOB	1	
5	34152-28K00	CASE, LOWER	1	
6	34183-29F00	SCREW (3X12)	6	
7	34189-08J00	CUSHION	2	
8	95643-58J00	SENSOR, AIR TEMP	1	




FIG.330C



FIG.330C (1-E-2) SPEEDOMETER (DL1000AL8 E33)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	34120-31JB0	SPEEDOMETER	1	
2	34150-28K00	CASE, UPPER	1	
3	34126-31J00	.RUBBER SWITCH	1	
4	34124-31J00	KNOB	1	
5	34152-28K00	CASE, LOWER	1	
6	34183-29F00	SCREW (3X12)	6	
7	34189-08J00	CUSHION	2	
8	95643-58J00	SENSOR, AIR TEMP	1	




FIG.330D



FIG.330D (1-E-3) SPEEDOMETER (DL1000XAL8 E03)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	34120-31JB0	SPEEDOMETER	1	
2	34150-28K00	CASE, UPPER	1	
3	34126-31J00	.RUBBER SWITCH	1	
4	34124-31J00	KNOB	1	
5	34152-28K00	CASE, LOWER	1	
6	34183-29F00	SCREW (3X12)	6	
7	34189-08J00	CUSHION	2	
8	95643-58J00	SENSOR, AIR TEMP	1	




FIG.330E




FIG.330E (1-E-4) SPEEDOMETER (DL1000XAL8 E28)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	34120-31JD0	SPEEDOMETER	1	
2	34150-28K00	CASE, UPPER	1	
3	34126-31J00	.RUBBER SWITCH	1	
4	34124-31J00	KNOB	1	
5	34152-28K00	CASE, LOWER	1	
6	34183-29F00	SCREW (3X12)	6	
7	34189-08J00	CUSHION	2	
8	95643-58J00	SENSOR, AIR TEMP	1	

FIG.330F



FIG.330F (1-E-5) SPEEDOMETER (DL1000XAL8 E33)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	34120-31JB0	SPEEDOMETER	1	
2	34150-28K00	CASE, UPPER	1	
3	34126-31J00	.RUBBER SWITCH	1	
4	34124-31J00	KNOB	1	
5	34152-28K00	CASE, LOWER	1	
6	34183-29F00	SCREW (3X12)	6	
7	34189-08J00	CUSHION	2	
8	95643-58J00	SENSOR, AIR TEMP	1	




FIG.333A




FIG.333A (1-E-6) HEADLAMP

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	35100-31J01	HEADLAMP ASSY	1	
2	35171-31J00	.CORD ASSY	1	
3	35179-31J00	.COVER	1	
4	35142-31J00	.SEAL, COVER	1	
5	09471-12188	.BULB (12V,55W)	1	
6	09471-12222	.BULB (12V,65W)	1	
7	09471-12216	.BULB (12V5W)	1	
8	09320-07014	.CUSHION	6	
9	09136-05062	SCREW (5X15)	6	

FIG.334A




FIG.334A (1-E-7) TURNSIGNAL LAMP

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	35601-08JA0	LAMP ASSY, FRONT TURNSIGNAL RH	1	
2	35612-08JA0	.LENS, RH	1	
3	03211-0414B	.SCREW	1	
4	09471-12186	.BULB (12V,21W)	1	
5	35602-08JB0	LAMP ASSY, FRONT TURNSIGNAL LH	1	
6	35632-08JA0	.LENS, LH	1	
7	03211-0414B	.SCREW	1	
8	09471-12186	.BULB (12V,21W)	1	
9	35629-18G00	PLATE, FRONT TURNSIGNAL	2	
10	08316-1005A	NUT	2	
11	35603-08JA0	LAMP ASSY, REAR TURNSIGNAL RH	1	
12	35632-08JA0	.LENS, RH	1	
13	03211-0414B	.SCREW	1	
14	09471-12186	.BULB (12V,21W)	1	
15	35604-08JA0	LAMP ASSY, REAR TURNSIGNAL LH	1	
16	35612-08JA0	.LENS, LH	1	
17	03211-0414B	.SCREW	1	
18	09471-12186	.BULB (12V,21W)	1	
19	08316-1005A	NUT	2	
20	38610-06F00	RELAY ASSY, TURNSIGNAL LAMP	1	
21	09404-06429	CLAMP (L:45)	2	

FIG.339A




FIG.339A (1-E-8) REAR COMBINATION LAMP

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	35710-31J01	LAMP ASSY, REAR COMBINATION	1	
2	09160-05501	WASHER (5.5X20X1.2)	3	
3	03541-0516A	SCREW	3	
4	35910-41GC2	LAMP ASSY, LICENSE	1	
5	35912-41G01	.LENS	1	
6	35913-41G00	.GASKET	1	
7	09471-12140	.BULB (12V,5W)	1	
8	35917-41G00	.COVER, LICENSE LAMP	1	
9	03211-0416A	.SCREW	2	
10	09180-06278	SPACER (6.5X9X33.3)	2	
11	09159-06096	NUT	2	
12	35927-14J30	BRACKET, LICENSE PLATE	1	
13	02142-0616A	SCREW	2	
14	09159-06096	NUT	2	
15	35970-13K00	REFLEX REFLECTOR ASSY, RR SIDE	2	
16	08316-1005A	NUT	2	

FIG.350A




FIG.350A (1-E-9) WIRING HARNESS (DL1000AL8 E03)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	36610-31JN0	HARNESS, WIRING NO.1	1	
2	09481-03501	.FUSE (3A)	1	
3	09481-10504	.FUSE (10A)	2	
4	09481-15504	.FUSE (15A)	5	
5	09481-25504	.FUSE (25A)	1	
6	38860-76F01	.RELAY ASSY	1	FOR FUEL PUMP
7	38860-76F01	.RELAY ASSY	1	FOR FAN MOTOR
8	38860-76F01	.RELAY ASSY	1	FOR SIDE STAND
9	36620-31J10	HARNESS, WIRING NO.2	1	
10	36618-41G00	.COVER, SPEEDOMETER	1	
11	36618-18G10	.COVER, SPEEDOMETER	1	
12	09407-14407	CLAMP (L:145)	3	
13	09407-17403	CLAMP (L:154)	1	
14	09407-14403	CLAMP (L:125)	3	
15	37740-31D00	SWITCH ASSY, STOP LAMP	1	
16	43259-31J00	SPRING, STOP LAMP	1	
17	37840-24F00	SWITCH ASSY, SIDE STAND	1	
18	09103-08357	BOLT (8X35)	1	
19	38500-41F50	HORN ASSY	1	
20	01550-0612A	BOLT	1	
21	36654-06J20	CAP, TS	1	
22	09404-06429	CLAMP (L:45)	1	
23	36851-31J10	WIRE, OIL PRESSURE SWITCH LEAD	1	
24	36618-31J00	.CAP, OIL PRESSURE SWITCH	1	
25	36856-31J10	WIRE, REAR TURN SIGNAL LEAD	1	
26	36854-31J20	WIRE, IGNITION COIL LEAD	1	
27	09404-06429	CLAMP (L:45)	1	
28	38850-31J00	TERMINAL, POWER SOURCE	1	
29	48599-57L00	SEAL, PROTECTOR	1	

FIG.350B




FIG.350B (1-E-10) WIRING HARNESS (DL1000AL8 E28)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	36610-31JN0	HARNESS, WIRING NO.1	1	
2	09481-03501	.FUSE (3A)	1	
3	09481-10504	.FUSE (10A)	2	
4	09481-15504	.FUSE (15A)	5	
5	09481-25504	.FUSE (25A)	1	
6	38860-76F01	.RELAY ASSY	1	FOR FUEL PUMP
7	38860-76F01	.RELAY ASSY	1	FOR FAN MOTOR
8	38860-76F01	.RELAY ASSY	1	FOR SIDE STAND
9	36620-31J10	HARNESS, WIRING NO.2	1	
10	36618-41G00	.COVER, SPEEDOMETER	1	
11	36618-18G10	.COVER, SPEEDOMETER	1	
12	09407-14407	CLAMP (L:145)	3	
13	09407-17403	CLAMP (L:154)	1	
14	09407-14403	CLAMP (L:125)	3	
15	37740-31D00	SWITCH ASSY, STOP LAMP	1	
16	43259-31J00	SPRING, STOP LAMP	1	
17	37840-24F00	SWITCH ASSY, SIDE STAND	1	
18	09103-08357	BOLT (8X35)	1	
19	38500-41F50	HORN ASSY	1	
20	01550-0612A	BOLT	1	
21	36654-06J20	CAP, TS	1	
22	09404-06429	CLAMP (L:45)	1	
23	36851-31J10	WIRE, OIL PRESSURE SWITCH LEAD	1	
24	36618-31J00	.CAP, OIL PRESSURE SWITCH	1	
25	36856-31J10	WIRE, REAR TURN SIGNAL LEAD	1	
26	36854-31J20	WIRE, IGNITION COIL LEAD	1	
27	09404-06429	CLAMP (L:45)	1	
28	38850-31J00	TERMINAL, POWER SOURCE	1	
29	48599-57L00	SEAL, PROTECTOR	1	

FIG.350C




FIG.350C (1-E-11) WIRING HARNESS (DL1000AL8 E33)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	36610-31JP0	HARNESS, WIRING NO.1	1	
2	09481-03501	.FUSE (3A)	1	
3	09481-10504	.FUSE (10A)	2	
4	09481-15504	.FUSE (15A)	5	
5	09481-25504	.FUSE (25A)	1	
6	38860-76F01	.RELAY ASSY	1	FOR FUEL PUMP
7	38860-76F01	.RELAY ASSY	1	FOR FAN MOTOR
8	38860-76F01	.RELAY ASSY	1	FOR SIDE STAND
9	36620-31J10	HARNESS, WIRING NO.2	1	
10	36618-41G00	.COVER, SPEEDOMETER	1	
11	36618-18G10	.COVER, SPEEDOMETER	1	
12	09407-14407	CLAMP (L:145)	3	
13	09407-17403	CLAMP (L:154)	1	
14	09407-14403	CLAMP (L:125)	3	
15	37740-31D00	SWITCH ASSY, STOP LAMP	1	
16	43259-31J00	SPRING, STOP LAMP	1	
17	37840-24F00	SWITCH ASSY, SIDE STAND	1	
18	09103-08357	BOLT (8X35)	1	
19	38500-41F50	HORN ASSY	1	
20	01550-0612A	BOLT	1	
21	36654-06J20	CAP, TS	1	
22	09404-06429	CLAMP (L:45)	1	
23	36851-31J10	WIRE, OIL PRESSURE SWITCH LEAD	1	
24	36618-31J00	.CAP, OIL PRESSURE SWITCH	1	
25	36856-31J10	WIRE, REAR TURN SIGNAL LEAD	1	
26	36854-31J20	WIRE, IGNITION COIL LEAD	1	
27	09404-06429	CLAMP (L:45)	1	
28	38850-31J00	TERMINAL, POWER SOURCE	1	
29	48599-57L00	SEAL, PROTECTOR	1	

FIG.350D




FIG.350D (1-E-12) WIRING HARNESS (DL1000XAL8 E03)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	36610-31JN0	HARNESS, WIRING NO.1	1	
2	09481-03501	.FUSE (3A)	1	
3	09481-10504	.FUSE (10A)	2	
4	09481-15504	.FUSE (15A)	5	
5	09481-25504	.FUSE (25A)	1	
6	38860-76F01	.RELAY ASSY	1	FOR FUEL PUMP
7	38860-76F01	.RELAY ASSY	1	FOR FAN MOTOR
8	38860-76F01	.RELAY ASSY	1	FOR SIDE STAND
9	36620-31J10	HARNESS, WIRING NO.2	1	
10	36618-41G00	.COVER, SPEEDOMETER	1	
11	36618-18G10	.COVER, SPEEDOMETER	1	
12	09407-14407	CLAMP (L:145)	3	
13	09407-17403	CLAMP (L:154)	1	
14	09407-14403	CLAMP (L:125)	3	
15	37740-31D00	SWITCH ASSY, STOP LAMP	1	
16	43259-31J00	SPRING, STOP LAMP	1	
17	37840-24F00	SWITCH ASSY, SIDE STAND	1	
18	09103-08357	BOLT (8X35)	1	
19	38500-41F50	HORN ASSY	1	
20	01550-0612A	BOLT	1	
21	36654-06J20	CAP, TS	1	
22	09404-06429	CLAMP (L:45)	1	
23	36851-31J10	WIRE, OIL PRESSURE SWITCH LEAD	1	
24	36618-31J00	.CAP, OIL PRESSURE SWITCH	1	
25	36856-31J10	WIRE, REAR TURN SIGNAL LEAD	1	
26	36854-31J20	WIRE, IGNITION COIL LEAD	1	
27	09404-06429	CLAMP (L:45)	1	
28	38850-31J00	TERMINAL, POWER SOURCE	1	
29	48599-57L00	SEAL, PROTECTOR	1	

FIG.350E




FIG.350E (1-E-13) WIRING HARNESS (DL1000XAL8 E28)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	36610-31JN0	HARNESS, WIRING NO.1	1	
2	09481-03501	.FUSE (3A)	1	
3	09481-10504	.FUSE (10A)	2	
4	09481-15504	.FUSE (15A)	5	
5	09481-25504	.FUSE (25A)	1	
6	38860-76F01	.RELAY ASSY	1	FOR FUEL PUMP
7	38860-76F01	.RELAY ASSY	1	FOR FAN MOTOR
8	38860-76F01	.RELAY ASSY	1	FOR SIDE STAND
9	36620-31J10	HARNESS, WIRING NO.2	1	
10	36618-41G00	.COVER, SPEEDOMETER	1	
11	36618-18G10	.COVER, SPEEDOMETER	1	
12	09407-14407	CLAMP (L:145)	3	
13	09407-17403	CLAMP (L:154)	1	
14	09407-14403	CLAMP (L:125)	3	
15	37740-31D00	SWITCH ASSY, STOP LAMP	1	
16	43259-31J00	SPRING, STOP LAMP	1	
17	37840-24F00	SWITCH ASSY, SIDE STAND	1	
18	09103-08357	BOLT (8X35)	1	
19	38500-41F50	HORN ASSY	1	
20	01550-0612A	BOLT	1	
21	36654-06J20	CAP, TS	1	
22	09404-06429	CLAMP (L:45)	1	
23	36851-31J10	WIRE, OIL PRESSURE SWITCH LEAD	1	
24	36618-31J00	.CAP, OIL PRESSURE SWITCH	1	
25	36856-31J10	WIRE, REAR TURN SIGNAL LEAD	1	
26	36854-31J20	WIRE, IGNITION COIL LEAD	1	
27	09404-06429	CLAMP (L:45)	1	
28	38850-31J00	TERMINAL, POWER SOURCE	1	
29	48599-57L00	SEAL, PROTECTOR	1	

FIG.350F




FIG.350F (1-E-14) WIRING HARNESS (DL1000XAL8 E33)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	36610-31JP0	HARNESS, WIRING NO.1	1	
2	09481-03501	.FUSE (3A)	1	
3	09481-10504	.FUSE (10A)	2	
4	09481-15504	.FUSE (15A)	5	
5	09481-25504	.FUSE (25A)	1	
6	38860-76F01	.RELAY ASSY	1	FOR FUEL PUMP
7	38860-76F01	.RELAY ASSY	1	FOR FAN MOTOR
8	38860-76F01	.RELAY ASSY	1	FOR SIDE STAND
9	36620-31J10	HARNESS, WIRING NO.2	1	
10	36618-41G00	.COVER, SPEEDOMETER	1	
11	36618-18G10	.COVER, SPEEDOMETER	1	
12	09407-14407	CLAMP (L:145)	3	
13	09407-17403	CLAMP (L:154)	1	
14	09407-14403	CLAMP (L:125)	3	
15	37740-31D00	SWITCH ASSY, STOP LAMP	1	
16	43259-31J00	SPRING, STOP LAMP	1	
17	37840-24F00	SWITCH ASSY, SIDE STAND	1	
18	09103-08357	BOLT (8X35)	1	
19	38500-41F50	HORN ASSY	1	
20	01550-0612A	BOLT	1	
21	36654-06J20	CAP, TS	1	
22	09404-06429	CLAMP (L:45)	1	
23	36851-31J10	WIRE, OIL PRESSURE SWITCH LEAD	1	
24	36618-31J00	.CAP, OIL PRESSURE SWITCH	1	
25	36856-31J10	WIRE, REAR TURN SIGNAL LEAD	1	
26	36854-31J20	WIRE, IGNITION COIL LEAD	1	
27	09404-06429	CLAMP (L:45)	1	
28	38850-31J00	TERMINAL, POWER SOURCE	1	
29	48599-57L00	SEAL, PROTECTOR	1	

FIG.352A




FIG.352A (1-E-15) LOCK SET

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	37102-31860	LOCK SET	1	
2	37100-31JE0	.LOCK ASSY, STEERING	1	
3	09139-08016	BOLT (8X20)	2	
4	37180-15H01	COVER, STEERING LOCK	1	
5	09407-14407	CLAMP (L:145)	3	
6	01547-0512B	BOLT	2	
7	37146-13K00	KEY, BLANK	1	OPT

FIG.352B (1-F-2) LOCK SET (FOR TOP CASE,SIDE CASE)



DL1000AL8_E03_E28_352B
LOCK SET

FIG.355A




FIG.355A (1-F-3) HANDLE SWITCH

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	37200-31J10	SWITCH ASSY, HANDLE RH	1	
2	02112-0545B	.SCREW	2	
3	37400-31J10	SWITCH ASSY, HANDLE LH	1	
4	02112-0525B	.SCREW	2	
5	09407-14407	CLAMP (L:145)	4	

FIG.401A





FIG.401A (1-F-4) FRAME

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	41100-31J10-YAP	FRAME (BLACK)	1	
2	41200-31J20-YAP	RAIL, SEAT (BLACK)	1	
3	09139-10003	BOLT (10X25)	4	
4	43580-31J00	COVER, PIVOT, RH	1	
5	33652-38A10	.CUSHION, PIVOT COVER NO.3	1	
6	63115-37H00	.CUSHION, PIVOT COVER NO.1	1	
7	94429-21E00	.CUSHION, PIVOT COVER NO.2	1	
8	43590-31J00	COVER, PIVOT LH	1	
9	33652-38A10	.CUSHION, PIVOT COVER NO.3	1	
10	63115-37H00	.CUSHION, PIVOT COVER NO.1	1	
11	94429-21E00	.CUSHION, PIVOT COVER NO.2	1	
12	09139-05074	BOLT (5X13)	4	
13	41922-19F20	NUT, ADJUSTER CENTER	1	
14	41921-16G00	BOLT, ADJUSTER LOWER	1	
15	41922-33E20	NUT, ADJUSTER LOWER	1	
16	41941-19F01	SPACER, ADJUSTER UPPER	1	
17	41921-47H00	BOLT, CRANK CASE ADJUST	1	
18	41942-02F00	SPACER, ENG HEAD MTG RR LH	1	
19	07130-0840B	BOLT	1	
20	07130-0840B	BOLT	1	

FIG.406A



DL1000AL8_E03_E28_406A
HOLDER

FIG.406A (1-F-5) HOLDER

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	47414-31J10	HOLDER, BATTERY	1	
2	47420-31J00	COVER, ACTUATOR	1	
3	47423-31J00	.CUSHION, ACTUATOR COVER	1	
4	47431-31J10	LID, BATTERY HOLDER	1	
5	09139-05092	SCREW	3	
6	09139-06144	SCREW (6X12)	4	
7	09148-05052	NUT	1	
8	09169-06082	WASHER	2	
9	47422-31J00	MUDGUARD, ACTUATOR COVER	1	

DL1000AL8_E03_E28

FIG.407A




FIG.407A (1-F-6) STAND

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	42310-31J11	STAND, PROP	1	
2	09111-10058	BOLT (10X37.5)	1	
3	42321-03FK0	NUT	1	
4	09443-14058	SPRING	1	NO.1
5	09443-19011	SPRING	1	NO.2
6	42330-31J00	BRACKET, PROP STAND	1	
7	01550-1235A	BOLT	2	
8	43111-31J00	PEDAL, BRAKE	1	
9	09160-18022	WASHER (18X24X1)	1	
10	09448-41005	SPRING	1	
11	08331-3118A	CIRCLIP	1	
12	43251-31J00	BRACKET, STOP SWITCH	1	
13	01550-0612A	BOLT	1	

FIG.412A




FIG.412A (1-F-7) CARRIER (DL1000AL8 E03)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	46311-31J01	CARRIER, SPORT	1	
2	09103-08512	BOLT (8X35)	4	
3	68391-06G80	LABEL, WARNING LUGGAGE CARRIER	1	
4	09169-08049	WASHER	4	



FIG.412B




FIG.412B (1-F-8) CARRIER (DL1000AL8 E28)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	46311-31J01	CARRIER, SPORT	1	
2	09103-08512	BOLT (8X35)	4	
3	68391-06G90	LABEL, WARNING LUGGAGE CARRIER	1	
4	09169-08049	WASHER	4	



FIG.412C




FIG.412C (1-F-9) CARRIER (DL1000AL8 E33)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	46311-31J01	CARRIER, SPORT	1	
2	09103-08512	BOLT (8X35)	4	
3	68391-06G80	LABEL, WARNING LUGGAGE CARRIER	1	
4	09169-08049	WASHER	4	



FIG.412D




FIG.412D (1-F-10) CARRIER (DL1000XAL8 E03)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	46311-31J01	CARRIER, SPORT	1	
2	09103-08512	BOLT (8X35)	4	
3	68391-06G80	LABEL, WARNING LUGGAGE CARRIER	1	
4	09169-08049	WASHER	4	



FIG.412E




FIG.412E (1-F-11) CARRIER (DL1000XAL8 E28)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	46311-31J01	CARRIER, SPORT	1	
2	09103-08512	BOLT (8X35)	4	
3	68391-06G90	LABEL, WARNING LUGGAGE CARRIER	1	
4	09169-08049	WASHER	4	

FIG.412F




FIG.412F (1-F-12) CARRIER (DL1000XAL8 E33)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	46311-31J01	CARRIER, SPORT	1	
2	09103-08512	BOLT (8X35)	4	
3	68391-06G80	LABEL, WARNING LUGGAGE CARRIER	1	
4	09169-08049	WASHER	4	



FIG.415A




FIG.415A (1-F-13) FOOTREST

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	43510-06G01-YAP	BRACKET, FRONT RH (BLACK)	1	
2	43521-06G01-YAP	BRACKET, FRONT LH (BLACK)	1	
3	09106-08150	BOLT (8X23)	4	
4	43501-31J00	FOOTREST ASSY, FRONT RH	1	
5	43576-31J00	.SENSOR, FOOTREST	1	
6	43551-06G00	.RUBBER	1	
7	43552-06G00	.PLATE	1	
8	02142-0516A	.SCREW	1	OUTER
9	02142-0520A	.SCREW	1	INNER
10	43502-31J00	FOOTREST ASSY, FRONT LH	1	
11	43576-31J00	.SENSOR, FOOTREST	1	
12	43551-06G00	.RUBBER	1	
13	43552-06G00	.PLATE	1	
14	02142-0516A	.SCREW	1	OUTER
15	02142-0520A	.SCREW	1	INNER
16	09208-08019	PIN	2	
17	09448-18022	SPRING	2	
18	08332-1106A	E RING	2	
19	43610-34A30	BAR, PILLION FOOTREST, RH	1	
20	43612-33G01	RUBBER	1	
21	43631-31J00	WASHER, FOOTREST RUBBER	1	
22	43710-34A30	BAR, PILLION FOOTREST, LH	1	
23	43612-33G01	RUBBER	1	
24	43631-31J00	WASHER, FOOTREST RUBBER	1	
25	43811-31J00-YAP	BRACKET, PILLION RH (BLACK)	1	
26	43821-31J00-YAP	BRACKET, PILLION LH (BLACK)	1	
27	09106-08131	BOLT (8X30)	4	
28	09208-06007	PIN	2	
29	08332-1104A	E RING	2	

FIG.420A




FIG.420A (1-F-14) FUEL TANK (DL1000AL8 E03) (FOR YU1)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	44100-31JA0-YU1	TANK, FUEL (YELLOW)	1	
2	68110-31J00-GY8	.TAPE SET, FUEL TANK (YELLOW/BLACK)	1	
3	44200-17820	CAP SET, FUEL TANK	1	
4	44244-11J00	BOLT	3	
5	44541-31J00	CUSHION, SIDE	2	
6	44550-31J00	BRACKET, REAR LOWER	1	
7	01550-0816A	BOLT	2	
8	44545-06G00	CUSHION, LOWER	1	
9	44542-06G00	CUSHION, UPPER	1	
10	44530-06G00	BRACKET, UPPER	1	
11	01550-0835A	BOLT	1	
12	44423-31J20	HOSE, WATER DRAIN	1	
13	44424-31J20	HOSE, FUEL TANK BRTHR NO.1	1	
14	44424-15H10	HOSE, TANK BREATHER NO.2	1	
15	09367-06007	3 WAY	1	
16	44424-31J10	HOSE, FUEL TANK BRTHR NO.2	1	
17	09352-13162-010	HOSE (13.5X16.5X10)	1	
18	68241-31J00	MOLDING, FUEL TANK COVER	1	
19	44179-31J00	BRACKET, FUEL TANK COVER SIDE RH	1	
20	44189-31J00	BRACKET, FUEL TANK COVER SIDE LH	1	
21	09139-06181	SCREW (6X10)	4	
22	44523-47H00	NUT (M6)	4	
23	44542-31J00	CUSHION, FUEL TANK COVER BRKT	2	
24	44276-21H00	CUSHION, FUEL TANK COVER	2	
25	44552-24B00	MOLDING, FUEL TANK REAR	2	
26	07130-1016B	BOLT	2	
27	44544-31J00	CUSHION, FUEL TANK	2	
28	44480-31J00	GUIDE, DRAIN HOSE	1	

FIG.420A




FIG.420A (1-F-15) FUEL TANK (DL1000AL8 E03) (FOR YU1)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
29	44423-31J11	HOSE, FUEL TANK DRAIN NO.2	1	
30	09367-08005	3 WAY	1	
31	09407-14407	CLAMP (L:145)	1	
32	44545-31J00	CUSHION	1	

FIG.420B




FIG.420B (1-G-2) FUEL TANK (DL1000AL8 E03) (FOR YVB,YWW)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	44100-31J30-YVB	TANK, FUEL (BLACK)	1	
1-2	44100-31J30-YVWW	TANK, FUEL (WHITE)	1	
2	44200-17820	CAP SET, FUEL TANK	1	
3	44244-11J00	BOLT	3	
4	44541-31J00	CUSHION, SIDE	2	
5	44550-31J00	BRACKET, REAR LOWER	1	
6	01550-0816A	BOLT	2	
7	44545-06G00	CUSHION, LOWER	1	
8	44542-06G00	CUSHION, UPPER	1	
9	44530-06G00	BRACKET, UPPER	1	
10	01550-0835A	BOLT	1	
11	44423-31J20	HOSE, WATER DRAIN	1	
12	44424-31J20	HOSE, FUEL TANK BRTHR NO.1	1	
13	44424-15H10	HOSE, TANK BREATHER NO.2	1	
14	09367-06007	3 WAY	1	
15	44424-31J10	HOSE, FUEL TANK BRTHR NO.2	1	
16	09352-13162-010	HOSE (13.5X16.5X10)	1	
17	68241-31J00	MOLDING, FUEL TANK COVER	1	
18	44179-31J00	BRACKET, FUEL TANK COVER SIDE RH	1	
19	44189-31J00	BRACKET, FUEL TANK COVER SIDE LH	1	
20	09139-06181	SCREW (6X10)	4	
21	44523-47H00	NUT (M6)	4	
22	44542-31J00	CUSHION, FUEL TANK COVER BRKT	2	
23	44276-21H00	CUSHION, FUEL TANK COVER	2	
24	44552-24B00	MOLDING, FUEL TANK REAR	2	
25	07130-1016B	BOLT	2	
26	44544-31J00	CUSHION, FUEL TANK	2	
27	44480-31J00	GUIDE, DRAIN HOSE	1	

FIG.420B




FIG.420B (1-G-3) FUEL TANK (DL1000AL8 E03) (FOR YVB,YWW)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
28	44423-31J11	HOSE, FUEL TANK DRAIN NO.2	1	
29	09367-08005	3 WAY	1	
30	09407-14407	CLAMP (L:145)	1	
31	44545-31J00	CUSHION	1	

FIG.420C




FIG.420C (1-G-4) FUEL TANK (DL1000AL8 E28) (FOR YU1)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	44100-31JA0-YU1	TANK, FUEL (YELLOW)	1	
2	68110-31J00-GY8	.TAPE SET, FUEL TANK (YELLOW/BLACK)	1	
3	44200-17820	CAP SET, FUEL TANK	1	
4	44244-11J00	BOLT	3	
5	44541-31J00	CUSHION, SIDE	2	
6	44550-31J00	BRACKET, REAR LOWER	1	
7	01550-0816A	BOLT	2	
8	44545-06G00	CUSHION, LOWER	1	
9	44542-06G00	CUSHION, UPPER	1	
10	44530-06G00	BRACKET, UPPER	1	
11	01550-0835A	BOLT	1	
12	44423-31J20	HOSE, WATER DRAIN	1	
13	44424-31J20	HOSE, FUEL TANK BRTHR NO.1	1	
14	44424-15H10	HOSE, TANK BREATHER NO.2	1	
15	09367-06007	3 WAY	1	
16	44424-31J10	HOSE, FUEL TANK BRTHR NO.2	1	
17	09352-13162-010	HOSE (13.5X16.5X10)	1	
18	68241-31J00	MOLDING, FUEL TANK COVER	1	
19	44179-31J00	BRACKET, FUEL TANK COVER SIDE RH	1	
20	44189-31J00	BRACKET, FUEL TANK COVER SIDE LH	1	
21	09139-06181	SCREW (6X10)	4	
22	44523-47H00	NUT (M6)	4	
23	44542-31J00	CUSHION, FUEL TANK COVER BRKT	2	
24	44276-21H00	CUSHION, FUEL TANK COVER	2	
25	44552-24B00	MOLDING, FUEL TANK REAR	2	
26	07130-1016B	BOLT	2	
27	44544-31J00	CUSHION, FUEL TANK	2	
28	44480-31J00	GUIDE, DRAIN HOSE	1	

FIG.420C




FIG.420C (1-G-5) FUEL TANK (DL1000AL8 E28) (FOR YU1)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
29	44423-31J11	HOSE, FUEL TANK DRAIN NO.2	1	
30	09367-08005	3 WAY	1	
31	09407-14407	CLAMP (L:145)	1	
32	44545-31J00	CUSHION	1	

FIG.420D




FIG.420D (1-G-6) FUEL TANK (DL1000AL8 E28) (FOR YVB,YWW)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	44100-31J30-YVB	TANK, FUEL (BLACK)	1	
1-2	44100-31J30-YVWW	TANK, FUEL (WHITE)	1	
2	44200-17820	CAP SET, FUEL TANK	1	
3	44244-11J00	BOLT	3	
4	44541-31J00	CUSHION, SIDE	2	
5	44550-31J00	BRACKET, REAR LOWER	1	
6	01550-0816A	BOLT	2	
7	44545-06G00	CUSHION, LOWER	1	
8	44542-06G00	CUSHION, UPPER	1	
9	44530-06G00	BRACKET, UPPER	1	
10	01550-0835A	BOLT	1	
11	44423-31J20	HOSE, WATER DRAIN	1	
12	44424-31J20	HOSE, FUEL TANK BRTHR NO.1	1	
13	44424-15H10	HOSE, TANK BREATHER NO.2	1	
14	09367-06007	3 WAY	1	
15	44424-31J10	HOSE, FUEL TANK BRTHR NO.2	1	
16	09352-13162-010	HOSE (13.5X16.5X10)	1	
17	68241-31J00	MOLDING, FUEL TANK COVER	1	
18	44179-31J00	BRACKET, FUEL TANK COVER SIDE RH	1	
19	44189-31J00	BRACKET, FUEL TANK COVER SIDE LH	1	
20	09139-06181	SCREW (6X10)	4	
21	44523-47H00	NUT (M6)	4	
22	44542-31J00	CUSHION, FUEL TANK COVER BRKT	2	
23	44276-21H00	CUSHION, FUEL TANK COVER	2	
24	44552-24B00	MOLDING, FUEL TANK REAR	2	
25	07130-1016B	BOLT	2	
26	44544-31J00	CUSHION, FUEL TANK	2	
27	44480-31J00	GUIDE, DRAIN HOSE	1	

FIG.420D




FIG.420D (1-G-7) FUEL TANK (DL1000AL8 E28) (FOR YVB,YWW)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
28	44423-31J11	HOSE, FUEL TANK DRAIN NO.2	1	
29	09367-08005	3 WAY	1	
30	09407-14407	CLAMP (L:145)	1	
31	44545-31J00	CUSHION	1	

FIG.420E




FIG.420E (1-G-8) FUEL TANK (DL1000AL8 E33) (FOR YU1)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	44100-31JA0-YU1	TANK, FUEL (YELLOW)	1	
2	68110-31J00-GY8	.TAPE SET, FUEL TANK (YELLOW/BLACK)	1	
3	44200-17820	CAP SET, FUEL TANK	1	
4	44244-11J00	BOLT	3	
5	44541-31J00	CUSHION, SIDE	2	
6	44550-31J00	BRACKET, REAR LOWER	1	
7	01550-0816A	BOLT	2	
8	44545-06G00	CUSHION, LOWER	1	
9	44542-06G00	CUSHION, UPPER	1	
10	44530-06G00	BRACKET, UPPER	1	
11	01550-0835A	BOLT	1	
12	44423-31J20	HOSE, WATER DRAIN	1	
13	68241-31J00	MOLDING, FUEL TANK COVER	1	
14	44179-31J00	BRACKET, FUEL TANK COVER SIDE RH	1	
15	44189-31J00	BRACKET, FUEL TANK COVER SIDE LH	1	
16	09139-06181	SCREW (6X10)	4	
17	44523-47H00	NUT (M6)	4	
18	44542-31J00	CUSHION, FUEL TANK COVER BRKT	2	
19	44276-21H00	CUSHION, FUEL TANK COVER	2	
20	44552-24B00	MOLDING, FUEL TANK REAR	2	
21	07130-1016B	BOLT	2	
22	44544-31J00	CUSHION, FUEL TANK	2	
23	44480-31J00	GUIDE, DRAIN HOSE	1	
24	44423-31J11	HOSE, FUEL TANK DRAIN NO.2	1	
25	09367-08005	3 WAY	1	
26	44545-31J00	CUSHION	1	

FIG.420F




FIG.420F (1-G-9) FUEL TANK (DL1000AL8 E33) (FOR YVB,YVW)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	44100-31J30-YVB	TANK, FUEL (BLACK)	1	
1-2	44100-31J30-YVW	TANK, FUEL (WHITE)	1	
2	44200-17820	CAP SET, FUEL TANK	1	
3	44244-11J00	BOLT	3	
4	44541-31J00	CUSHION, SIDE	2	
5	44550-31J00	BRACKET, REAR LOWER	1	
6	01550-0816A	BOLT	2	
7	44545-06G00	CUSHION, LOWER	1	
8	44542-06G00	CUSHION, UPPER	1	
9	44530-06G00	BRACKET, UPPER	1	
10	01550-0835A	BOLT	1	
11	44423-31J20	HOSE, WATER DRAIN	1	
12	68241-31J00	MOLDING, FUEL TANK COVER	1	
13	44179-31J00	BRACKET, FUEL TANK COVER SIDE RH	1	
14	44189-31J00	BRACKET, FUEL TANK COVER SIDE LH	1	
15	09139-06181	SCREW (6X10)	4	
16	44523-47H00	NUT (M6)	4	
17	44542-31J00	CUSHION, FUEL TANK COVER BRKT	2	
18	44276-21H00	CUSHION, FUEL TANK COVER	2	
19	44552-24B00	MOLDING, FUEL TANK REAR	2	
20	07130-1016B	BOLT	2	
21	44544-31J00	CUSHION, FUEL TANK	2	
22	44480-31J00	GUIDE, DRAIN HOSE	1	
23	44423-31J11	HOSE, FUEL TANK DRAIN NO.2	1	
24	09367-08005	3 WAY	1	
25	44545-31J00	CUSHION	1	

FIG.420G





FIG.420G (1-G-10) FUEL TANK (DL1000XAL8 E03)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	44100-31JA0-YU1	TANK, FUEL (YELLOW)	1	
1-2	44100-31JA0-YVB	TANK, FUEL (BLACK)	1	
1-3	44100-31JA0-YWW	TANK, FUEL (WHITE)	1	
2-1	68110-31J00-GY8	.TAPE SET, FUEL TANK (YELLOW/BLACK)	1	FOR YU1
2-2	68110-31J00-AA3	.TAPE SET, FUEL TANK (GRAY/BLACK)	1	FOR YVB
2-3	68110-31J00-BGZ	.TAPE SET, FUEL TANK (GRAY/WHITE)	1	FOR YWW
3	44200-17820	CAP SET, FUEL TANK	1	
4	44244-11J00	BOLT	3	
5	44541-31J00	CUSHION, SIDE	2	
6	44550-31J00	BRACKET, REAR LOWER	1	
7	01550-0816A	BOLT	2	
8	44545-06G00	CUSHION, LOWER	1	
9	44542-06G00	CUSHION, UPPER	1	
10	44530-06G00	BRACKET, UPPER	1	
11	01550-0835A	BOLT	1	
12	44423-31J20	HOSE, WATER DRAIN	1	
13	44424-31J20	HOSE, FUEL TANK BRTHR NO.1	1	
14	44424-15H10	HOSE, TANK BATHER NO.2	1	
15	09367-06007	3 WAY	1	
16	44424-31J10	HOSE, FUEL TANK BRTHR NO.2	1	
17	09352-13162-010	HOSE (13.5X16.5X10)	1	
18	68241-31J00	MOLDING, FUEL TANK COVER	1	
19	44179-31J00	BRACKET, FUEL TANK COVER SIDE RH	1	
20	44189-31J00	BRACKET, FUEL TANK COVER SIDE LH	1	
21	09139-06181	SCREW (6X10)	4	
22	44523-47H00	NUT (M6)	4	
23	44542-31J00	CUSHION, FUEL TANK COVER BRKT	2	
24	44276-21H00	CUSHION, FUEL TANK COVER	2	
25	44552-24B00	MOLDING, FUEL TANK REAR	2	
26	07130-1016B	BOLT	2	
27	44544-31J00	CUSHION, FUEL TANK	2	



DL1000AL8_E03_E28

1000AL8_E03_E28

FIG.420H





FIG.420H (1-G-12) FUEL TANK (DL1000XAL8 E28)


REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	44100-31JA0-YU1	TANK, FUEL (YELLOW)	1	
1-2	44100-31JA0-YVB	TANK, FUEL (BLACK)	1	
1-3	44100-31JA0-YWW	TANK, FUEL (WHITE)	1	
2-1	68110-31J00-GY8	.TAPE SET, FUEL TANK (YELLOW/BLACK)	1	FOR YU1
2-2	68110-31J00-AA3	.TAPE SET, FUEL TANK (GRAY/BLACK)	1	FOR YVB
2-3	68110-31J00-BGZ	.TAPE SET, FUEL TANK (GRAY/WHITE)	1	FOR YWW
3	44200-17820	CAP SET, FUEL TANK	1	
4	44244-11J00	BOLT	3	
5	44541-31J00	CUSHION, SIDE	2	
6	44550-31J00	BRACKET, REAR LOWER	1	
7	01550-0816A	BOLT	2	
8	44545-06G00	CUSHION, LOWER	1	
9	44542-06G00	CUSHION, UPPER	1	
10	44530-06G00	BRACKET, UPPER	1	
11	01550-0835A	BOLT	1	
12	44423-31J20	HOSE, WATER DRAIN	1	
13	44424-31J20	HOSE, FUEL TANK BRTHR NO.1	1	
14	44424-15H10	HOSE, TANK BREATHER NO.2	1	
15	09367-06007	3 WAY	1	
16	44424-31J10	HOSE, FUEL TANK BRTHR NO.2	1	
17	09352-13162-010	HOSE (13.5X16.5X10)	1	
18	68241-31J00	MOLDING, FUEL TANK COVER	1	
19	44179-31J00	BRACKET, FUEL TANK COVER SIDE RH	1	
20	44189-31J00	BRACKET, FUEL TANK COVER SIDE LH	1	
21	09139-06181	SCREW (6X10)	4	
22	44523-47H00	NUT (M6)	4	
23	44542-31J00	CUSHION, FUEL TANK COVER BRKT	2	
24	44276-21H00	CUSHION, FUEL TANK COVER	2	
25	44552-24B00	MOLDING, FUEL TANK REAR	2	
26	07130-1016B	BOLT	2	
27	44544-31J00	CUSHION, FUEL TANK	2	



DL1000AL8_E03_E28

REF NO.	PART NO.	DESCRIPTION	QTY	REMARKS
28	44480-31J00	GUIDE, DRAIN HOSE	1	
29	44423-31J11	HOSE, FUEL TANK DRAIN NO.2	1	
30	09367-08005	3 WAY	1	
31	09407-14407	CLAMP (L:145)	1	
32	44545-31J00	CUSHION	1	

FIG.420J



DL1000AL8_E03_E28_420J
FUEL TANK

FIG.420J (1-G-14) FUEL TANK (DL1000XAL8 E33)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	44100-31JA0-YU1	TANK, FUEL (YELLOW)	1	
1-2	44100-31JA0-YVB	TANK, FUEL (BLACK)	1	
1-3	44100-31JA0-YWW	TANK, FUEL (WHITE)	1	
2-1	68110-31J00-GY8	.TAPE SET, FUEL TANK (YELLOW/BLACK)	1	FOR YU1
2-2	68110-31J00-AA3	.TAPE SET, FUEL TANK (GRAY/BLACK)	1	FOR YVB
2-3	68110-31J00-BGZ	.TAPE SET, FUEL TANK (GRAY/WHITE)	1	FOR YWW
3	44200-17820	CAP SET, FUEL TANK	1	
4	44244-11J00	BOLT	3	
5	44541-31J00	CUSHION, SIDE	2	
6	44550-31J00	BRACKET, REAR LOWER	1	
7	01550-0816A	BOLT	2	
8	44545-06G00	CUSHION, LOWER	1	
9	44542-06G00	CUSHION, UPPER	1	
10	44530-06G00	BRACKET, UPPER	1	
11	01550-0835A	BOLT	1	
12	44423-31J20	HOSE, WATER DRAIN	1	
13	68241-31J00	MOLDING, FUEL TANK COVER	1	
14	44179-31J00	BRACKET, FUEL TANK COVER SIDE RH	1	
15	44189-31J00	BRACKET, FUEL TANK COVER SIDE LH	1	
16	09139-06181	SCREW (6X10)	4	
17	44523-47H00	NUT (M6)	4	
18	44542-31J00	CUSHION, FUEL TANK COVER BRKT	2	
19	44276-21H00	CUSHION, FUEL TANK COVER	2	
20	44552-24B00	MOLDING, FUEL TANK REAR	2	
21	07130-1016B	BOLT	2	
22	44544-31J00	CUSHION, FUEL TANK	2	
23	44480-31J00	GUIDE, DRAIN HOSE	1	
24	44423-31J11	HOSE, FUEL TANK DRAIN NO.2	1	
25	09367-08005	3 WAY	1	
26	44545-31J00	CUSHION	1	

DL1000AL8_E03_E28

FIG.423A




FIG.423A (1-G-15) FUEL TANK COVER (DL1000AL8 E03) (FOR YU1)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	44191-31J00-YKV	COVER, FUEL TANK CENTER (BLACK)	1	
2	44170-31J10-YKV	COVER, FUEL TANK SIDE RH (BLACK)	1	
3	68125-31J00-BHA	.TAPE, FUEL TANK COVER RH	1	
4	44180-31J10-YKV	COVER, FUEL TANK SIDE LH (BLACK)	1	
5	68135-31J00-BHA	.TAPE, FUEL TANK COVER LH	1	
6	44270-31J00	COVER, FUEL TANK FRONT RH	1	
7	45517-31J00	.TAPE, FUEL TANK COVER	1	
8	44280-31J00	COVER, FUEL TANK FRONT LH	1	
9	45517-31J00	.TAPE, FUEL TANK COVER	1	
10	44612-13600	CUSHION, TANK COVER SIDE NO.4	2	CUT AS REQUIRED
11	44277-01H00	CUSHION, FUEL TANK COVER	2	
12	94642-10GA0	CUSHION, FUEL TANK COVER NO.2	2	
13	44176-31J00	CUSHION, TANK COVER SIDE NO.1	2	
14	44177-31J00	CUSHION, TANK COVER SIDE NO.2	2	
15	44178-31J00	CUSHION, TANK COVER SIDE NO.3	2	
16	09139-06172	BOLT (6X10)	3	
17	09139-05074	BOLT (5X13)	4	
18	09148-05052	NUT	2	
19	03241-0516B	SCREW	6	

FIG.423A




FIG.423A (1-H-2) FUEL TANK COVER (DL1000AL8 E03) (FOR YU1)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
20	68281-47HA0	EMBLEM, "S"	1	
21	09409-08326	CLIP	2	
22	68111-47HA0	EMBLEM, "S"	2	
23	09409-06314	CLIP	4	
24	44552-24B00	MOLDING, FUEL TANK	2	
25	45289-05H00	CUSHION	1	

FIG.423B




FIG.423B (1-H-3) FUEL TANK COVER (DL1000AL8 E03) (FOR YVB,YWW)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	44191-31J00-PGZ	COVER, FUEL TANK CENTER (GRAY)	1	
2	44170-31J20-PGZ	COVER, FUEL TANK SIDE RH (GRAY)	1	
3	68121-31J00-BG9	.EMBLEM, FUEL TANK COVER RH	1	
4	44180-31J20-PGZ	COVER, FUEL TANK SIDE LH (GRAY)	1	
5	68131-31J00-BG9	.EMBLEM, FUEL TANK COVER LH	1	
6	44270-31J00	COVER, FUEL TANK FRONT RH	1	
7	45517-31J00	.TAPE, FUEL TANK COVER	1	
8	44280-31J00	COVER, FUEL TANK FRONT LH	1	
9	45517-31J00	.TAPE, FUEL TANK COVER	1	
10	44612-13600	CUSHION, TANK COVER SIDE NO.4	2	CUT AS REQUIRED
11	44277-01H00	CUSHION, FUEL TANK COVER	2	
12	94642-10GA0	CUSHION, FUEL TANK COVER NO.2	2	
13	44176-31J00	CUSHION, TANK COVER SIDE NO.1	2	
14	44177-31J00	CUSHION, TANK COVER SIDE NO.2	2	
15	44178-31J00	CUSHION, TANK COVER SIDE NO.3	2	
16	09139-06172	BOLT (6X10)	3	
17	09139-05074	BOLT (5X13)	4	
18	09148-05052	NUT	2	
19	03241-0516B	SCREW	6	

FIG.423B




FIG.423B (1-H-4) FUEL TANK COVER (DL1000AL8 E03) (FOR YVB,YWW)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
20	68281-47HA0	EMBLEM, "S"	1	
21	09409-08326	CLIP	2	
22	68111-47HA0	EMBLEM, "S"	2	
23	09409-06314	CLIP	4	
24	44552-24B00	MOLDING, FUEL TANK	2	
25	45289-05H00	CUSHION	1	

FIG.423C




FIG.423C (1-H-5) FUEL TANK COVER (DL1000AL8 E28) (FOR YU1)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	44191-31J00-YKV	COVER, FUEL TANK CENTER (BLACK)	1	
2	44170-31J10-YKV	COVER, FUEL TANK SIDE RH (BLACK)	1	
3	68125-31J00-BHA	.TAPE, FUEL TANK COVER RH	1	
4	44180-31J10-YKV	COVER, FUEL TANK SIDE LH (BLACK)	1	
5	68135-31J00-BHA	.TAPE, FUEL TANK COVER LH	1	
6	44270-31J00	COVER, FUEL TANK FRONT RH	1	
7	45517-31J00	.TAPE, FUEL TANK COVER	1	
8	44280-31J00	COVER, FUEL TANK FRONT LH	1	
9	45517-31J00	.TAPE, FUEL TANK COVER	1	
10	44612-13600	CUSHION, TANK COVER SIDE NO.4	2	CUT AS REQUIRED
11	44277-01H00	CUSHION, FUEL TANK COVER	2	
12	94642-10GA0	CUSHION, FUEL TANK COVER NO.2	2	
13	44176-31J00	CUSHION, TANK COVER SIDE NO.1	2	
14	44177-31J00	CUSHION, TANK COVER SIDE NO.2	2	
15	44178-31J00	CUSHION, TANK COVER SIDE NO.3	2	
16	09139-06172	BOLT (6X10)	3	
17	09139-05074	BOLT (5X13)	4	
18	09148-05052	NUT	2	
19	03241-0516B	SCREW	6	

FIG.423C




FIG.423C (1-H-6) FUEL TANK COVER (DL1000AL8 E28) (FOR YU1)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
20	68281-47HA0	EMBLEM, "S"	1	
21	09409-08326	CLIP	2	
22	68111-47HA0	EMBLEM, "S"	2	
23	09409-06314	CLIP	4	
24	44552-24B00	MOLDING, FUEL TANK	2	
25	45289-05H00	CUSHION	1	

FIG.423D




FIG.423D (1-H-7) FUEL TANK COVER (DL1000AL8 E28) (FOR YVB,YWW)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	44191-31J00-PGZ	COVER, FUEL TANK CENTER (GRAY)	1	
2	44170-31J20-PGZ	COVER, FUEL TANK SIDE RH (GRAY)	1	
3	68121-31J00-BG9	.EMBLEM, FUEL TANK COVER RH	1	
4	44180-31J20-PGZ	COVER, FUEL TANK SIDE LH (GRAY)	1	
5	68131-31J00-BG9	.EMBLEM, FUEL TANK COVER LH	1	
6	44270-31J00	COVER, FUEL TANK FRONT RH	1	
7	45517-31J00	.TAPE, FUEL TANK COVER	1	
8	44280-31J00	COVER, FUEL TANK FRONT LH	1	
9	45517-31J00	.TAPE, FUEL TANK COVER	1	
10	44612-13600	CUSHION, TANK COVER SIDE NO.4	2	CUT AS REQUIRED
11	44277-01H00	CUSHION, FUEL TANK COVER	2	
12	94642-10GA0	CUSHION, FUEL TANK COVER NO.2	2	
13	44176-31J00	CUSHION, TANK COVER SIDE NO.1	2	
14	44177-31J00	CUSHION, TANK COVER SIDE NO.2	2	
15	44178-31J00	CUSHION, TANK COVER SIDE NO.3	2	
16	09139-06172	BOLT (6X10)	3	
17	09139-05074	BOLT (5X13)	4	
18	09148-05052	NUT	2	
19	03241-0516B	SCREW	6	

FIG.423D




FIG.423D (1-H-8) FUEL TANK COVER (DL1000AL8 E28) (FOR YVB,YWW)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
20	68281-47HA0	EMBLEM, "S"	1	
21	09409-08326	CLIP	2	
22	68111-47HA0	EMBLEM, "S"	2	
23	09409-06314	CLIP	4	
24	44552-24B00	MOLDING, FUEL TANK	2	
25	45289-05H00	CUSHION	1	

FIG.423E




FIG.423E (1-H-9) FUEL TANK COVER (DL1000AL8 E33) (FOR YU1)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	44191-31J00-YKV	COVER, FUEL TANK CENTER (BLACK)	1	
2	44170-31J10-YKV	COVER, FUEL TANK SIDE RH (BLACK)	1	
3	68125-31J00-BHA	.TAPE, FUEL TANK COVER RH	1	
4	44180-31J10-YKV	COVER, FUEL TANK SIDE LH (BLACK)	1	
5	68135-31J00-BHA	.TAPE, FUEL TANK COVER LH	1	
6	44270-31J00	COVER, FUEL TANK FRONT RH	1	
7	45517-31J00	.TAPE, FUEL TANK COVER	1	
8	44280-31J00	COVER, FUEL TANK FRONT LH	1	
9	45517-31J00	.TAPE, FUEL TANK COVER	1	
10	44612-13600	CUSHION, TANK COVER SIDE NO.4	2	CUT AS REQUIRED
11	44277-01H00	CUSHION, FUEL TANK COVER	2	
12	94642-10GA0	CUSHION, FUEL TANK COVER NO.2	2	
13	44176-31J00	CUSHION, TANK COVER SIDE NO.1	2	
14	44177-31J00	CUSHION, TANK COVER SIDE NO.2	2	
15	44178-31J00	CUSHION, TANK COVER SIDE NO.3	2	
16	09139-06172	BOLT (6X10)	3	
17	09139-05074	BOLT (5X13)	4	
18	09148-05052	NUT	2	
19	03241-0516B	SCREW	6	

FIG.423E




FIG.423E (1-H-10) FUEL TANK COVER (DL1000AL8 E33) (FOR YU1)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
20	68281-47HA0	EMBLEM, "S"	1	
21	09409-08326	CLIP	2	
22	68111-47HA0	EMBLEM, "S"	2	
23	09409-06314	CLIP	4	
24	44552-24B00	MOLDING, FUEL TANK	2	
25	45289-05H00	CUSHION	1	

FIG.423F




FIG.423F (1-H-11) FUEL TANK COVER (DL1000AL8 E33) (FOR YVB,YWW)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	44191-31J00-PGZ	COVER, FUEL TANK CENTER (GRAY)	1	
2	44170-31J20-PGZ	COVER, FUEL TANK SIDE RH (GRAY)	1	
3	68121-31J00-BG9	.EMBLEM, FUEL TANK COVER RH	1	
4	44180-31J20-PGZ	COVER, FUEL TANK SIDE LH (GRAY)	1	
5	68131-31J00-BG9	.EMBLEM, FUEL TANK COVER LH	1	
6	44270-31J00	COVER, FUEL TANK FRONT RH	1	
7	45517-31J00	.TAPE, FUEL TANK COVER	1	
8	44280-31J00	COVER, FUEL TANK FRONT LH	1	
9	45517-31J00	.TAPE, FUEL TANK COVER	1	
10	44612-13600	CUSHION, TANK COVER SIDE NO.4	2	CUT AS REQUIRED
11	44277-01H00	CUSHION, FUEL TANK COVER	2	
12	94642-10GA0	CUSHION, FUEL TANK COVER NO.2	2	
13	44176-31J00	CUSHION, TANK COVER SIDE NO.1	2	
14	44177-31J00	CUSHION, TANK COVER SIDE NO.2	2	
15	44178-31J00	CUSHION, TANK COVER SIDE NO.3	2	
16	09139-06172	BOLT (6X10)	3	
17	09139-05074	BOLT (5X13)	4	
18	09148-05052	NUT	2	
19	03241-0516B	SCREW	6	

FIG.423F




FIG.423F (1-H-12) FUEL TANK COVER (DL1000AL8 E33) (FOR YVB,YWW)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
20	68281-47HA0	EMBLEM, "S"	1	
21	09409-08326	CLIP	2	
22	68111-47HA0	EMBLEM, "S"	2	
23	09409-06314	CLIP	4	
24	44552-24B00	MOLDING, FUEL TANK	2	
25	45289-05H00	CUSHION	1	

FIG.423G




FIG.423G (1-H-13) FUEL TANK COVER (DL1000XAL8 E03)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	44191-31J00-YKV	COVER, FUEL TANK CENTER (BLACK)	1	
2-1	44170-31J10-YKV	COVER, FUEL TANK SIDE RH (BLACK)	1	FOR YU1
2-2	44170-31J10-4TX	COVER, FUEL TANK SIDE RH (BLACK)	1	FOR YVB,YWW
3-1	68125-31J00-BHA	.TAPE, FUEL TANK COVER RH	1	FOR YKV
3-2	68125-31J00-BG4	.TAPE, FUEL TANK COVER RH	1	FOR 4TX
4-1	44180-31J10-YKV	COVER, FUEL TANK SIDE LH (BLACK)	1	FOR YU1
4-2	44180-31J10-4TX	COVER, FUEL TANK SIDE LH (BLACK)	1	FOR YVB,YWW
5-1	68135-31J00-BHA	.TAPE, FUEL TANK COVER LH	1	FOR YKV
5-2	68135-31J00-BG4	.TAPE, FUEL TANK COVER LH	1	FOR 4TX
6	44270-31J00	COVER, FUEL TANK FRONT RH	1	
7	45517-31J00	.TAPE, FUEL TANK COVER	1	
8	44280-31J00	COVER, FUEL TANK FRONT LH	1	
9	45517-31J00	.TAPE, FUEL TANK COVER	1	
10	44612-13600	CUSHION, TANK COVER SIDE NO.4	2	CUT AS REQUIRED
11	44277-01H00	CUSHION, FUEL TANK COVER	2	
12	94642-10GA0	CUSHION, FUEL TANK COVER NO.2	2	
13	44176-31J00	CUSHION, TANK COVER SIDE NO.1	2	
14	44177-31J00	CUSHION, TANK COVER SIDE NO.2	2	
15	44178-31J00	CUSHION, TANK COVER SIDE NO.3	2	
16	09139-06172	BOLT (6X10)	3	
17	09139-05074	BOLT (5X13)	4	
18	09148-05052	NUT	2	
19	03241-0516B	SCREW	6	

FIG.423G




FIG.423G (1-H-14) FUEL TANK COVER (DL1000XAL8 E03)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
20	68281-47HA0	EMBLEM, "S"	1	
21	09409-08326	CLIP	2	
22	68111-47HA0	EMBLEM, "S"	2	
23	09409-06314	CLIP	4	
24	44552-24B00	MOLDING, FUEL TANK	2	
25	45289-05H00	CUSHION	1	

FIG.423H




FIG.423H (1-H-15) FUEL TANK COVER (DL1000AL8 E28)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	44191-31J00-YKV	COVER, FUEL TANK CENTER (BLACK)	1	
2-1	44170-31J10-YKV	COVER, FUEL TANK SIDE RH (BLACK)	1	FOR YU1
2-2	44170-31J10-4TX	COVER, FUEL TANK SIDE RH (BLACK)	1	FOR YVB,YWW
3-1	68125-31J00-BHA	.TAPE, FUEL TANK COVER RH	1	FOR YKV
3-2	68125-31J00-BG4	.TAPE, FUEL TANK COVER RH	1	FOR 4TX
4-1	44180-31J10-YKV	COVER, FUEL TANK SIDE LH (BLACK)	1	FOR YU1
4-2	44180-31J10-4TX	COVER, FUEL TANK SIDE LH (BLACK)	1	FOR YVB,YWW
5-1	68135-31J00-BHA	.TAPE, FUEL TANK COVER LH	1	FOR YKV
5-2	68135-31J00-BG4	.TAPE, FUEL TANK COVER LH	1	FOR 4TX
6	44270-31J00	COVER, FUEL TANK FRONT RH	1	
7	45517-31J00	.TAPE, FUEL TANK COVER	1	
8	44280-31J00	COVER, FUEL TANK FRONT LH	1	
9	45517-31J00	.TAPE, FUEL TANK COVER	1	
10	44612-13600	CUSHION, TANK COVER SIDE NO.4	2	CUT AS REQUIRED
11	44277-01H00	CUSHION, FUEL TANK COVER	2	
12	94642-10GA0	CUSHION, FUEL TANK COVER NO.2	2	
13	44176-31J00	CUSHION, TANK COVER SIDE NO.1	2	
14	44177-31J00	CUSHION, TANK COVER SIDE NO.2	2	
15	44178-31J00	CUSHION, TANK COVER SIDE NO.3	2	
16	09139-06172	BOLT (6X10)	3	
17	09139-05074	BOLT (5X13)	4	
18	09148-05052	NUT	2	
19	03241-0516B	SCREW	6	

FIG.423H




FIG.423H (1-I-2) FUEL TANK COVER (DL1000XAL8 E28)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
20	68281-47HA0	EMBLEM, "S"	1	
21	09409-08326	CLIP	2	
22	68111-47HA0	EMBLEM, "S"	2	
23	09409-06314	CLIP	4	
24	44552-24B00	MOLDING, FUEL TANK	2	
25	45289-05H00	CUSHION	1	

FIG.423J




FIG.423J (1-I-3) FUEL TANK COVER (DL1000XAL8 E33)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	44191-31J00-YKV	COVER, FUEL TANK CENTER (BLACK)	1	
2-1	44170-31J10-YKV	COVER, FUEL TANK SIDE RH (BLACK)	1	FOR YU1
2-2	44170-31J10-4TX	COVER, FUEL TANK SIDE RH (BLACK)	1	FOR YVB,YWW
3-1	68125-31J00-BHA	.TAPE, FUEL TANK COVER RH	1	FOR YKV
3-2	68125-31J00-BG4	.TAPE, FUEL TANK COVER RH	1	FOR 4TX
4-1	44180-31J10-YKV	COVER, FUEL TANK SIDE LH (BLACK)	1	FOR YU1
4-2	44180-31J10-4TX	COVER, FUEL TANK SIDE LH (BLACK)	1	FOR YVB,YWW
5-1	68135-31J00-BHA	.TAPE, FUEL TANK COVER LH	1	FOR YKV
5-2	68135-31J00-BG4	.TAPE, FUEL TANK COVER LH	1	FOR 4TX
6	44270-31J00	COVER, FUEL TANK FRONT RH	1	
7	45517-31J00	.TAPE, FUEL TANK COVER	1	
8	44280-31J00	COVER, FUEL TANK FRONT LH	1	
9	45517-31J00	.TAPE, FUEL TANK COVER	1	
10	44612-13600	CUSHION, TANK COVER SIDE NO.4	2	CUT AS REQUIRED
11	44277-01H00	CUSHION, FUEL TANK COVER	2	
12	94642-10GA0	CUSHION, FUEL TANK COVER NO.2	2	
13	44176-31J00	CUSHION, TANK COVER SIDE NO.1	2	
14	44177-31J00	CUSHION, TANK COVER SIDE NO.2	2	
15	44178-31J00	CUSHION, TANK COVER SIDE NO.3	2	
16	09139-06172	BOLT (6X10)	3	
17	09139-05074	BOLT (5X13)	4	
18	09148-05052	NUT	2	
19	03241-0516B	SCREW	6	

FIG.423J




FIG.423J (1-I-4) FUEL TANK COVER (DL1000AL8 E33)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
20	68281-47HA0	EMBLEM, "S"	1	
21	09409-08326	CLIP	2	
22	68111-47HA0	EMBLEM, "S"	2	
23	09409-06314	CLIP	4	
24	44552-24B00	MOLDING, FUEL TANK	2	
25	45289-05H00	CUSHION	1	

FIG.427A




FIG.427A (1-1-5) EVAP SYSTEM (DL1000AL8 E33)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	44434-31J01	HOSE, TANK & BREATHER VALVE	1	
2	09401-11413	CLIP	11	
3	18572-31J00	BRACKET, SURGE HOSE	1	
4	01550-0612A	BOLT	1	
5	09407-17403	CLAMP (L:154)	1	
6	17210-15H10	CANISTER	1	
7	09251-07003	CAP (OD:11.5)	1	
8	18571-31J10	CUSHION, CANISTER	1	
9	09401-12404	CLIP	2	
10	09367-06009	JOINT	4	
11	18561-31JB0	HOSE, CSTR PURGE NO.1	1	
12	18561-31J10	HOSE, CSTR PURGE NO.2	1	
13	18561-31J20	HOSE, CSTR PURGE NO.3	1	
14	18563-31JA0	HOSE, CSTR SURGE NO.1	1	
15	18563-31JB0	HOSE, CSTR SURGE NO.2	1	
16	09407-18402	CLAMP (L:165)	1	

FIG.427B




FIG.427B (1-I-6) EVAP SYSTEM (DL1000XAL8 E33)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	44434-31J01	HOSE, TANK & BREATHER VALVE	1	
2	09401-11413	CLIP	11	
3	18572-31J00	BRACKET, SURGE HOSE	1	
4	01550-0612A	BOLT	1	
5	09407-17403	CLAMP (L:154)	1	
6	17210-15H10	CANISTER	1	
7	09251-07003	CAP (OD:11.5)	1	
8	18571-31J10	CUSHION, CANISTER	1	
9	09401-12404	CLIP	2	
10	09367-06009	JOINT	4	
11	18561-31JB0	HOSE, CSTR PURGE NO.1	1	
12	18561-31J10	HOSE, CSTR PURGE NO.2	1	
13	18561-31J20	HOSE, CSTR PURGE NO.3	1	
14	18563-31JA0	HOSE, CSTR SURGE NO.1	1	
15	18563-31JB0	HOSE, CSTR SURGE NO.2	1	
16	09407-18402	CLAMP (L:165)	1	

FIG.444A





FIG.444A (1-I-7) FRONT BRACKET (DL1000AL8 E03) (FOR YU1)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	44193-31J00	SCREW	2	
2	94420-31J20-YMD	COVER, SIDE REAR RH (SILVER)	1	
3	68275-31J00-BG5	.TAPE, COVER SIDE RH	1	
4	94430-31J20-YMD	COVER, SIDE REAR LH (SILVER)	1	
5	68285-31J00-BG5	.TAPE, COVER SIDE LH	1	
6	44160-31J00	BRACKET, COVER	1	
7	09139-06190	BOLT (6X20)	2	
8	44164-31J00	CUSHION, COVER	2	
9	44520-31J01	BRACKET, FRONT	1	
10	09139-06192	SCREW (6X25)	3	
11	09160-06012	WASHER (6.5X22X1.6)	3	
12	44512-16G00	SPACER, FUEL TANK FR	3	
13	44511-16G00	CUSHION	3	
14	01550-0695A	BOLT	1	
15	44561-35F00	SPACER	1	
16	08319-3106B	NUT	1	
17	44560-31J00	BRACKET, SIDE RH	1	
18	44560-31J00	BRACKET, SIDE LH	1	
19	01550-0612A	BOLT	2	
20	44543-31J00	CUSHION, FRONT SIDE BRACKET	2	
21	09139-05091	SCREW	4	

FIG.444B



DL1000AL8_E03_E28_444B
FRONT BRACKET

FIG.444B (1-1-8) FRONT BRACKET (DL1000AL8 E03) (FOR YVB,YWW)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	44193-31J00	SCREW	2	
2-1	94420-31J10-YVB	COVER, SIDE REAR RH (BLACK)	1	
2-2	94420-31J10-YWW	COVER, SIDE REAR RH (WHITE)	1	
3-1	94430-31J10-YVB	COVER, SIDE REAR LH (BLACK)	1	
3-2	94430-31J10-YWW	COVER, SIDE REAR LH (WHITE)	1	
4	44160-31J00	BRACKET, COVER	1	
5	09139-06190	BOLT (6X20)	2	
6	44164-31J00	CUSHION, COVER	2	
7	44520-31J01	BRACKET, FRONT	1	
8	09139-06192	SCREW (6X25)	3	
9	09160-06012	WASHER (6.5X22X1.6)	3	
10	44512-16G00	SPACER, FUEL TANK FR	3	
11	44511-16G00	CUSHION	3	
12	01550-0695A	BOLT	1	
13	44561-35F00	SPACER	1	
14	08319-3106B	NUT	1	
15	44560-31J00	BRACKET, SIDE RH	1	
16	44560-31J00	BRACKET, SIDE LH	1	
17	01550-0612A	BOLT	2	
18	44543-31J00	CUSHION, FRONT SIDE BRACKET	2	
19	09139-05091	SCREW	4	

DL1000AL8_E03_E28

FIG.444C




FIG.444C (1-I-9) FRONT BRACKET (DL1000AL8 E28) (FOR YU1)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	44193-31J00	SCREW	2	
2	94420-31J20-YMD	COVER, SIDE REAR RH (SILVER)	1	
3	68275-31J00-BG5	.TAPE, COVER SIDE RH	1	
4	94430-31J20-YMD	COVER, SIDE REAR LH (SILVER)	1	
5	68285-31J00-BG5	.TAPE, COVER SIDE LH	1	
6	44160-31J00	BRACKET, COVER	1	
7	09139-06190	BOLT (6X20)	2	
8	44164-31J00	CUSHION, COVER	2	
9	44520-31J01	BRACKET, FRONT	1	
10	09139-06192	SCREW (6X25)	3	
11	09160-06012	WASHER (6.5X22X1.6)	3	
12	44512-16G00	SPACER, FUEL TANK FR	3	
13	44511-16G00	CUSHION	3	
14	01550-0695A	BOLT	1	
15	44561-35F00	SPACER	1	
16	08319-3106B	NUT	1	
17	44560-31J00	BRACKET, SIDE RH	1	
18	44560-31J00	BRACKET, SIDE LH	1	
19	01550-0612A	BOLT	2	
20	44543-31J00	CUSHION, FRONT SIDE BRACKET	2	
21	09139-05091	SCREW	4	

FIG.444D




FIG.444D (1-I-10) FRONT BRACKET (DL1000AL8 E28) (FOR YVB,YWW)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	44193-31J00	SCREW	2	
2-1	94420-31J10-YVB	COVER, SIDE REAR RH (BLACK)	1	
2-2	94420-31J10-YWW	COVER, SIDE REAR RH (WHITE)	1	
3-1	94430-31J10-YVB	COVER, SIDE REAR LH (BLACK)	1	
3-2	94430-31J10-YWW	COVER, SIDE REAR LH (WHITE)	1	
4	44160-31J00	BRACKET, COVER	1	
5	09139-06190	BOLT (6X20)	2	
6	44164-31J00	CUSHION, COVER	2	
7	44520-31J01	BRACKET, FRONT	1	
8	09139-06192	SCREW (6X25)	3	
9	09160-06012	WASHER (6.5X22X1.6)	3	
10	44512-16G00	SPACER, FUEL TANK FR	3	
11	44511-16G00	CUSHION	3	
12	01550-0695A	BOLT	1	
13	44561-35F00	SPACER	1	
14	08319-3106B	NUT	1	
15	44560-31J00	BRACKET, SIDE RH	1	
16	44560-31J00	BRACKET, SIDE LH	1	
17	01550-0612A	BOLT	2	
18	44543-31J00	CUSHION, FRONT SIDE BRACKET	2	
19	09139-05091	SCREW	4	

FIG.444E




FIG.444E (1-I-11) FRONT BRACKET (DL1000AL8 E33) (FOR YU1)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	44193-31J00	SCREW	2	
2	94420-31J20-YMD	COVER, SIDE REAR RH (SILVER)	1	
3	68275-31J00-BG5	.TAPE, COVER SIDE RH	1	
4	94430-31J20-YMD	COVER, SIDE REAR LH (SILVER)	1	
5	68285-31J00-BG5	.TAPE, COVER SIDE LH	1	
6	44160-31J00	BRACKET, COVER	1	
7	09139-06190	BOLT (6X20)	2	
8	44164-31J00	CUSHION, COVER	2	
9	44520-31J01	BRACKET, FRONT	1	
10	09139-06192	SCREW (6X25)	3	
11	09160-06012	WASHER (6.5X22X1.6)	3	
12	44512-16G00	SPACER, FUEL TANK FR	3	
13	44511-16G00	CUSHION	3	
14	01550-0695A	BOLT	1	
15	44561-35F00	SPACER	1	
16	08319-3106B	NUT	1	
17	44560-31J00	BRACKET, SIDE RH	1	
18	44560-31J00	BRACKET, SIDE LH	1	
19	01550-0612A	BOLT	2	
20	44543-31J00	CUSHION, FRONT SIDE BRACKET	2	
21	09139-05091	SCREW	4	

FIG.444F




FIG.444F (1-I-12) FRONT BRACKET (DL1000AL8 E33) (FOR YVB,YWW)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	44193-31J00	SCREW	2	
2-1	94420-31J10-YVB	COVER, SIDE REAR RH (BLACK)	1	
2-2	94420-31J10-YWW	COVER, SIDE REAR RH (WHITE)	1	
3-1	94430-31J10-YVB	COVER, SIDE REAR LH (BLACK)	1	
3-2	94430-31J10-YWW	COVER, SIDE REAR LH (WHITE)	1	
4	44160-31J00	BRACKET, COVER	1	
5	09139-06190	BOLT (6X20)	2	
6	44164-31J00	CUSHION, COVER	2	
7	44520-31J01	BRACKET, FRONT	1	
8	09139-06192	SCREW (6X25)	3	
9	09160-06012	WASHER (6.5X22X1.6)	3	
10	44512-16G00	SPACER, FUEL TANK FR	3	
11	44511-16G00	CUSHION	3	
12	01550-0695A	BOLT	1	
13	44561-35F00	SPACER	1	
14	08319-3106B	NUT	1	
15	44560-31J00	BRACKET, SIDE RH	1	
16	44560-31J00	BRACKET, SIDE LH	1	
17	01550-0612A	BOLT	2	
18	44543-31J00	CUSHION, FRONT SIDE BRACKET	2	
19	09139-05091	SCREW	4	

FIG.444G




FIG.444G (1-I-13) FRONT BRACKET (DL1000AL8 E03)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	44193-31J00	SCREW	2	
2-1	94420-31J20-YMD	COVER, SIDE REAR RH (SILVER)	1	FOR YU1
2-2	94420-31J20-5JX	COVER, SIDE REAR RH (SILVER)	1	FOR YVB,YWW
3-1	68275-31J00-BG5	.TAPE, COVER SIDE RH	1	FOR YMD
3-2	68275-31J00-BG6	.TAPE, COVER SIDE RH	1	FOR 5JX
4-1	94430-31J20-YMD	COVER, SIDE REAR LH (SILVER)	1	FOR YU1
4-2	94430-31J20-5JX	COVER, SIDE REAR LH (SILVER)	1	FOR YVB,YWW
5-1	68285-31J00-BG5	.TAPE, COVER SIDE LH	1	FOR YMD
5-2	68285-31J00-BG6	.TAPE, COVER SIDE LH	1	FOR 5JX
6	44160-31J00	BRACKET, COVER	1	
7	09139-06190	BOLT (6X20)	2	
8	44164-31J00	CUSHION, COVER	2	
9	44520-31J01	BRACKET, FRONT	1	
10	09139-06192	SCREW (6X25)	3	
11	09160-06012	WASHER (6.5X22X1.6)	3	
12	44512-16G00	SPACER, FUEL TANK FR	3	
13	44511-16G00	CUSHION	3	
14	01550-0695A	BOLT	1	
15	44561-35F00	SPACER	1	
16	08319-3106B	NUT	1	
17	44560-31J00	BRACKET, SIDE RH	1	
18	44560-31J00	BRACKET, SIDE LH	1	
19	01550-0612A	BOLT	2	
20	44543-31J00	CUSHION, FRONT SIDE BRACKET	2	
21	09139-05091	SCREW	4	

FIG.444H




FIG.444H (1-I-14) FRONT BRACKET (DL1000AL8 E28)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	44193-31J00	SCREW	2	
2-1	94420-31J20-YMD	COVER, SIDE REAR RH (SILVER)	1	FOR YU1
2-2	94420-31J20-5JX	COVER, SIDE REAR RH (SILVER)	1	FOR YVB,YWW
3-1	68275-31J00-BG5	.TAPE, COVER SIDE RH	1	FOR YMD
3-2	68275-31J00-BG6	.TAPE, COVER SIDE RH	1	FOR 5JX
4-1	94430-31J20-YMD	COVER, SIDE REAR LH (SILVER)	1	FOR YU1
4-2	94430-31J20-5JX	COVER, SIDE REAR LH (SILVER)	1	FOR YVB,YWW
5-1	68285-31J00-BG5	.TAPE, COVER SIDE LH	1	FOR YMD
5-2	68285-31J00-BG6	.TAPE, COVER SIDE LH	1	FOR 5JX
6	44160-31J00	BRACKET, COVER	1	
7	09139-06190	BOLT (6X20)	2	
8	44164-31J00	CUSHION, COVER	2	
9	44520-31J01	BRACKET, FRONT	1	
10	09139-06192	SCREW (6X25)	3	
11	09160-06012	WASHER (6.5X22X1.6)	3	
12	44512-16G00	SPACER, FUEL TANK FR	3	
13	44511-16G00	CUSHION	3	
14	01550-0695A	BOLT	1	
15	44561-35F00	SPACER	1	
16	08319-3106B	NUT	1	
17	44560-31J00	BRACKET, SIDE RH	1	
18	44560-31J00	BRACKET, SIDE LH	1	
19	01550-0612A	BOLT	2	
20	44543-31J00	CUSHION, FRONT SIDE BRACKET	2	
21	09139-05091	SCREW	4	

FIG.444J




FIG.444J (1-I-15) FRONT BRACKET (DL1000XAL8 E33)

REF NO.	PART NO.	DESCRIPTION	QTY	REMARKS
1	44193-31J00	SCREW	2	
2-1	94420-31J20-YMD	COVER, SIDE REAR RH (SILVER)	1	FOR YU1
2-2	94420-31J20-5JX	COVER, SIDE REAR RH (SILVER)	1	FOR YVB,YWW
3-1	68275-31J00-BG5	.TAPE, COVER SIDE RH	1	FOR YMD
3-2	68275-31J00-BG6	.TAPE, COVER SIDE RH	1	FOR 5JX
4-1	94430-31J20-YMD	COVER, SIDE REAR LH (SILVER)	1	FOR YU1
4-2	94430-31J20-5JX	COVER, SIDE REAR LH (SILVER)	1	FOR YVB,YWW
5-1	68285-31J00-BG5	.TAPE, COVER SIDE LH	1	FOR YMD
5-2	68285-31J00-BG6	.TAPE, COVER SIDE LH	1	FOR 5JX
6	44160-31J00	BRACKET, COVER	1	
7	09139-06190	BOLT (6X20)	2	
8	44164-31J00	CUSHION, COVER	2	
9	44520-31J01	BRACKET, FRONT	1	
10	09139-06192	SCREW (6X25)	3	
11	09160-06012	WASHER (6.5X22X1.6)	3	
12	44512-16G00	SPACER, FUEL TANK FR	3	
13	44511-16G00	CUSHION	3	
14	01550-0695A	BOLT	1	
15	44561-35F00	SPACER	1	
16	08319-3106B	NUT	1	
17	44560-31J00	BRACKET, SIDE RH	1	
18	44560-31J00	BRACKET, SIDE LH	1	
19	01550-0612A	BOLT	2	
20	44543-31J00	CUSHION, FRONT SIDE BRACKET	2	
21	09139-05091	SCREW	4	

FIG.445A




FIG.445A (1-J-2) FRAME COVER

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	47111-31J10	COVER, FRAME RH	1	
2	47211-31J10	COVER, FRAME LH	1	
3	47411-31J00	COVER, FRAME REAR RH	1	
4	47511-31J00	COVER, FRAME REAR LH	1	
5	09139-05074	BOLT (5X13)	4	
6	09320-08028	CUSHION	2	
7	47121-31J00	CUSHION, FRAME COVER	2	
8	94479-35F00	CLIP	2	
9	47913-31J00	SCREW	6	
10	09320-20010	CUSHION	2	
11	09139-06120	SCREW (6X16)	4	
12	47510-28K00	SPACER,FRAME COVER	2	



FIG.460A




FIG.460A (1-J-3) FRONT FENDER (DL1000AL8 E03) (FOR YU1)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	53100-31J20-BG7	FENDER, FRONT	1	
2	68150-31J00-BG7	.TAPE SET, FRONT FENDER	1	
3	47915-31J00	SCREW	4	
4	35950-13K00	REFLEX REFLECTOR ASSY, FRONT	2	
5	09119-06109	BOLT	2	
6	09160-08043	WASHER (8.5X18X1)	2	

FIG.460B




FIG.460B (1-J-4) FRONT FENDER (DL1000AL8 E03) (FOR YVB,YWW)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	53100-31J10-GWM	FENDER, FRONT (GRAY/BLACK)	1	
2	68151-44G10-GWM	.EMBLEM "ABS" (GRAY/BLACK)	1	
3	47915-31J00	SCREW	4	
4	35950-13K00	REFLEX REFLECTOR ASSY, FRONT	2	
5	09119-06109	BOLT	2	
6	09160-08043	WASHER (8.5X18X1)	2	

FIG.460C




FIG.460C (1-J-5) FRONT FENDER (DL1000AL8 E28) (FOR YU1)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	53100-31J20-BG7	FENDER, FRONT	1	
2	68150-31J00-BG7	.TAPE SET, FRONT FENDER	1	
3	47915-31J00	SCREW	4	
4	35950-13K00	REFLEX REFLECTOR ASSY, FRONT	2	
5	09119-06109	BOLT	2	
6	09160-08043	WASHER (8.5X18X1)	2	

FIG.460D




FIG.460D (1-J-6) FRONT FENDER (DL1000AL8 E28) (FOR YVB,YWW)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	53100-31J10-GWM	FENDER, FRONT (GRAY/BLACK)	1	
2	68151-44G10-GWM	.EMBLEM "ABS" (GRAY/BLACK)	1	
3	47915-31J00	SCREW	4	
4	35950-13K00	REFLEX REFLECTOR ASSY, FRONT	2	
5	09119-06109	BOLT	2	
6	09160-08043	WASHER (8.5X18X1)	2	



FIG.460E




FIG.460E (1-J-7) FRONT FENDER (DL1000AL8 E33) (FOR YU1)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	53100-31J20-BG7	FENDER, FRONT	1	
2	68150-31J00-BG7	.TAPE SET, FRONT FENDER	1	
3	47915-31J00	SCREW	4	
4	35950-13K00	REFLEX REFLECTOR ASSY, FRONT	2	
5	09119-06109	BOLT	2	
6	09160-08043	WASHER (8.5X18X1)	2	

FIG.460F




FIG.460F (1-J-8) FRONT FENDER (DL1000AL8 E33) (FOR YVB,YWW)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	53100-31J10-GWM	FENDER, FRONT (GRAY/BLACK)	1	
2	68151-44G10-GWM	.EMBLEM "ABS" (GRAY/BLACK)	1	
3	47915-31J00	SCREW	4	
4	35950-13K00	REFLEX REFLECTOR ASSY, FRONT	2	
5	09119-06109	BOLT	2	
6	09160-08043	WASHER (8.5X18X1)	2	



FIG.460G




FIG.460G (1-J-9) FRONT FENDER (DL1000XAL8 E03)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	53100-31J20-BG7	FENDER, FRONT	1	FOR YU1
1-2	53100-31J20-BG8	FENDER, FRONT	1	FOR YVB, YWW
2-1	68150-31J00-BG7	.TAPE SET, FRONT FENDER	1	FOR BG7
2-2	68150-31J00-BG8	.TAPE SET, FRONT FENDER	1	FOR BG8
3	47915-31J00	SCREW	4	
4	35950-13K00	REFLEX REFLECTOR ASSY, FRONT	2	
5	09119-06109	BOLT	2	
6	09160-08043	WASHER (8.5X18X1)	2	



FIG.460H




FIG.460H (1-J-10) FRONT FENDER (DL1000XAL8 E28)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	53100-31J20-BG7	FENDER, FRONT	1	FOR YU1
1-2	53100-31J20-BG8	FENDER, FRONT	1	FOR YVB, YWW
2-1	68150-31J00-BG7	.TAPE SET, FRONT FENDER	1	FOR BG7
2-2	68150-31J00-BG8	.TAPE SET, FRONT FENDER	1	FOR BG8
3	47915-31J00	SCREW	4	
4	35950-13K00	REFLEX REFLECTOR ASSY, FRONT	2	
5	09119-06109	BOLT	2	
6	09160-08043	WASHER (8.5X18X1)	2	



FIG.460J





FIG.460J (1-J-11) FRONT FENDER (DL1000XAL8 E33)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	53100-31J20-BG7	FENDER, FRONT	1	FOR YU1
1-2	53100-31J20-BG8	FENDER, FRONT	1	FOR YVB, YWW
2-1	68150-31J00-BG7	.TAPE SET, FRONT FENDER	1	FOR BG7
2-2	68150-31J00-BG8	.TAPE SET, FRONT FENDER	1	FOR BG8
3	47915-31J00	SCREW	4	
4	35950-13K00	REFLEX REFLECTOR ASSY, FRONT	2	
5	09119-06109	BOLT	2	
6	09160-08043	WASHER (8.5X18X1)	2	



FIG.462A



DL1000AL8_E03_E28_462A
HANDLEBAR

FIG.462A (1-J-12) HANDLEBAR (DL1000AL8 E03)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	56111-31J10-YAP	HANDLEBAR (BLACK)	1	
2	56200-32851	BALANCER SET, HANDLEBAR	2	
3	56272-10G00	.EXPANDER, HANDLE BALANCER	2	
4	56272-42F00	.EXPANDER, HANDLE BALANCER	2	
5	56273-10G10	.NUT	2	
6	57346-31J00	.SPACER, BALANCER	2	
7	09127-06023	.SCREW (6X140)	2	
8	09160-06131	.WASHER (6.5X16X4)	6	
9	09180-06356	.SPACER (6.5X9X34)	2	
10	56500-04F30	MIRROR ASSY, REAR VIEW RH	1	
11	56600-04F30	MIRROR ASSY, REAR VIEW LH	1	
12	58300-31J00	CABLE ASSY, THROTTLE	1	
13	58620-31J00	GUIDE, CABLE	1	
14	01547-0612A	BOLT	2	
15	58620-31J10	GUIDE, CABLE	1	

FIG.462B

FIG.462B (1-J-13) HANDLEBAR (DL1000AL8 E28)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	56111-31J10-YAP	HANDLEBAR (BLACK)	1	
2	56200-32851	BALANCER SET, HANDLEBAR	2	
3	56272-10G00	.EXPANDER, HANDLE BALANCER	2	
4	56272-42F00	.EXPANDER, HANDLE BALANCER	2	
5	56273-10G10	.NUT	2	
6	57346-31J00	.SPACER, BALANCER	2	
7	09127-06023	.SCREW (6X140)	2	
8	09160-06131	.WASHER (6.5X16X4)	6	
9	09180-06356	.SPACER (6.5X9X34)	2	
10	56500-04F30	MIRROR ASSY, REAR VIEW RH	1	
11	56600-04F30	MIRROR ASSY, REAR VIEW LH	1	
12	58300-31J00	CABLE ASSY, THROTTLE	1	
13	58620-31J00	GUIDE, CABLE	1	
14	01547-0612A	BOLT	2	
15	58620-31J10	GUIDE, CABLE	1	




FIG.462C

FIG.462C (1-J-14) HANDLEBAR (DL1000AL8 E33)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	56111-31J10-YAP	HANDLEBAR (BLACK)	1	
2	56200-32851	BALANCER SET, HANDLEBAR	2	
3	56272-10G00	.EXPANDER, HANDLE BALANCER	2	
4	56272-42F00	.EXPANDER, HANDLE BALANCER	2	
5	56273-10G10	.NUT	2	
6	57346-31J00	.SPACER, BALANCER	2	
7	09127-06023	.SCREW (6X140)	2	
8	09160-06131	.WASHER (6.5X16X4)	6	
9	09180-06356	.SPACER (6.5X9X34)	2	
10	56500-04F30	MIRROR ASSY, REAR VIEW RH	1	
11	56600-04F30	MIRROR ASSY, REAR VIEW LH	1	
12	58300-31J00	CABLE ASSY, THROTTLE	1	
13	58620-31J00	GUIDE, CABLE	1	
14	01547-0612A	BOLT	2	
15	58620-31J10	GUIDE, CABLE	1	




FIG.462D

FIG.462D (1-J-15) HANDLEBAR (DL1000XAL8 E03)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	56111-31JA0-YUS	HANDLEBAR (SILVER)	1	
2	56200-04830	BALANCER SET, HANDLEBAR	2	
3	56272-10G00	.EXPANDER, HANDLE BALANCER	2	
4	56272-42F00	.EXPANDER, HANDLE BALANCER	2	
5	56273-10G10	.NUT	2	
6	57346-31J00	.SPACER, BALANCER	2	
7	09127-06023	.SCREW (6X140)	2	
8	09160-06131	.WASHER (6.5X16X4)	6	
9	09180-06356	.SPACER (6.5X9X34)	2	
10	56500-04F30	MIRROR ASSY, REAR VIEW RH	1	
11	56600-04F30	MIRROR ASSY, REAR VIEW LH	1	
12	58300-31J00	CABLE ASSY, THROTTLE	1	
13	58620-31J00	GUIDE, CABLE	1	
14	01547-0612A	BOLT	2	
15	58620-31J10	GUIDE, CABLE	1	




FIG.462E

FIG.462E (1-K-2) HANDLEBAR (DL1000XAL8 E28)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	56111-31JA0-YUS	HANDLEBAR (SILVER)	1	
2	56200-04830	BALANCER SET, HANDLEBAR	2	
3	56272-10G00	.EXPANDER, HANDLE BALANCER	2	
4	56272-42F00	.EXPANDER, HANDLE BALANCER	2	
5	56273-10G10	.NUT	2	
6	57346-31J00	.SPACER, BALANCER	2	
7	09127-06023	.SCREW (6X140)	2	
8	09160-06131	.WASHER (6.5X16X4)	6	
9	09180-06356	.SPACER (6.5X9X34)	2	
10	56500-04F30	MIRROR ASSY, REAR VIEW RH	1	
11	56600-04F30	MIRROR ASSY, REAR VIEW LH	1	
12	58300-31J00	CABLE ASSY, THROTTLE	1	
13	58620-31J00	GUIDE, CABLE	1	
14	01547-0612A	BOLT	2	
15	58620-31J10	GUIDE, CABLE	1	




FIG.462F

FIG.462F (1-K-3) HANDLEBAR (DL1000XAL8 E33)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	56111-31JA0-YUS	HANDLEBAR (SILVER)	1	
2	56200-04830	BALANCER SET, HANDLEBAR	2	
3	56272-10G00	.EXPANDER, HANDLE BALANCER	2	
4	56272-42F00	.EXPANDER, HANDLE BALANCER	2	
5	56273-10G10	.NUT	2	
6	57346-31J00	.SPACER, BALANCER	2	
7	09127-06023	.SCREW (6X140)	2	
8	09160-06131	.WASHER (6.5X16X4)	6	
9	09180-06356	.SPACER (6.5X9X34)	2	
10	56500-04F30	MIRROR ASSY, REAR VIEW RH	1	
11	56600-04F30	MIRROR ASSY, REAR VIEW LH	1	
12	58300-31J00	CABLE ASSY, THROTTLE	1	
13	58620-31J00	GUIDE, CABLE	1	
14	01547-0612A	BOLT	2	
15	58620-31J10	GUIDE, CABLE	1	




FIG.467A




FIG.467A (1-K-4) HANDLE LEVER

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	57110-21H02	GRIP, THROTTLE	1	
2	57100-42F00	CASE ASSY, THROTTLE	1	
3	07130-0525B	.BOLT	2	
4	57300-10G50	LEVER ASSY, BRAKE	1	
5	57431-06GA0	.BOLT	1	
6	08316-1606B	.NUT	1	
7	57460-14J01	SWITCH ASSY, STOP	1	
8	57465-17C00	.SCREW	1	
9	57211-21H01	GRIP LH	1	
10	57500-06G20	LEVER ASSY, CLUTCH	1	
11	57431-06GB0	.BOLT	1	
12	08316-1606B	.NUT	1	
13	57560-02FA0	SWITCH ASSY, CLUTCH	1	

FIG.472A




FIG.472A (1-K-5) KNUCKLE COVER

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	57341-31J00-291	COVER, KNUCKLE RH (BLACK)	1	
2	57541-31J00-291	COVER, KNUCKLE LH (BLACK)	1	
3	09139-06027	SCREW (6X12)	2	
4	09160-06130	WASHER (6.5X16X1.6)	2	
5	09180-06306	SPACER (6.5X9X5)	2	
6	08319-2106A	NUT	2	



FIG.474A




FIG.474A (1-K-6) REAR FENDER

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	63111-31J10-291	FENDER, REAR FRONT (BLACK)	1	
2	63112-31J00-291	FENDER, REAR (BLACK)	1	
3	09116-06165	BOLT (6X16)	2	
4	63411-31J10	MUDGUARD, REAR FENDER	1	
5	94479-35F00	CLIP	2	
6	09148-05052	NUT	2	
7	08322-0106B	WASHER	2	
8	47912-31J00	SCREW (5X13)	2	
9	33972-31D00	CUSHION	2	
10	15896-65J00	CUSHION	2	
11	96514-17K00	HEXAGON, SPANNER 5	1	
12	96514-17K10	HEXAGON, SPANNER 4	1	
13	09811-00173	TOOL BAG	1	
14	09812-00006	PLIER	1	
15	09813-00031	OPEN SPANNER (14X17)	1	
16	09813-00030	OPEN SPANNER (10X12)	1	
17	09814-00015	DRIVER	1	
18	09814-00016	DRIVER GRIP	1	

FIG.481A




FIG.481A (1-K-7) COWLING BODY

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	94411-31J10-YKV	COWLING, BODY (BLACK)	1	
2	48410-31JB0	WINDSCREEN (BLACK)	1	
3	09148-06020	NUT	2	
4	94402-31J10	COWLING, BODY LOWER	1	
5	73415-70A00	.PAD	2	
6	09148-05052	.NUT	2	
7	48415-31J00	BOLT, WINDSCREEN	4	
8	09320-09016	CUSHION	2	
9	94630-31J10	PANEL, METER	1	
10	73415-70A00	.PAD	3	
11	09320-08028	.CUSHION	1	
12	48414-31J00	CAP, WINDSCREEN SCREW	4	
13	94413-31J10	COVER, SIDE FR RH	1	
14	94414-31J10	COVER, SIDE FR LH	1	
15	94441-31J00-291	COWLING, SIDE LOWER RH (BLACK)	1	
16	94451-31J00-291	COWLING, SIDE LOWER LH (BLACK)	1	
17	94461-31J00	COVER, SIDE COWL INNER RH	1	
18	94462-31J00	COVER, SIDE COWL INNER LH	1	
19	47911-31J00	SCREW	2	
20	09320-09016	CUSHION	4	
21	09148-05038	NUT	2	
22	09148-05052	NUT	2	
23	09409-06314	CLIP	2	
24	09139-06120	SCREW (6X16)	2	
25	09409-06314	CLIP	2	
26	03541-0512A	SCREW	2	
27	03541-0512A	SCREW	4	
28	09409-06329	CLIP	2	

FIG.482A




FIG.482A (1-K-8) COWLING INSTALLATION PARTS

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	94510-31J00	BRACE, COWLING	1	
2	01550-0820A	BOLT	2	
3	48420-31J00	BRACE, WINDSCREEN RH	1	
4	48430-31J00	BRACE, WINDSCREEN LH	1	
5	09103-06283	BOLT (6X16)	4	
6	09320-08028	CUSHION	2	
7	09139-06126	SCREW (6X20)	2	
8	09320-09016	CUSHION	2	
9	34189-08J00	CUSHION, SPEEDOMETER	1	

FIG.483A




FIG.483A (1-K-9) UNDER COWLING

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	94470-31J00	COWLING, UNDER RH	1	
2	94473-31J00	.CUSHION, COWLING UNDER NO.1	1	
3	94474-31J00	.CUSHION, COWLING UNDER NO.2	1	
4	94480-31J00	COWLING, UNDER LH	1	
5	94483-31J00	.CUSHION, COWLING UNDER NO.1	1	
6	94484-31J00	.CUSHION, COWLING UNDER NO.2	1	
7	94491-31J01	COWLING, UNDER CTR	1	
8	47914-31J00	SCREW, UNDER COWLING	4	
9	09320-09016	CUSHION	4	
10	03541-0516B	SCREW	4	
11	94530-31J00	BRACKET, UNDER COWLING FR RH	1	
12	94540-31J00	BRACKET, UNDER COWLING FR LH	1	
13	94530-06G00	BRACKET, UNDER COWLING RH	1	
14	94540-06G00	BRACKET, UNDER COWLING LH	1	
15	09148-05045	NUT	3	



FIG.496A




FIG.496A (1-K-10) LABEL (DL1000AL8 E03)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	68319-49J00	LABEL, WARNING	1	
2	68332-31J10	LABEL, TIRE INFORMATION	1	
3	68353-26E02	LABEL, MANUAL NOTICE	1	
4	18803-02F01	LABEL, FUEL INFORMATION	1	
5	99011-31J53-03A	MANUAL, OWNER'S	1	

FIG.496B




FIG.496B (1-K-11) LABEL (DL1000AL8 E28)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	68319-49J10	LABEL, WARNING	1	
2	68332-31J00	LABEL, TIRE INFORMATION	1	
3-1	18803-40F10	LABEL, FUEL INFORMATION (ENGLISH/FRENCH)	1	
3-2	18803-45G00	LABEL, FUEL INFORMATION (SPANISH)	1	
4-1	99011-31J53-01A	MANUAL, OWNER'S (ENGLISH)	1	
4-2	99011-31J53-01F	MANUAL, OWNER'S (FRENCH)	1	
4-3	99011-31J53-029	MANUAL, OWNER'S (SPANISH)	1	

FIG.496C




FIG.496C (1-K-12) LABEL (DL1000AL8 E33)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	68319-49J00	LABEL, WARNING	1	
2	68332-31J10	LABEL, TIRE INFORMATION	1	
3	68353-26E02	LABEL, MANUAL NOTICE	1	
4	18803-02F01	LABEL, FUEL INFORMATION	1	
5	99011-31J53-03A	MANUAL, OWNER'S	1	

FIG.496D




FIG.496D (1-K-13) LABEL (DL1000XAL8 E03)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	68319-49J00	LABEL, WARNING	1	
2	68332-31J10	LABEL, TIRE INFORMATION	1	
3	68353-26E02	LABEL, MANUAL NOTICE	1	
4	18803-02F01	LABEL, FUEL INFORMATION	1	
5	99011-31J53-03A	MANUAL, OWNER'S	1	

FIG.496E




FIG.496E (1-K-14) LABEL (DL1000XAL8 E28)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	68319-49J10	LABEL, WARNING	1	
2	68332-31J00	LABEL, TIRE INFORMATION	1	
3-1	18803-40F10	LABEL, FUEL INFORMATION (ENGLISH/FRENCH)	1	
3-2	18803-45G00	LABEL, FUEL INFORMATION (SPANISH)	1	
4-1	99011-31J53-01A	MANUAL, OWNER'S (ENGLISH)	1	
4-2	99011-31J53-01F	MANUAL, OWNER'S (FRENCH)	1	
4-3	99011-31J53-029	MANUAL, OWNER'S (SPANISH)	1	

FIG.496F




FIG.496F (1-K-15) LABEL (DL1000XAL8 E33)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	68319-49J00	LABEL, WARNING	1	
2	68332-31J10	LABEL, TIRE INFORMATION	1	
3	68353-26E02	LABEL, MANUAL NOTICE	1	
4	18803-02F01	LABEL, FUEL INFORMATION	1	
5	99011-31J53-03A	MANUAL, OWNER'S	1	

FIG.505A




FIG.505A (1-L-2) SEAT

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	45100-31J10-BGQ	SEAT ASSY	1	FOR YVB,YWW
1-2	45100-31J10-BGR	SEAT ASSY	1	FOR YU1
2	45149-31300	.CUSHION	4	
3	09321-10012	.CUSHION	4	
4	94474-17H00	.TAPE, SEAT BOTTOM	2	
5	45213-13601	.CUSHION, SEAT LOCK	2	
6	45215-26F00	.STRIKER, SEAT LOCK	1	
7	08316-1006A	.NUT	2	
8	45256-31J00	SHEET, HEAT SHIELD RUBBER	1	
9	45220-47H00	BRACKET, SEAT SUPPORT	1	
10	45288-14F00	GUIDE, SEAT LOCK CABLE	1	
11	95700-14F00	LOCK SET, SEAT	1	
12	45289-11F00	PLATE, SEAT LOCK ASSY	1	
13	02122-0630A	SCREW	2	
14	45280-18G01	CABLE, SEAT LOCK	1	

FIG.521A




FIG.521A (1-L-3) FRONT FORK DAMPER

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	51103-31J30	DAMPER ASSY, FRONT FORK RH	1	
2	51110-31J20	.TUBE, INNER RH	1	
3	51158-14200	.WASHER	1	
4	51153-44G00	.OIL SEAL	1	
5	51156-14200	.RING, OIL SEAL STOPPER	1	
6	51173-02FA0	.SEAL, DUST	1	
7	51146-31J00	.CYLINDER	1	
8	51352-13A60	.NUT, ROD	1	
9	51171-31J00	.SPRING	1	
10	51158-40F30	.GUIDE, SPRING	1	
11	51176-48G10	.SPACER, SPRING	1	
12	51131-31J30	.TUBE, OUTER	1	
13	51351-31J30	.CAP	1	
14	62278-14100	..O RING	1	
15	51112-31J00	.PISTON	1	
16	51152-31J00	.SLIDEMETAL	1	
17	51178-31J00	.SEAT, SPRING	1	
18	51104-31J30	DAMPER ASSY, FRONT FORK LH	1	
19	51120-31J20	.TUBE, INNER LH	1	
20	51158-14200	.WASHER	1	
21	51153-44G00	.OIL SEAL	1	
22	51156-14200	.RING, OIL SEAL STOPPER	1	
23	51173-02FA0	.SEAL, DUST	1	
24	51146-31J00	.CYLINDER	1	
25	51352-13A60	.NUT, ROD	1	
26	51171-31J00	.SPRING	1	
27	51158-40F30	.GUIDE, SPRING	1	
28	51176-48G10	.SPACER, SPRING	1	
29	51131-31J30	.TUBE, OUTER	1	
30	51351-31J30	.CAP	1	
31	62278-14100	..O RING	1	
32	51112-31J00	.PISTON	1	
33	51152-31J00	.SLIDEMETAL	1	
34	51178-31J00	.SEAT, SPRING	1	
35	51166-24F60	BOLT	4	

FIG.524A




FIG.524A (1-L-4) STEERING STEM (DL1000AL8 E03)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	51410-31J00	BRACKET, UNDER	1	
2	51644-12C00	.SEAL, STEERING LOWER	1	
3	09267-30010	.BEARING (30X55X17)	1	
4	51328-44G10	BOLT	4	
5	51311-31J00-YTA	BRACKET, UPPER (BLACK)	1	
6	51147-31J00	BOLT	4	
7	51328-44G10	BOLT	2	
8	51321-17H10	BOLT	2	
9	51353-24F00	NUT, CAP	1	
10	51354-17H00	WASHER	2	
11	51355-16G00	WASHER	2	
12	51356-24F50	WASHER	1	
13	56211-31J00-YTA	HOLDER, HANDLE (BLACK)	2	
14	56221-08J00-YTA	HOLDER, HANDLE (BLACK)	2	
15	56245-31J00	RUBBER, HANDLE HOLDER	4	
16	08319-3110A	NUT	2	
17	09267-30010	BEARING (30X55X17)	1	
18	51643-41G00	COVER, STEERING UPPER	1	
19	51631-33E00	NUT, STEERING STEM	2	
20	51644-12C00	SEAL, STEERING LWR	1	
21	51641-33E00	WASHER, STEERING STEM	1	
22	09164-08015	WASHER	4	

FIG.524B




FIG.524B (1-L-5) STEERING STEM (DL1000AL8 E28)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	51410-31J00	BRACKET, UNDER	1	
2	51644-12C00	.SEAL, STEERING LOWER	1	
3	09267-30010	.BEARING (30X55X17)	1	
4	51328-44G10	BOLT	4	
5	51311-31J00-YTA	BRACKET, UPPER (BLACK)	1	
6	51147-31J00	BOLT	4	
7	51328-44G10	BOLT	2	
8	51321-17H10	BOLT	2	
9	51353-24F00	NUT, CAP	1	
10	51354-17H00	WASHER	2	
11	51355-16G00	WASHER	2	
12	51356-24F50	WASHER	1	
13	56211-31J00-YTA	HOLDER, HANDLE (BLACK)	2	
14	56221-08J00-YTA	HOLDER, HANDLE (BLACK)	2	
15	56245-31J00	RUBBER, HANDLE HOLDER	4	
16	08319-3110A	NUT	2	
17	09267-30010	BEARING (30X55X17)	1	
18	51643-41G00	COVER, STEERING UPPER	1	
19	51631-33E00	NUT, STEERING STEM	2	
20	51644-12C00	SEAL, STEERING LWR	1	
21	51641-33E00	WASHER, STEERING STEM	1	
22	09164-08015	WASHER	4	

FIG.524C




FIG.524C (1-L-6) STEERING STEM (DL1000AL8 E33)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	51410-31J00	BRACKET, UNDER	1	
2	51644-12C00	.SEAL, STEERING LOWER	1	
3	09267-30010	.BEARING (30X55X17)	1	
4	51328-44G10	BOLT	4	
5	51311-31J00-YTA	BRACKET, UPPER (BLACK)	1	
6	51147-31J00	BOLT	4	
7	51328-44G10	BOLT	2	
8	51321-17H10	BOLT	2	
9	51353-24F00	NUT, CAP	1	
10	51354-17H00	WASHER	2	
11	51355-16G00	WASHER	2	
12	51356-24F50	WASHER	1	
13	56211-31J00-YTA	HOLDER, HANDLE (BLACK)	2	
14	56221-08J00-YTA	HOLDER, HANDLE (BLACK)	2	
15	56245-31J00	RUBBER, HANDLE HOLDER	4	
16	08319-3110A	NUT	2	
17	09267-30010	BEARING (30X55X17)	1	
18	51643-41G00	COVER, STEERING UPPER	1	
19	51631-33E00	NUT, STEERING STEM	2	
20	51644-12C00	SEAL, STEERING LWR	1	
21	51641-33E00	WASHER, STEERING STEM	1	
22	09164-08015	WASHER	4	

FIG.524D




FIG.524D (1-L-7) STEERING STEM (DL1000XAL8 E03)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	51410-31J00	BRACKET, UNDER	1	
2	51644-12C00	.SEAL, STEERING LOWER	1	
3	09267-30010	.BEARING (30X55X17)	1	
4	51328-44G10	BOLT	4	
5	51311-31J00-YTA	BRACKET, UPPER (BLACK)	1	
6	51328-46H00	BOLT	4	
7	51328-44G10	BOLT	2	
8	51321-17H10	BOLT	2	
9	51353-24F00	NUT, CAP	1	
10	51354-17H00	WASHER	2	
11	51355-16G00	WASHER	2	
12	51356-24F50	WASHER	1	
13	56211-13K00-YTA	HOLDER, HANDLE (BLACK)	2	
14	56221-13K00-YTA	HOLDER, HANDLE (BLACK)	2	
15	56245-31J00	RUBBER, HANDLE HOLDER	4	
16	08319-3110A	NUT	2	
17	09267-30010	BEARING (30X55X17)	1	
18	51643-41G00	COVER, STEERING UPPER	1	
19	51631-33E00	NUT, STEERING STEM	2	
20	51644-12C00	SEAL, STEERING LWR	1	
21	51641-33E00	WASHER, STEERING STEM	1	
22	09164-08015	WASHER	4	
23	09250-06015	CAP, HANDLE BAR BOLT	4	

FIG.524E




FIG.524E (1-L-8) STEERING STEM (DL1000XAL8 E28)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	51410-31J00	BRACKET, UNDER	1	
2	51644-12C00	.SEAL, STEERING LOWER	1	
3	09267-30010	.BEARING (30X55X17)	1	
4	51328-44G10	BOLT	4	
5	51311-31J00-YTA	BRACKET, UPPER (BLACK)	1	
6	51328-46H00	BOLT	4	
7	51328-44G10	BOLT	2	
8	51321-17H10	BOLT	2	
9	51353-24F00	NUT, CAP	1	
10	51354-17H00	WASHER	2	
11	51355-16G00	WASHER	2	
12	51356-24F50	WASHER	1	
13	56211-13K00-YTA	HOLDER, HANDLE (BLACK)	2	
14	56221-13K00-YTA	HOLDER, HANDLE (BLACK)	2	
15	56245-31J00	RUBBER, HANDLE HOLDER	4	
16	08319-3110A	NUT	2	
17	09267-30010	BEARING (30X55X17)	1	
18	51643-41G00	COVER, STEERING UPPER	1	
19	51631-33E00	NUT, STEERING STEM	2	
20	51644-12C00	SEAL, STEERING LWR	1	
21	51641-33E00	WASHER, STEERING STEM	1	
22	09164-08015	WASHER	4	
23	09250-06015	CAP, HANDLE BAR BOLT	4	

FIG.524F





FIG.524F (1-L-9) STEERING STEM (DL1000XAL8 E33)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	51410-31J00	BRACKET, UNDER	1	
2	51644-12C00	.SEAL, STEERING LOWER	1	
3	09267-30010	.BEARING (30X55X17)	1	
4	51328-44G10	BOLT	4	
5	51311-31J00-YTA	BRACKET, UPPER (BLACK)	1	
6	51328-46H00	BOLT	4	
7	51328-44G10	BOLT	2	
8	51321-17H10	BOLT	2	
9	51353-24F00	NUT, CAP	1	
10	51354-17H00	WASHER	2	
11	51355-16G00	WASHER	2	
12	51356-24F50	WASHER	1	
13	56211-13K00-YTA	HOLDER, HANDLE (BLACK)	2	
14	56221-13K00-YTA	HOLDER, HANDLE (BLACK)	2	
15	56245-31J00	RUBBER, HANDLE HOLDER	4	
16	08319-3110A	NUT	2	
17	09267-30010	BEARING (30X55X17)	1	
18	51643-41G00	COVER, STEERING UPPER	1	
19	51631-33E00	NUT, STEERING STEM	2	
20	51644-12C00	SEAL, STEERING LWR	1	
21	51641-33E00	WASHER, STEERING STEM	1	
22	09164-08015	WASHER	4	
23	09250-06015	CAP, HANDLE BAR BOLT	4	

FIG.530A



DL1000AL8_E03_E28_530A
FRONT WHEEL

FIG.530A (1-L-10) FRONT WHEEL (DL1000AL8 E03)

REF NO.	PART NO.	DESCRIPTION	Q'TY		REMARKS
1	54111-31J00-019	WHEEL, FRONT (19M/CXMT2.50) (BLACK)	1		
2	54731-33E20	SPACER, FRONT WHEEL BEARING	1		
3	09262-25167	BEARING (25X52X15)	2		
4	09285-32004	OIL SEAL (32X52X7)	2		
5	54711-31J00	AXLE, FRONT	1		
6	54751-41G10	SPACER, FRONT AXLE	1		
7	54162-27G00	RING, SPEED SENSOR FRONT	1		
8	07130-0512A	BOLT	3		
9	59210-31J00	DISC, FRONT BRAKE	2		
10	09106-08160	BOLT (8X21)	10		
11	55110-31J00	TIRE, FRONT (110/80R19M/C 59V)	1		BW-501 RADIAL J BRIDGESTONE
12	43130-24A00	VALVE ASSY, WHEEL RIM (TR412)	1		
13	54712-47H00	NUT, FRONT AXLE	1		
14-1	55411-22H00	BALANCER, WHEEL NO.1	AR	10G	
14-2	55412-22H00	BALANCER, WHEEL NO.2	AR	20G	
14-3	55413-22H00	BALANCER, WHEEL NO.3	AR	30G	

This diagram illustrates the assembly of a motorcycle front wheel. The components are numbered as follows:

- 1: Wheel rim
- 2: Tire
- 3: Brake pad (inner)
- 4: Brake pad (outer)
- 5: Axle
- 6: Nut
- 7: Washer
- 8: Seal
- 9: Brake disc
- 10: Pin
- 11: Hub
- 12: Pin
- 13: Seal
- 14: Pin


The diagram shows the wheel (1) with the tire (2) mounted. The brake disc (9) is shown being attached to the hub (11) using the axle (5), nut (6), washer (7), and seal (8). The brake pads (3 and 4) are shown being attached to the disc (9) using the pins (10 and 12). The seal (13) is shown being attached to the hub (11). The pin (14) is shown being inserted into the hub (11).

FWD

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	54111-31J00-019	WHEEL, FRONT (19M/CXMT2.50) (BLACK)	1	
2	54731-33E20	SPACER, FRONT WHEEL BEARING	1	
3	09262-25167	BEARING (25X52X15)	2	
4	09285-32004	OIL SEAL (32X52X7)	2	
5	54711-31J00	AXLE, FRONT	1	
6	54751-41G10	SPACER, FRONT AXLE	1	
7	54162-27G00	RING, SPEED SENSOR FRONT	1	
8	07130-0512A	BOLT	3	
9	59210-31J00	DISC, FRONT BRAKE	2	
10	09106-08160	BOLT (8X21)	10	
11	55110-31J00	TIRE, FRONT (110/80R19M/C 59V)	1	BW-501 RADIAL J BRIDGESTONE
12	43130-24A00	VALVE ASSY, WHEEL RIM (TR412)	1	
13	54712-47H00	NUT, FRONT AXLE	1	
14-1	55411-22H00	BALANCER, WHEEL NO.1	AR	10G
14-2	55412-22H00	BALANCER, WHEEL NO.2	AR	20G
14-3	55413-22H00	BALANCER, WHEEL NO.3	AR	30G

DL1000AL8_E03_E28

FIG.530C




DL1000AL8_E03_E28_530C
FRONT WHEEL

FIG.530C (1-L-12) FRONT WHEEL (DL1000AL8 E33)

REF NO.	PART NO.	DESCRIPTION	Q'TY		REMARKS
1	54111-31J00-019	WHEEL, FRONT (19M/CXMT2.50) (BLACK)	1		
2	54731-33E20	SPACER, FRONT WHEEL BEARING	1		
3	09262-25167	BEARING (25X52X15)	2		
4	09285-32004	OIL SEAL (32X52X7)	2		
5	54711-31J00	AXLE, FRONT	1		
6	54751-41G10	SPACER, FRONT AXLE	1		
7	54162-27G00	RING, SPEED SENSOR FRONT	1		
8	07130-0512A	BOLT	3		
9	59210-31J00	DISC, FRONT BRAKE	2		
10	09106-08160	BOLT (8X21)	10		
11	55110-31J00	TIRE, FRONT (110/80R19M/C 59V)	1		BW-501 RADIAL J BRIDGESTONE
12	43130-24A00	VALVE ASSY, WHEEL RIM (TR412)	1		
13	54712-47H00	NUT, FRONT AXLE	1		
14-1	55411-22H00	BALANCER, WHEEL NO.1	AR	10G	
14-2	55412-22H00	BALANCER, WHEEL NO.2	AR	20G	
14-3	55413-22H00	BALANCER, WHEEL NO.3	AR	30G	

FIG.530D




DL1000AL8_E03_E28_530D
FRONT WHEEL

FIG.530D (1-L-13) FRONT WHEEL (DL1000XAL8 E03)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	54111-31J10	HUB, FRONT	1	
2	54731-33E20	SPACER, FR HUB BEARING	1	
3	09262-25167	BEARING (25X52X15)	2	
4	09285-32004	OIL SEAL (32X52X7)	2	
5-1	55311-31J00	RIM, FRONT WHEEL (BLACK) (19M/CXMT2.50)	1	
5-2	55311-31J10	RIM, FRONT WHEEL (GOLD) (19M/CXMT2.50)	1	
6	55321-11J00	SPOKE, FRONT WHEEL INNER	16	
7	55322-31J00	SPOKE, FRONT WHEEL OUTER	16	
8	55326-11J00	NIPPLE, FRONT WHEEL	32	
9	54162-27G00	RING, SPEED SENSOR FR (50T)	1	
10	07130-0512A	BOLT	3	
11	43130-24A00	VALVE ASSY, WHEEL RIM (TR412)	1	
12	54711-31J00	AXLE, FRONT	1	
13	54712-47H00	NUT, FR AXLE	1	
14	54751-41G10	SPACER, FRONT AXLE RH	1	
15	59210-31J00	DISC, FRONT BRAKE	2	
16	09106-08160	BOLT (8X21)	10	
17	55110-31J00	TIRE, FRONT (110/80R19M/C 59V)	1	BW-501 RADIAL J BRIDGESTONE
18	55411-11J00	WEIGHT, WHEEL BALANCE (5GRAM)	1	

FIG.530E




DL1000AL8_E03_E28_530E
FRONT WHEEL

FIG.530E (1-L-14) FRONT WHEEL (DL1000XAL8 E28)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	54111-31J10	HUB, FRONT	1	
2	54731-33E20	SPACER, FR HUB BEARING	1	
3	09262-25167	BEARING (25X52X15)	2	
4	09285-32004	OIL SEAL (32X52X7)	2	
5-1	55311-31J00	RIM, FRONT WHEEL (BLACK) (19M/CXMT2.50)	1	
5-2	55311-31J10	RIM, FRONT WHEEL (GOLD) (19M/CXMT2.50)	1	
6	55321-11J00	SPOKE, FRONT WHEEL INNER	16	
7	55322-31J00	SPOKE, FRONT WHEEL OUTER	16	
8	55326-11J00	NIPPLE, FRONT WHEEL	32	
9	54162-27G00	RING, SPEED SENSOR FR (50T)	1	
10	07130-0512A	BOLT	3	
11	43130-24A00	VALVE ASSY, WHEEL RIM (TR412)	1	
12	54711-31J00	AXLE, FRONT	1	
13	54712-47H00	NUT, FR AXLE	1	
14	54751-41G10	SPACER, FRONT AXLE RH	1	
15	59210-31J00	DISC, FRONT BRAKE	2	
16	09106-08160	BOLT (8X21)	10	
17	55110-31J00	TIRE, FRONT (110/80R19M/C 59V)	1	BW-501 RADIAL J BRIDGESTONE
18	55411-11J00	WEIGHT, WHEEL BALANCE (5GRAM)	1	

DL1000AL8_E03_E28

FIG.530F



DL1000AL8_E03_E28_530F
FRONT WHEEL

FIG.530F (1-L-15) FRONT WHEEL (DL1000XAL8 E33)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	54111-31J10	HUB, FRONT	1	
2	54731-33E20	SPACER, FR HUB BEARING	1	
3	09262-25167	BEARING (25X52X15)	2	
4	09285-32004	OIL SEAL (32X52X7)	2	
5-1	55311-31J00	RIM, FRONT WHEEL (BLACK) (19M/CXMT2.50)	1	
5-2	55311-31J10	RIM, FRONT WHEEL (GOLD) (19M/CXMT2.50)	1	
6	55321-11J00	SPOKE, FRONT WHEEL INNER	16	
7	55322-31J00	SPOKE, FRONT WHEEL OUTER	16	
8	55326-11J00	NIPPLE, FRONT WHEEL	32	
9	54162-27G00	RING, SPEED SENSOR FR (50T)	1	
10	07130-0512A	BOLT	3	
11	43130-24A00	VALVE ASSY, WHEEL RIM (TR412)	1	
12	54711-31J00	AXLE, FRONT	1	
13	54712-47H00	NUT, FR AXLE	1	
14	54751-41G10	SPACER, FRONT AXLE RH	1	
15	59210-31J00	DISC, FRONT BRAKE	2	
16	09106-08160	BOLT (8X21)	10	
17	55110-31J00	TIRE, FRONT (110/80R19M/C 59V)	1	BW-501 RADIAL J BRIDGESTONE
18	55411-11J00	WEIGHT, WHEEL BALANCE (5GRAM)	1	

FIG.533A




FIG.533A (2-B-2) HYDRAULIC UNIT

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	55610-31J10	UNIT ASSY, HYDRAULIC ABS	1	
2	55660-31J10	HOLDER, HYDRAULIC UNIT	1	
3	55661-10G00	BOLT (6X25)	3	
4	55662-10G00	SPACER, HYDRAULIC UNIT	3	
5	09320-10066	RUBBER	3	
6	01550-0612A	BOLT	3	



FIG.534A




FIG.534A (2-B-3) BODY ELECTRICAL

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	55710-31J10	SENSOR, FRONT WHEEL ABS	1	
2	65710-31J10	SENSOR, REAR WHEEL ABS	1	
3	09408-00266	CLAMP	2	
4	01547-0612A	BOLT	2	
5	55731-23H00	CLAMP, SENSOR LEAD	2	
6	09408-00307	CLAMP	4	
7	01547-0612A	BOLT	2	
8	39988-62R00	CLAMP	1	
9	55750-31J00	SENSOR, INERTIAL	1	
10	55760-31J00	BRACKET, INERTIAL SENSOR	1	
11	09160-06109	WASHER (6.5X18X1.6)	2	
12	09180-06331	SPACER (6.2X8.4X10.9)	2	
13	09320-08501	CUSHION	2	
14	01550-0616A	BOLT	2	
15	01550-0620A	BOLT	2	

FIG.535A




FIG.535A (2-B-4) FRONT CALIPER

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	59100-31J00-999	CALIPER ASSY, FRONT RH	1	
2	59100-31810	.PISTON SET	1	
3	59101-47810	..SEAL SET, PISTON	1	
4	59141-41G10	.PIN, PAD	2	
5	59151-29G00	.SPRING, PAD	1	
6	59121-18410	.BLEEDER	1	
7	55156-66310	.CAP BLEEDER PLUG	1	
8	59300-31J00-999	CALIPER ASSY, FRONT LH	1	
9	59100-31810	.PISTON SET	1	
10	59101-47810	..SEAL SET, PISTON	1	
11	59141-41G10	.PIN, PAD	2	
12	59151-29G00	.SPRING, PAD	1	
13	59121-18410	.BLEEDER	1	
14	55156-66310	.CAP BLEEDER PLUG	1	
15	59100-31820	PAD & SHIM SET	2	
16	59171-31J00	.SHIM	4	
17	09103-10392	BOLT (10X70)	4	
18	59151-41G00	PIN, CALIPER	4	

FIG.536A




FIG.536A (2-B-5) FRONT BRAKE HOSE

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	09360-10062	UNION	1	
2	09360-10062	UNION	1	
3	09360-10064	UNION	1	
4	09161-10009	WASHER (10X15X1.5)	7	
5	59200-31J20	HOSE ASSY, FRONT BRAKE NO.1	1	
6	59240-31J20	HOSE, FRONT BRAKE NO.2	1	
7	09403-06324	CLAMP	2	
8	09403-16412	CLAMP	1	
9	59400-31J20	HOSE ASSY, FR BRAKE NO.2	1	
10	09403-07334	CLAMP	1	
11	01547-0612A	BOLT	1	
12	01547-0616A	BOLT	1	
13	01547-0625A	BOLT	1	
14	59261-31J00	CLAMP, FRONT BRAKE HOSE NO.1	1	

FIG.537A




FIG.537A (2-B-6) FRONT MASTER CYLINDER

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	59600-10G50	CYLINDER ASSY, FRONT MASTER	1	
2	59600-45870	.PISTON/CUP SET	1	
3	59666-44300	..BOOT	1	
4	59667-49460	.DIAPHRAGM	1	
5	59668-41C00	.PLATE, DIAPHRAGM	1	
6	59669-10G20	.CAP	1	
7	69689-49300	.SCREW	2	
8	59671-32F00	.HOLDER	1	
9	59675-02FA0	.BOLT (6X22)	2	
10	59664-32F00	.PROTECTOR	1	

FIG.539A




FIG.539A (2-B-7) CLUTCH MASTER CYLINDER

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	59800-32F40	CYLINDER ASSY, CLUTCH MASTER	1	
2	59800-31810	.PISTON/CUP SET	1	
3	59866-23H00	..BOOT	1	
4	59871-23H10	.PUSH ROD	1	
5	59892-08A00	.BUSH	1	
6	59667-49460	.DIAPHRAGM	1	
7	59668-41C00	.PLATE, DIAPHRAGM	1	
8	59669-10G20	.CAP	1	
9	69689-49300	.SCREW	2	
10	59664-32F00	.PROTECTOR	1	
11	59671-32F00	.HOLDER	1	
12	59675-02FA0	.BOLT (6X22)	2	
13	09360-10062	UNION	2	
14	09161-10009	WASHER (10X15X1.5)	4	
15	59910-31J00	HOSE, CLUTCH	1	
16	59915-31J00	CLAMP, CLUTCH HOSE NO.1	1	
17	59921-31J00	CLAMP, CLUTCH HOSE NO.2	1	
18	01550-0612A	BOLT	2	

FIG.541A




FIG.541A (2-B-8) REAR SWINGINGARM

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	61000-31J10-YAP	SWINGING ARM ASSY, REAR (BLACK)	1	
2	61281-31J00	.SPACER (20.8X27.2X196.7)	1	
3	09263-20070	.BEARING (20X27X30)	1	
4	09263-27013	.BEARING (27X35X35)	2	
5	61251-41G00	SPACER, SWINGING ARM	2	
6	61211-31J00	SHAFT, RR SWINGING ARM PIVOT	1	
7	61214-42E10	NUT, PIVOT SHAFT	1	
8	09159-20006	NUT	1	
9	61273-31J00	BUFFER, CHAIN TOUCH DEFENSE	1	
10	09111-06072	BOLT (6X17.8)	2	
11	61446-40F00	ADJUSTER, CHAIN LH	1	
12	61445-40F00	ADJUSTER, CHAIN RH	1	
13	09100-08287	BOLT (8X50)	2	
14	08316-1008A	NUT	2	
15	61310-16G00	CASE, CHAIN	1	
16	09111-06107	BOLT (6X12)	2	
17	61124-33E00	PLATE, RR SWINGARM BRKT	1	
18	09125-06060	SCREW (6X12)	1	

FIG.543A (2-B-9) REAR CUSHION LEVER




FIG.550A




FIG.550A (2-B-10) REAR WHEEL (DL1000AL8 E03)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	64111-31J00-019	WHEEL, REAR (17M/CXMT4.00) (BLACK)	1	
2	64731-49G00	SPACER, REAR WHEEL BEARING	1	
3	09262-28052	BEARING (28X52X12)	2	
4	09284-37001	OIL SEAL (37X52X8)	1	
5	69211-06G00	DISC, REAR BRAKE	1	
6	09106-08160	BOLT (8X21)	4	
7	64162-17G00	RING, SPEED SENSOR REAR	1	
8	07130-0512A	BOLT	3	
9	64711-31J00	AXLE, REAR	1	
10	64721-17K00	NUT	1	
11	09160-25070	WASHER (25.2X42X3.2)	1	
12	64741-35F00	SPACER, REAR AXLE RH	1	
13	64751-47H00	SPACER, REAR AXLE LH	1	
14	64610-35F40	DRUM, REAR SPROCKET	1	
15	64733-35F00	RETAINER, REAR SPROCKET DRUM	1	
16	09262-32022	BEARING (32X65X17)	1	
17	09285-39001	OIL SEAL (39X65X7)	1	
18	64651-35F30	ABSORBER, REAR HUB SHOCK	5	
19	64511-35F20	SPROCKET, REAR (NT:41)	1	
20	08319-3110A	NUT	5	
21	65110-31J00	TIRE, REAR (150/70R17M/C 69V)	1	BW-502 RADIAL J BRIDGESTONE
22	43130-24A00	VALVE ASSY, WHEEL RIM (TR412)	1	
23-1	55411-22H00	BALANCER, WHEEL NO.1	AR	10G
23-2	55412-22H00	BALANCER, WHEEL NO.2	AR	20G
23-3	55413-22H00	BALANCER, WHEEL NO.3	AR	30G

FIG.550B





FIG.550B (2-B-11) REAR WHEEL (DL1000AL8 E28)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	64111-31J00-019	WHEEL, REAR (17M/CXMT4.00) (BLACK)	1	
2	64731-49G00	SPACER, REAR WHEEL BEARING	1	
3	09262-28052	BEARING (28X52X12)	2	
4	09284-37001	OIL SEAL (37X52X8)	1	
5	69211-06G00	DISC, REAR BRAKE	1	
6	09106-08160	BOLT (8X21)	4	
7	64162-17G00	RING, SPEED SENSOR REAR	1	
8	07130-0512A	BOLT	3	
9	64711-31J00	AXLE, REAR	1	
10	64721-17K00	NUT	1	
11	09160-25070	WASHER (25.2X42X3.2)	1	
12	64741-35F00	SPACER, REAR AXLE RH	1	
13	64751-47H00	SPACER, REAR AXLE LH	1	
14	64610-35F40	DRUM, REAR SPROCKET	1	
15	64733-35F00	RETAINER, REAR SPROCKET DRUM	1	
16	09262-32022	BEARING (32X65X17)	1	
17	09285-39001	OIL SEAL (39X65X7)	1	
18	64651-35F30	ABSORBER, REAR HUB SHOCK	5	
19	64511-35F20	SPROCKET, REAR (NT:41)	1	
20	08319-3110A	NUT	5	
21	65110-31J00	TIRE, REAR (150/70R17M/C 69V)	1	BW-502 RADIAL J BRIDGESTONE
22	43130-24A00	VALVE ASSY, WHEEL RIM (TR412)	1	
23-1	55411-22H00	BALANCER, WHEEL NO.1	AR 10G	
23-2	55412-22H00	BALANCER, WHEEL NO.2	AR 20G	
23-3	55413-22H00	BALANCER, WHEEL NO.3	AR 30G	


FIG.550C



DL1000AL8_E03_E28_550C
REAR WHEEL


FIG.550C (2-B-12) REAR WHEEL (DL1000AL8 E33)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	64111-31J00-019	WHEEL, REAR (17M/CXMT4.00) (BLACK)	1	
2	64731-49G00	SPACER, REAR WHEEL BEARING	1	
3	09262-28052	BEARING (28X52X12)	2	
4	09284-37001	OIL SEAL (37X52X8)	1	
5	69211-06G00	DISC, REAR BRAKE	1	
6	09106-08160	BOLT (8X21)	4	
7	64162-17G00	RING, SPEED SENSOR REAR	1	
8	07130-0512A	BOLT	3	
9	64711-31J00	AXLE, REAR	1	
10	64721-17K00	NUT	1	
11	09160-25070	WASHER (25.2X42X3.2)	1	
12	64741-35F00	SPACER, REAR AXLE RH	1	
13	64751-47H00	SPACER, REAR AXLE LH	1	
14	64610-35F40	DRUM, REAR SPROCKET	1	
15	64733-35F00	RETAINER, REAR SPROCKET DRUM	1	
16	09262-32022	BEARING (32X65X17)	1	
17	09285-39001	OIL SEAL (39X65X7)	1	
18	64651-35F30	ABSORBER, REAR HUB SHOCK	5	
19	64511-35F20	SPROCKET, REAR (NT:41)	1	
20	08319-3110A	NUT	5	
21	65110-31J00	TIRE, REAR (150/70R17M/C 69V)	1	BW-502 RADIAL J BRIDGESTONE
22	43130-24A00	VALVE ASSY, WHEEL RIM (TR412)	1	
23-1	55411-22H00	BALANCER, WHEEL NO.1	AR 10G	
23-2	55412-22H00	BALANCER, WHEEL NO.2	AR 20G	
23-3	55413-22H00	BALANCER, WHEEL NO.3	AR 30G	



DL1000AL8_E03_E28


FIG.550E



DL1000AL8_E03_E28_550E
REAR WHEEL

FIG.550E (2-B-14) REAR WHEEL (DL1000XAL8 E28)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	64111-31J10	HUB, REAR	1	
2-1	65311-31J00	RIM, REAR WHEEL (BLACK) (17M/CXMT4.00)	1	
2-2	65311-31J10	RIM, REAR WHEEL (GOLD) (17M/CXMT4.00)	1	
3	65321-31J00	SPOKE, REAR WHEEL INNER	16	
4	65322-31J00	SPOKE, REAR WHEEL OUTER	16	
5	55326-11J00	NIPPLE, REAR WHEEL	32	
6	64651-35F30	ABSORBER, REAR HUB SHOCK	5	
7	64162-17G00	RING, SPEED SENSOR RR (50T)	1	
8	07130-0512A	BOLT	3	
9	64731-49G00	SPACER (20.8X27.2X124)	1	
10	09262-28052	BEARING	2	
11	09284-37001	OIL SEAL (37X52X8)	1	
12	69211-06G00	DISC, REAR BRAKE	1	
13	09106-08160	BOLT (8X21)	4	
14	64741-35F00	SPACER, REAR AXLE RH	1	
15	64610-35F40	DRUM, REAR SPROCKET	1	
16	64711-31J00	AXLE, REAR	1	
17	64733-35F00	RETAINER, REAR SPROCKET DRUM	1	
18	64751-47H00	SPACER, REAR AXLE LH	1	
19	64721-17K00	NUT	1	
20	09262-32022	BEARING (32X65X17)	1	
21	09285-39001	OIL SEAL (39X65X7)	1	
22	64511-35F20	SPROCKET, REAR (NT:41)	1	
23	08319-3110A	NUT	5	
24	09160-25070	WASHER (25.2X42X3.2)	1	
25	65110-31J00	TIRE, REAR (150/70R17M/C 69V)	1	BW-502 RADIAL J BRIDGESTONE
26	43130-24A00	VALVE ASSY, WHEEL RIM (TR412)	1	
27	55411-11J00	WEIGHT, WHEEL BALANCE (5GRAM)	1	



DL1000AL8_E03_E28

FIG.555A





FIG.555A (2-C-2) REAR CALIPER

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	69100-31J00-999	CALIPER ASSY, REAR	1	
2	69100-44890	.PISTON SET	1	
3	69102-05880	..SEAL SET, PISTON	1	
4	59112-44B00	.BOOT, AXLE	1	
5	69115-44G00	.SPRING, PAD	1	
6	59141-40F00	.PIN, PAD	1	
7	69105-44G00	.PIN, BOLT	1	
8	69116-44G00	.RETAINER	1	
9	59121-18410	.BLEEDER	1	
10	55156-66310	.CAP, BLEEDER PLUG	1	
11	69150-31J00	.BRACKET	1	
12	69182-44G00	.BOLT	1	
13	69185-44G00	.SLEEVE	1	
14	69186-44G00	.BOOT, SLEEVE	1	
15	69101-44890	PAD SET	1	
16	69132-44G10	.INSULATOR	2	
17	69133-44G00	.SHIM	2	

FIG.558A



DL1000AL8_E03_E28_558A
REAR MASTER CYLINDER

FIG.558A (2-C-3) REAR MASTER CYLINDER

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	69600-31J00	CYLINDER ASSY, REAR MASTER	1	
2	69600-34830	.PISTON / CAP SET	1	
3	69691-00A00	..BOOT	1	
4	69692-44H00	.YOKE	1	
5	69670-31J00	.ROD, PUSH	1	
6	69693-05A00	.NUT	2	
7	69672-00B20	.CONNECTOR	1	
8	69686-34200	.O RING	1	
9	69674-00B20	.CIRCLIP	1	
10	09139-06029	SCREW (6X25)	2	
11	69740-18K00	TANK ASSY, RESERVOIR	1	
12	69667-01H00	.DIAPHRAGM	1	
13	69669-18K00	.CAP	1	
14	69689-01H00	.SCREW	2	
15	69668-01H00	.PLATE, DIAPHRAGM	1	
16	09111-06116	BOLT (6X16.5)	1	
17	69730-31J00	HOSE, RR RESERVOIR TANK	1	
18	09401-12404	CLIP	2	
19	09200-06068	PIN (6X18.2)	1	
20	08322-0106A	WASHER	1	
21	04111-2015A	PIN	1	
22	01547-0612A	BOLT	1	
23	69200-31J20	HOSE ASSY, REAR BRAKE NO.1	1	
24	69400-31J20	HOSE ASSY, REAR BRAKE NO.2	1	
25	09360-10062	UNION	2	
26	09161-10009	WASHER (10X15X1.5)	4	
27	02142-0616A	SCREW	2	
28	69243-16G00	GUIDE, REAR BRAKE HOSE	1	
29	61196-44H00	GUIDE, REAR BRAKE HOSE	1	
30	69261-31J00	CLAMP, RR BRAKE HOSE	1	
31	01547-0612A	BOLT	1	
32	69641-31J01	COVER, REAR MASTER CYLINDER	1	
33	69273-31J00	CUSHION, REAR BRAKE HOSE	1	
34	69486-31J00	WASHER, REAR BRAKE HOSE GUIDE	1	

DL1000AL8_E03_E28

FIG.901A




FIG.901A (2-C-4) OPTIONAL

REF NO.	PART NO.	DESCRIPTION	Q'TY		REMARKS
1	99000-25110	SUZUKI PBC GREASE	1	20G	
2-1	99000-32020	THREAD LOCK SUPER (1333B)	1	50G	
2-2	99000-32030	THREAD LOCK SUPER (1303B)	1	50G	
2-3	99000-32050	THREAD LOCK SUPER (1342)	1	50G	
2-4	99000-32100	THREAD LOCK SUPER (1305)	1	50G	
2-5	99000-32130	THREAD LOCK SUPER (1360)	1	50G	
3	99000-32040	THREAD LOCK CEMENT	1	200G	
4-1	99000-31140	SUZUKI BOND (1207B)(BLACK)	1	100G	
4-2	99000-31110	SUZUKI BOND (1215)	1	100G	
5	99000-25030	SUZUKI SUPER GREASE	1	150G	
6	99000-25140	SUZUKI MOLY PASTE	1	50G	

FIG.970A

FIG.970A (2-C-5) OPTIONAL (LOW SEAT)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	45100-31J70-BGQ	SEAT ASSY LOW	1	FOR YVB,YWW
1-2	45100-31J70-BGR	SEAT ASSY LOW	1	FOR YU1




FIG.970B

FIG.970B (2-C-6) OPTIONAL (HIGH SEAT)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	45100-31J80-BKK	SEAT ASSY HIGH	1	FOR YVB,YWW
1-2	45100-31J80-BKL	SEAT ASSY HIGH	1	FOR YU1




FIG.970C




FIG.970C (2-C-7) OPTIONAL (GRIP HEATER SET)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	57100-28860	HEATER SET, GRIP	1	

FIG.970D

FIG.970D (2-C-8) OPTIONAL (TOP CASE SET)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	93300-31820	CASE SET, TOP	1	




FIG.970E




FIG.970E (2-C-9) OPTIONAL (TOP CASE BRACKET SET)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	93900-31820	PLATE SET, TOP CASE	1	

FIG.970F




FIG.970F (2-C-10) OPTIONAL (SIDE CASE SET)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	93100-31820	CASE SET, SIDE	1	

FIG.970G





FIG.970G (2-C-11) OPTIONAL (SIDE CASE BRACKET SET)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	93700-31830	BRACKET SET, SIDE CASE	1	

FIG.970H

FIG.970H (2-C-12) OPTIONAL (CENTER STAND SET)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	42100-31820	STAND SET, CENTER	1	



PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
10000			112A-25	12892-41C00-255	126A-13-6
		11971-25D00	112A-30	12892-41C00-260	126A-13-7
		11971-33210	112A-2	12892-41C00-265	126A-13-8
		12111-31J10-0F0	120A-8	12892-41C00-270	126A-13-9
11100-31J00	104A-1	12140-31J00	120A-9	12892-41C00-275	126A-13-10
		12151-02F10	120A-10	12892-41C00-280	126A-13-11
11115-32E70	105A-1	12160-06G10	120A-4	12892-41C00-285	126A-13-12
		12163-06G00	120A-5	12892-41C00-290	126A-13-13
11117-33H00	105A-4	12164-31J00-0A0	120A-7-1	12892-41C00-295	126A-13-14
		12164-31J00-0B0	120A-7-2	12892-41C00-300	126A-13-15
11134-31J00	105A-9	12164-31J00-0C0	120A-7-3	12892-41C00-305	126A-13-16
		12164-31J00-0D0	120A-7-4	12892-41C00-310	126A-13-17
11141-31J00	105A-25	12165-27A50	120A-6	12892-41C00-315	126A-13-18
		12220-31J00	120A-1	12892-41C00-320	126A-13-19
	101A-2	12229-31J00-0A0	120A-2-1	12892-41C00-325	126A-13-20
		12229-31J00-0B0	120A-2-2	12892-41C00-330	126A-13-21
11171-31J40	104A-5	12229-31J00-0C0	120A-2-3	12892-41C00-335	126A-13-22
		12600-06B11	122A-4	12892-41C00-340	126A-13-23
11172-31J20	105A-20	12600-06G01	122A-6	12892-41C00-345	126A-13-24
11173-02F00	101A-3	12612-06G00	122A-1	12892-41C00-350	126A-13-25
	104A-21	12618-31G00	122A-7	12911-16G00	126A-5
		105A-21	12618-31G00	12912-02F10	126A-6
11178-17E00	101A-4	12652-38B00	120A-3	12921-06G00	126A-7
		104A-22	12701-06G00	12931-06G00	126A-8
	105A-22	12702-06G00	126A-2	12932-24400	126A-11
		104A-24	12703-06G00	12933-06G00	126A-9
11191-27E00	105A-24	12704-06G00	126A-4	13101-31J00	104A-16
11211-31J00-0F0	107A-1	12716-06G00	127A-19	13102-31J00	105A-16
		11221-31J00-0F0	107A-2	13170-40H01	104A-19
11241-31J00	101A-5	12750-31J10	127A-16		
	107A-3	12755-31J00	127A-17		105A-19
		101A-6	12760-23F20	13405-31J00	140A-1
11242-31J00	107A-4	12771-06G00	127A-1		140B-1
11269-18G01	163A-27	12800-41810	126A-14		140D-1
		11276-31J10	12810-06G00		140E-1
11277-31J10	163A-28	12837-19B10	127A-3	13405-31J10	140C-1
11306-06B31	108A-1	12830-30A01	127A-4		140F-1
		11319-33E00	108A-2	13453-36F00	140A-6
11340-06G40	112A-1	12832-02A00	127A-9		140B-6
11342-06G00	112A-7	12832-05A10	127A-6		140C-6
11351-31J10	112A-11	12833-30A01	127A-10		140D-6
11360-31J00	112A-20	12834-02A00	127A-11		140E-6
11362-31J00	112A-21		101A-10		140F-6
11381-06G00	112A-24	12837-24A10	127A-12		140A-3
11390-06G10	108A-18		101A-11	13575-29G00	140B-3
11401-31820	101A-1		127A-13		140C-3
11482-06G10	101A-7	12891-02F00	126A-12		140D-3
		12892-41C00-230	126A-13-1		140E-3
11483-02F10	112A-3	12892-41C00-235	126A-13-2		140F-3
		12892-41C00-240	126A-13-3	13580-27G21	140A-2
11485-02F10	112A-12	12892-41C00-245	126A-13-4		140B-2
		101A-9	12892-41C00-250		140C-2

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
			140C-2		140D-10
			140D-2		140E-10
			140E-2		140F-10
			140F-2		140C-19
13601-11J00		13685-04F10	140A-14	15717-58B00	140F-19
			140B-14		140A-8
		13700-31J00	155A-1		140B-8
		13738-31J00	155A-18		140C-8
		13741-31J00	155A-3		140D-8
		13746-31J00	155A-6		140E-8
		13746-31J10	155A-11		140F-8
			140F-14		
13602-06128		13780-31J00	155A-5	15722-14J00	140A-9
		13827-31J00	155A-7		140B-9
13602-29G00		13850-31J00	155A-19		140C-9
		13878-10G00	155A-9		140D-9
		13881-31J00	155A-2		140E-9
		13882-31J00	155A-12		140F-9
		13891-31J00	155A-4	15731-11J00	140A-12
		14150-31J00	163A-1		140B-12
13605-02F00		14160-31J00	163A-2		140C-12
		14181-31D00	101A-12		140D-12
		140B-4	140C-4		140E-12
		140C-4	140D-4		140F-12
		14205-31J02	163A-11		140A-13
		14250-21H00	163A-30	15732-11J00	140B-13
		14252-14J00	163A-31		140C-13
		14280-08J00	163A-32		140D-13
13627-31J00		14310-31J30-H01	163A-12		140E-13
		14459-31J10	163A-37		140F-13
		14771-18H00	163A-38		140A-14
13650-41F10		14771-42F40	101A-13	15810-31J00	172A-17
		13655-41F10	155A-16		172A-18
13662-22J00		140A-5	163A-9	15896-65J00	474A-10
		140B-5	163A-13		170A-11
		14780-31J00	163A-16	16321-02F00	170A-3
		14791-31J10	163A-17	16400-02F00	170A-1
		14795-10FA0	172A-1	16440-24F00	170A-7
		15100-31J01	172A-3	16510-07J00	170A-9
		15111-27G00	172A-4		170A-10
		15112-05H00	172A-5	16520-32E00	108A-12
13681-06G40		15113-05H00	172A-6	16591-06B01	427A-6
13683-31J00		15113-35F00	172A-8	17210-15H10	427B-6
		15114-14J00	172A-9		180A-1
13683-31J10		15115-08J00	172A-12	17410-31J10	101A-18
		15116-10F00	172A-13	17435-02F00	180A-5
13683-31J20		15116-31J00	172A-14		180A-3
		15151-31J00	172A-10	17470-02F10	180A-2
		15181-31J00	101A-14	17662-02F11	187A-17
		15201-35F00	172A-15		187A-19
		15420-05H00	172A-2	17670-06G50	187A-18
		15610-14J00	172A-7	17710-31J00	185A-1
13683-48G10		15710-31J00	140A-7	17730-14G00	187A-1
			140B-7		185A-6

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
17800-31J00	185A-2	21111-02F11	120A-12	25231-35F00	212A-2
17802-14F00	185A-8	21112-02F00	120A-13	25310-31J00	212A-6
17851-31J00	187A-2	21114-02F00	120A-14	25312-42F01	212A-8
17852-31J00	187A-3	21200-31Y11	201A-1	25350-06G00	212A-12
17853-02F10	187A-6	21411-31J10	201A-4	25355-38F00	212A-13
17856-16G10	187A-21	21412-31J00	201A-5	25381-13E30	212A-9
17890-06G20	187A-7	21413-31J00	201A-6	25411-02F20	212A-3
	187A-8	21414-31J00	201A-7		212A-4
17910-31J00	187A-11	21415-31J00	201A-35	25510-06G10	212A-16
17920-31J00	187A-25	21441-31J00	201A-8	25512-06G10	212A-17
17931-31J00	187A-12	21442-31J00	201A-9	25520-16G00	212A-24
17981-31J00	187A-16	21451-24F00	201A-10	25525-11C00	212A-26
17982-31J00	187A-14	21452-31J00	201A-11	25526-47000	212A-25
18117-52G10	140C-22	21462-31J10	201A-12		212A-28
	140F-22	21471-24F00	201A-13	25600-31J00	212A-27
18213-16H10	163A-40	21472-24F00	201A-14	25617-03F10	212A-30
18213-18H20	163A-41	23110-27A00	201A-19	25652-20C00	212A-29
18561-31J10	427A-12	23111-26D00	201A-20	25671-01011	212A-18
	427B-12	23121-31E00	201A-21	27510-20A40	206A-42
18561-31J20	427A-13	23160-06G20	201A-22	27531-31J00	206A-43
	427B-13	23163-06B00	201A-23	27600-06G40-120	206A-44
18561-31JB0	427A-11	23164-05A00	201A-24	27620-06G40	206A-45
	427B-11	23166-06G10	201A-27		
18563-31JA0	427A-14	23171-06G00	201A-32		
	427B-14	24120-06G00	206A-1		
18563-31JB0	427A-15	24130-02F20	206A-13		
	427B-15	24221-02F01	206A-2		
18571-31J10	427A-8	24231-02F30	206A-3		
	427B-8	24251-02F11	206A-4		
18572-31J00	427A-3	24252-02F10	206A-5		
	427B-3	24261-02F20	206A-6	31100-06G01	301A-1
18590-18K00	155A-13	24262-02F00	206A-7	31132-45C00	301A-2
18595-04K00	155A-14	24311-06G00	206A-14	31143-38300	301A-3
18803-02F01	496A-4	24321-02F11	206A-16	31150-44B10	301A-4
	496C-4	24322-02F01	206A-17	31156-48B00	301A-11
	496D-4	24331-02F20	206A-18	31170-02F10	301A-5
	496F-4	24332-17E20	206A-19	31170-43400	301A-6
18803-40F10	496B-3-1		206A-21	31172-38300	301A-7
	496E-3-1	24333-02F00	206A-25	31173-88C00	301A-8
18803-45G00	496B-3-2		206A-26	31264-44110	301A-9
	496E-3-2	24333-02F10	206A-27	31281-24B10	301A-10
		24341-02F20	206A-20	31497-45000	212A-37
		24351-02F20	206A-22	31800-06G00	312A-1
		24361-02F30	206A-23		312B-1
		24741-06G00	206A-36		312C-1
		24741-20A00	127A-24		312D-1
		24741-21A00	206A-37		312E-1
			212A-5		312F-1
		24751-06G00	206A-38		312A-2
		25211-17E02	212A-1		312B-2

20000

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
	312C-2		312B-8		312B-25
	312D-2		312C-8		312C-25
	312E-2		312D-8		312D-25
	312F-2		312E-8		312E-25
	303A-1		312F-8		312F-25
32101-31J00	303A-2	33510-31G00	312A-17	33972-31D00	474A-9
32102-31J00	303A-3		312B-17	34120-31JB0	330A-1
32371-13E30	312A-5		312C-17		330C-1
32800-31J00	312B-5		312D-17		330D-1
	312C-5		312E-17		330F-1
	312D-5		312F-17	34120-31JD0	330B-1
	312E-5	33510-31G10	312A-18		330E-1
	312F-5		312B-18	34124-31J00	330A-4
32920-31J12	312A-22		312C-18		330B-4
	312B-22		312D-18		330C-4
	312D-22		312E-18		330D-4
	312E-22		312F-18		330E-4
32920-31J22	312C-22	33542-06G00	312A-19		330F-4
	312F-22		312B-19	34126-31J00	330A-3
33410-06G00	312A-13		312C-19		330B-3
	312B-13		312D-19		330C-3
	312C-13		312E-19		330D-3
	312D-13	33542-06G10	312F-19		330E-3
	312E-13		312A-20		330F-3
	312F-13		312B-20	34150-28K00	330A-2
33410-17G00	312A-14		312C-20		330B-2
	312B-14		312D-20		330C-2
	312C-14		312E-20		330D-2
	312D-14		312F-20		330E-2
	312E-14	33542-38B00	312A-21		330F-2
	312F-14		312B-21	34152-28K00	330A-5
33410-20H00	312A-15		312C-21		330B-5
	312B-15		312D-21		330C-5
	312C-15		312E-21		330D-5
	312D-15		312F-21		330E-5
	312E-15	33620-31J00	310A-1		330F-5
	312F-15	33652-16G00	310A-2	34183-29F00	330A-6
33410-26G00	312A-16	33652-28C00	310A-3		330B-6
	312B-16	33652-31J00	310A-4		330C-6
	312C-16	33652-38A10	401A-5		330D-6
	312D-16		401A-9		330E-6
	312E-16	33810-31J10	310A-6		330F-6
	312F-16	33860-31J10	310A-7	34189-08J00	330A-7
33414-31J00	312A-7	33960-06G10	312A-23		330B-7
	312B-7		312B-23		330C-7
	312C-7		312C-23		330D-7
	312D-7		312D-23		330E-7
	312E-7		312E-23		330F-7
	312F-7		312F-23		482A-9
33424-31J00	312A-8	33970-47H01	312A-25	34810-31J00	172A-11

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
35100-31J01	333A-1		350D-10		350F-15
35142-31J00	333A-4		350E-10	37820-33D10	108A-30
35171-31J00	333A-2		350F-10	37822-33D00	108A-31
35179-31J00	333A-3	36620-31J10	350A-9	37840-24F00	350A-17
35601-08JA0	334A-1		350B-9		350B-17
35602-08JB0	334A-5		350C-9		350C-17
35603-08JA0	334A-11		350D-9		350D-17
35604-08JA0	334A-15		350E-9		350E-17
35612-08JA0	334A-2		350F-9		350F-17
	334A-16	36651-48E00	310A-9	38500-41F50	350A-19
35629-18G00	334A-9	36654-06J20	350A-21		350B-19
35632-08JA0	334A-6		350B-21		350C-19
	334A-12		350C-21		350D-19
35710-31J01	339A-1		350D-21		350E-19
35910-41GC2	339A-4		350E-21		350F-19
35912-41G01	339A-5		350F-21	38610-06F00	334A-20
35913-41G00	339A-6	36851-31J10	350A-23	38850-31J00	350A-28
35917-41G00	339A-8		350B-23		350B-28
35927-14J30	339A-12		350C-23		350C-28
35950-13K00	460A-4		350D-23		350D-28
	460B-4		350E-23		350E-28
	460C-4		350F-23		350F-28
	460D-4	36854-31J20	350A-26	38860-76F01	350A-6
	460E-4		350B-26		350A-7
	460F-4		350C-26		350A-8
	460G-4		350D-26		350B-6
	460H-4		350E-26		350B-7
	460J-4		350F-26		350B-8
35970-13K00	339A-15	36856-31J10	350A-25		350C-6
36610-31JN0	350A-1		350B-25		350C-7
	350B-1		350C-25		350C-8
	350D-1		350D-25		350D-6
	350E-1		350E-25		350D-7
36610-31JP0	350C-1		350F-25		350D-8
	350F-1	37100-31JE0	352A-2		350E-6
36618-18G10	350A-11		352B-2		350E-7
	350B-11	37102-31850	352B-1		350E-8
	350C-11	37102-31860	352A-1		350F-6
	350D-11	37146-13K00	352A-7		350F-7
	350E-11		352B-8		350F-8
	350F-11	37180-15H01	352A-4	39988-62R00	534A-8
36618-31J00	350A-24		352B-4		
	350B-24	37200-31J10	355A-1		
	350C-24	37400-31J10	355A-3		
	350D-24	37730-31J00	212A-36		
	350E-24	37740-31D00	350A-15		
	350F-24		350B-15		
36618-41G00	350A-10		350C-15	40000	
	350B-10		350D-15		
	350C-10		350E-15		

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
41100-31J10-YAP	401A-1	43811-31J00-YAP	415A-25	44176-31J00	423A-13
41200-31J20-YAP	401A-2	43821-31J00-YAP	415A-26		423B-13
41921-16G00	401A-14	44100-31J30-YVB	420B-1-1		423C-13
41921-47H00	401A-17		420D-1-1		423D-13
41922-19F20	401A-13		420F-1-1		423E-13
41922-33E20	401A-15	44100-31J30-YWW	420B-1-2		423F-13
41941-19F01	401A-16		420D-1-2		423G-13
41942-02F00	401A-18		420F-1-2		423H-13
42100-31820	970H-1	44100-31JA0-YU1	420A-1		423J-13
42310-31J11	407A-1		420C-1	44177-31J00	423A-14
42321-03FK0	407A-3		420E-1		423B-14
42330-31J00	407A-6		420G-1-1		423C-14
43111-31J00	407A-8		420H-1-1		423D-14
43130-24A00	530A-12		420J-1-1		423E-14
	530B-12	44100-31JA0-YVB	420G-1-2		423F-14
	530C-12		420H-1-2		423G-14
	530D-11		420J-1-2		423H-14
	530E-11	44100-31JA0-YWW	420G-1-3		423J-14
	530F-11		420H-1-3	44178-31J00	423A-15
	550A-22		420J-1-3		423B-15
	550B-22	44160-31J00	444A-6		423C-15
	550C-22		444B-4		423D-15
	550D-26		444C-6		423E-15
	550E-26		444D-4		423F-15
	550F-26		444E-6		423G-15
43251-31J00	407A-12		444F-4		423H-15
43259-31J00	350A-16		444G-6		423J-15
	350B-16		444H-6	44179-31J00	420A-19
	350C-16		444J-6		420B-18
	350D-16	44164-31J00	444A-8		420C-19
	350E-16		444B-6		420D-18
	350F-16		444C-8		420E-14
43501-31J00	415A-4		444D-6		420F-13
43502-31J00	415A-10		444E-8		420G-19
43510-06G01-YAP	415A-1		444F-6		420H-19
43521-06G01-YAP	415A-2		444G-8		420J-14
43551-06G00	415A-6		444H-8	44180-31J10-4TX	423G-4-2
	415A-12		444J-8		423H-4-2
43552-06G00	415A-7	44170-31J10-4TX	423G-2-2		423J-4-2
	415A-13		423H-2-2	44180-31J10-YKV	423A-4
43576-31J00	415A-5		423J-2-2		423C-4
	415A-11	44170-31J10-YKV	423A-2		423E-4
43580-31J00	401A-4		423C-2		423G-4-1
43590-31J00	401A-8		423E-2		423H-4-1
43610-34A30	415A-19		423G-2-1		423J-4-1
43612-33G01	415A-20		423H-2-1	44180-31J20-PGZ	423B-4
	415A-23		423J-2-1		423D-4
43631-31J00	415A-21	44170-31J20-PGZ	423B-2		423F-4
	415A-24		423D-2	44189-31J00	420A-20
43710-34A30	415A-22		423F-2		420B-19

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
	420C-20		423H-6		420D-13
	420D-19		423J-6		420G-14
	420E-15	44276-21H00	420A-24		420H-14
	420F-14		420B-23	44424-31J10	420A-16
	420G-20		420C-24		420B-15
	420H-20		420D-23		420C-16
	420J-15		420E-19		420D-15
44191-31J00-PGZ	423B-1		420F-18		420G-16
	423D-1		420G-24		420H-16
	423F-1		420H-24	44424-31J20	420A-13
44191-31J00-YKV	423A-1		420J-19		420B-12
	423C-1	44277-01H00	423A-11		420C-13
	423E-1		423B-11		420D-12
	423G-1		423C-11		420G-13
	423H-1		423D-11		420H-13
	423J-1		423E-11	44434-31J01	427A-1
44193-31J00	444A-1		423F-11		427B-1
	444B-1		423G-11	44480-31J00	420A-28
	444C-1		423H-11		420B-27
	444D-1		423J-11		420C-28
	444E-1	44280-31J00	423A-8		420D-27
	444F-1		423B-8		420E-23
	444G-1		423C-8		420F-22
	444H-1		423D-8		420G-28
	444J-1		423E-8		420H-28
44200-17820	420A-3		423F-8		420J-23
	420B-2		423G-8	44511-16G00	444A-13
	420C-3		423H-8		444B-11
	420D-2		423J-8		444C-13
	420E-3	44423-31J11	420A-29		444D-11
	420F-2		420B-28		444E-13
	420G-3		420C-29		444F-11
	420H-3		420D-28		444G-13
	420J-3		420E-24		444H-13
44244-11J00	420A-4		420F-23		444J-13
	420B-3		420G-29	44512-16G00	444A-12
	420C-4		420H-29		444B-10
	420D-3		420J-24		444C-12
	420E-4	44423-31J20	420A-12		444D-10
	420F-3		420B-11		444E-12
	420G-4		420C-12		444F-10
	420H-4		420D-11		444G-12
	420J-4		420E-12		444H-12
44270-31J00	423A-6		420F-11		444J-12
	423B-6		420G-12	44520-31J01	444A-9
	423C-6		420H-12		444B-7
	423D-6		420J-12		444C-9
	423E-6	44424-15H10	420A-14		444D-7
	423F-6		420B-13		444E-9
	423G-6		420C-14		444F-7

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
	444G-9		420F-17		420B-24
	444H-9		420G-23		420C-25
	444J-9		420H-23		420D-24
44523-47H00	420A-22		420J-18		420E-20
	420B-21	44543-31J00	444A-20		420F-19
	420C-22		444B-18		420G-25
	420D-21		444C-20		420H-25
	420E-17		444D-18		420J-20
	420F-16		444E-20		423A-24
	420G-22		444F-18		423B-24
	420H-22		444G-20		423C-24
	420J-17		444H-20		423D-24
44530-06G00	420A-10		444J-20		423E-24
	420B-9	44544-31J00	420A-27		423F-24
	420C-10		420B-26		423G-24
	420D-9		420C-27		423H-24
	420E-10		420D-26		423J-24
	420F-9		420E-22	44560-31J00	444A-17
	420G-10		420F-21		444A-18
	420H-10		420G-27		444B-15
	420J-10		420H-27		444B-16
44534-24F00	312A-28		420J-22		444C-17
	312B-28	44545-06G00	420A-8		444C-18
	312C-28		420B-7		444D-15
	312D-28		420C-8		444D-16
	312E-28		420D-7		444E-17
	312F-28		420E-8		444E-18
44541-31J00	420A-5		420F-7		444F-15
	420B-4		420G-8		444F-16
	420C-5		420H-8		444G-17
	420D-4		420J-8		444G-18
	420E-5	44545-31J00	420A-32		444H-17
	420F-4		420B-31		444H-18
	420G-5		420C-32		444J-17
	420H-5		420D-31		444J-18
	420J-5		420E-26	44561-35F00	444A-15
44542-06G00	420A-9		420F-25		444B-13
	420B-8		420G-32		444C-15
	420C-9		420H-32		444D-13
	420D-8		420J-26		444E-15
	420E-9	44550-31J00	420A-6		444F-13
	420F-8		420B-5		444G-15
	420G-9		420C-6		444H-15
	420H-9		420D-5		444J-15
	420J-9		420E-6	44612-13600	423A-10
44542-31J00	420A-23		420F-5		423B-10
	420B-22		420G-6		423C-10
	420C-23		420H-6		423D-10
	420D-22		420J-6		423E-10
	420E-18	44552-24B00	420A-25		423F-10

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
	423G-10	47111-31J10	445A-1	51147-31J00	524A-6
	423H-10	47121-31J00	445A-7		524B-6
	423J-10	47211-31J10	445A-2		524C-6
45100-31J10-BGQ	505A-1-1	47411-31J00	445A-3	51152-31J00	521A-16
45100-31J10-BGR	505A-1-2	47414-31J10	406A-1		521A-33
45100-31J70-BGQ	970A-1-1	47420-31J00	406A-2	51153-44G00	521A-4
45100-31J70-BGR	970A-1-2	47422-31J00	406A-9		521A-21
45100-31J80-BKK	970B-1-1	47423-31J00	406A-3	51156-14200	521A-5
45100-31J80-BKL	970B-1-2	47431-31J10	406A-4		521A-22
45149-31300	505A-2	47510-28K00	445A-12	51158-14200	521A-3
45213-13601	505A-5	47511-31J00	445A-4		521A-20
45215-26F00	505A-6	47911-31J00	481A-19	51158-40F30	521A-10
45220-47H00	505A-9	47912-31J00	474A-8		521A-27
45256-31J00	505A-8	47913-31J00	445A-9	51166-24F60	521A-35
45280-18G01	505A-14	47914-31J00	483A-8	51171-31J00	521A-9
45288-14F00	505A-10	47915-31J00	460A-3		521A-26
45289-05H00	423A-25		460B-3	51173-02FA0	521A-6
	423B-25		460C-3		521A-23
	423C-25		460D-3	51176-48G10	521A-11
	423D-25		460E-3		521A-28
	423E-25		460F-3	51178-31J00	521A-17
	423F-25		460G-3		521A-34
	423G-25		460H-3	51311-31J00-YTA	524A-5
	423H-25		460J-3		524B-5
	423J-25	48410-31JB0	481A-2		524C-5
45289-11F00	505A-12	48414-31J00	481A-12		524D-5
45517-31J00	423A-7	48415-31J00	481A-7		524E-5
	423A-9	48420-31J00	482A-3		524F-5
	423B-7	48430-31J00	482A-4	51321-17H10	524A-8
	423B-9	48599-57L00	350A-29		524B-8
	423C-7		350B-29		524C-8
	423C-9		350C-29		524D-8
	423D-7		350D-29		524E-8
	423D-9		350E-29		524F-8
	423E-7		350F-29	51328-44G10	524A-4
	423E-9				524A-7
	423F-7				524B-4
	423F-9	50000			524B-7
	423G-7				524C-4
	423G-9				524C-7
	423H-7	51103-31J30	521A-1		524D-4
	423H-9	51104-31J30	521A-18		524D-7
	423J-7	51110-31J20	521A-2		524E-4
	423J-9	51112-31J00	521A-15		524E-7
46311-31J01	412A-1		521A-32		524F-4
	412B-1	51120-31J20	521A-19		524F-7
	412C-1	51131-31J30	521A-12	51328-46H00	524D-6
	412D-1		521A-29		524E-6
	412E-1	51146-31J00	521A-7		524F-6
	412F-1		521A-24	51351-31J30	521A-13

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
	521A-30		524E-18	54731-33E20	530A-2
51352-13A60	521A-8		524F-18		530B-2
	521A-25	51644-12C00	524A-2		530C-2
51353-24F00	524A-9		524A-20		530D-2
	524B-9		524B-2		530E-2
	524C-9		524B-20		530F-2
	524D-9		524C-2	54751-41G10	530A-6
	524E-9		524C-20		530B-6
	524F-9		524D-2		530C-6
51354-17H00	524A-10		524D-20		530D-14
	524B-10		524E-2		530E-14
	524C-10		524E-20		530F-14
	524D-10		524F-2	55110-31J00	530A-11
	524E-10		524F-20		530B-11
	524F-10	53100-31J10-GWM	460B-1		530C-11
51355-16G00	524A-11		460D-1		530D-17
	524B-11		460F-1		530E-17
	524C-11	53100-31J20-BG7	460A-1		530F-17
	524D-11		460C-1	55156-66310	535A-7
	524E-11		460E-1		535A-14
	524F-11		460G-1-1		555A-10
51356-24F50	524A-12		460H-1-1	55311-31J00	530D-5-1
	524B-12		460J-1-1		530E-5-1
	524C-12	53100-31J20-BG8	460G-1-2		530F-5-1
	524D-12		460H-1-2	55311-31J10	530D-5-2
	524E-12		460J-1-2		530E-5-2
	524F-12	54111-31J00-019	530A-1		530F-5-2
51410-31J00	524A-1		530B-1	55321-11J00	530D-6
	524B-1		530C-1		530E-6
	524C-1	54111-31J10	530D-1		530F-6
	524D-1		530E-1	55322-31J00	530D-7
	524E-1		530F-1		530E-7
	524F-1	54162-27G00	530A-7		530F-7
51553-15D40	310A-5		530B-7	55326-11J00	530D-8
51631-33E00	524A-19		530C-7		530E-8
	524B-19		530D-9		530F-8
	524C-19		530E-9		550D-5
	524D-19	54711-31J00	530F-9		550E-5
	524E-19		530A-5		550F-5
	524F-19		530B-5	55411-11J00	530D-18
51641-33E00	524A-21		530C-5		530E-18
	524B-21		530D-12		530F-18
	524C-21		530E-12		550D-27
	524D-21		530F-12		550E-27
	524E-21	54712-47H00	530A-13		550F-27
	524F-21		530B-13	55411-22H00	530A-14-1
51643-41G00	524A-18		530C-13		530B-14-1
	524B-18		530D-13		530C-14-1
	524C-18		530E-13		550A-23-1
	524D-18		530F-13		550B-23-1

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
55412-22H00	550C-23-1	56272-10G00	524F-15	58300-31J00	462A-12
	530A-14-2		462A-3		462B-12
	530B-14-2		462B-3		462C-12
	530C-14-2		462C-3		462D-12
55413-22H00	550A-23-2	56272-42F00	462D-3	58620-31J00	462E-12
	550B-23-2		462E-3		462F-12
	550C-23-2		462F-3		462A-13
	530A-14-3		462A-4		462B-13
55610-31J10	530B-14-3	56273-10G10	462B-4	58620-31J10	462C-13
	530C-14-3		462C-4		462D-13
	550A-23-3		462D-4		462E-13
	550B-23-3		462E-4		462F-13
55660-31J10	550C-23-3	56500-04F30	462F-4	59100-31810	462A-15
	533A-1		462A-5		462B-15
	533A-2		462B-5		462C-15
	533A-3		462C-5		462D-15
55661-10G00	533A-4	56500-04F30	462D-5	59100-31820	462E-15
55662-10G00	534A-1		462E-5		462F-15
55710-31J10	534A-5		462F-5		535A-2
55731-23H00	534A-9		462A-10		535A-9
55750-31J00	534A-10	56600-04F30	462B-10	59100-31820	535A-15
55760-31J00	462A-1		462C-10		535A-1
56111-31J10-YAP	462B-1		462D-10		535A-3
56111-31JA0-YUS	462C-1		462E-10	59101-47810	535A-10
	462D-1	56600-04F30	462F-10		555A-4
	462E-1		462A-11		201A-25
	462F-1		462B-11		535A-6
56200-04830	462D-2	56600-04F30	462C-11	59122-46H00	535A-13
	462E-2		462D-11		555A-9
	462F-2		462E-11		201A-26
	462A-2		462F-11		555A-6
56200-32851	462B-2	57100-28860	970C-1	59141-40F00	535A-4
	462C-2		467A-2		535A-11
	524D-13		467A-1		535A-5
	524E-13		467A-9		535A-12
56211-13K00-YTA	524F-13	57100-42F00	467A-4	59151-29G00	535A-18
	524A-13		472A-1		535A-16
	524B-13		462A-6		536A-5
	524C-13		462B-6		530A-9
56211-31J00-YTA	524A-14	57341-31J00-291	462C-6	59210-31J00	530B-9
	524B-14		462D-6		530C-9
	524C-14		462E-6		530D-15
	524D-14		462F-6		530E-15
56221-08J00-YTA	524E-14	57346-31J00	467A-5	59240-31J20	530F-15
	524F-14		467A-11		536A-6
	524A-15		467A-7		536A-14
	524B-15		467A-8		536A-8
56221-13K00-YTA	524C-15	57500-06G20	467A-10	59300-31J00-999	536A-9
	524D-15		472A-2		537A-1
	524E-15		467A-13		537A-2
	524E-15		57560-02FA0		537A-2

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
59664-32F00	537A-10	62658-37F10	543A-11	64731-49G00	550A-2
	539A-10	62668-42A02	543A-3		550B-2
59666-44300	537A-3		543A-6		550C-2
59667-49460	537A-4	63111-31J10-291	474A-1		550D-9
	539A-6	63112-31J00-291	474A-2		550E-9
59668-41C00	537A-5	63115-37H00	401A-6		550F-9
	539A-7		401A-10	64733-35F00	550A-15
59669-10G20	537A-6	63411-31J10	474A-4		550B-15
	539A-8	64111-31J00-019	550A-1		550C-15
59671-32F00	537A-8		550B-1		550D-17
	539A-11		550C-1		550E-17
59675-02FA0	537A-9	64111-31J10	550D-1		550F-17
	539A-12		550E-1	64741-35F00	550A-12
59800-31810	539A-2		550F-1		550B-12
59800-32F40	539A-1	64162-17G00	550A-7		550C-12
59866-23H00	539A-3		550B-7		550D-14
59871-23H10	539A-4		550C-7		550E-14
59892-08A00	539A-5		550D-7		550F-14
59910-31J00	539A-15		550E-7	64751-47H00	550A-13
59915-31J00	539A-16		550F-7		550B-13
59921-31J00	539A-17	64511-35F20	550A-19		550C-13
			550B-19		550D-18
			550C-19		550E-18
			550D-22		550F-18
			550E-22	65110-31J00	550A-21
		64610-35F40	550F-22		550B-21
			550A-14		550C-21
			550B-14		550D-25
			550C-14		550E-25
			550D-15		550F-25
61000-31J10-YAP	541A-1		550E-15	65311-31J00	550D-2-1
61124-33E00	541A-17		550F-15		550E-2-1
61196-44H00	558A-29	64651-35F30	550A-18		550F-2-1
61211-31J00	541A-6		550B-18	65311-31J10	550D-2-2
61214-42E10	541A-7		550C-18		550E-2-2
61251-41G00	541A-5		550D-6		550F-2-2
61273-31J00	541A-9		550E-6	65321-31J00	550D-3
61281-31J00	541A-2		550F-6		550E-3
61310-16G00	541A-15	64711-31J00	550A-9		550F-3
61445-40F00	541A-12		550B-9	65322-31J00	550D-4
61446-40F00	541A-11		550C-9		550E-4
62100-31JD0-YKS	543A-13		550D-16		550F-4
62278-14100	521A-14		550E-16	65710-31J10	534A-2
	521A-31		550F-16	68110-31J00-AA3	420G-2-2
62317-27C10	543A-2	64721-17K00	550A-10		420H-2-2
62317-44B00	543A-5		550B-10		420J-2-2
62317-47H00	543A-15		550C-10	68110-31J00-BGZ	420G-2-3
62611-31J00	543A-1		550D-19		420H-2-3
62641-31J00	543A-8		550E-19		420J-2-3
62647-47H00	543A-10		550F-19	68110-31J00-GY8	420A-2

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
68111-47HA0	420C-2	68241-31J00	420A-18	68391-06G80	496D-3
	420E-2		420B-17		496F-3
	420G-2-1		420C-18		412A-3
	420H-2-1		420D-17		412C-3
	420J-2-1		420E-13		412D-3
	423A-22		420F-12		412F-3
	423B-22		420G-18		412B-3
	423C-22		420H-18		412E-3
	423D-22		420J-13		555A-1
	423E-22		444A-3		555A-2
68121-31J00-BG9	423F-22	68275-31J00-BG5	444C-3	68391-06G90	555A-15
	423G-22		444E-3		555A-3
	423H-22		444G-3-1		555A-7
	423J-22		444H-3-1		555A-5
	423B-3		444J-3-1		555A-8
	423D-3		444G-3-2		555A-16
	423F-3		444H-3-2		555A-17
	423G-3-2		444J-3-2		555A-11
	423H-3-2		423A-20		555A-12
	423J-3-2		423B-20		555A-13
68125-31J00-BHA	423A-3	68275-31J00-BG6	423C-20	68281-47HA0	555A-14
	423C-3		423D-20		558A-23
	423E-3		423E-20		550A-5
	423G-3-1		423F-20		550B-5
	423H-3-1		423G-20		550C-5
	423J-3-1		423H-20		550D-12
	423B-5		423J-20		550E-12
	423D-5		444A-5		550F-12
	423F-5		444C-5		558A-28
	423G-5-2		444E-5		558A-30
68135-31J00-BG4	423H-5-2	68285-31J00-BG5	444G-5-1	68243-16G00	558A-33
	423J-5-2		444H-5-1		558A-24
	423A-5		444J-5-1		558A-34
	423C-5		444G-5-2		558A-1
	423E-5		444H-5-2		558A-2
	423G-5-1		444J-5-2		558A-32
	423H-5-1		496A-1		558A-12
	423J-5-1		496C-1		558A-15
	460A-2		496D-1		558A-13
	460C-2		496F-1		558A-5
68150-31J00-BG7	460E-2	68319-49J00	496B-1	68391-06G80	558A-7
	460G-2-1		496E-1		558A-9
	460H-2-1		496B-2		558A-8
	460J-2-1		496E-2		558A-14
	460G-2-2		496A-2		537A-7
	460H-2-2		496C-2		539A-9
	460J-2-2		496D-2		558A-3
	460B-2		496F-2		558A-4
	460D-2		496A-3		558A-6
	460F-2		496C-3		558A-17

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
69740-18K00	558A-11	94430-31J20-5JX	444F-3-2	99000-25110	901A-1
			444G-4-2	99000-25140	901A-6
			444H-4-2	99000-31110	901A-4-2
			444J-4-2	99000-31140	901A-4-1
			444A-4	99000-32020	901A-2-1
		94430-31J20-YMD	444C-4	99000-32030	901A-2-2
			444E-4	99000-32040	901A-3
			444G-4-1	99000-32050	901A-2-3
			444H-4-1	99000-32100	901A-2-4
			444J-4-1	99000-32130	901A-2-5
73415-70A00	481A-5 481A-10	94441-31J00-291	481A-15	99000-69471	126A-15
		94451-31J00-291	481A-16	99011-31J53-01A	496B-4-1
		94461-31J00	481A-17		496E-4-1
		94462-31J00	481A-18	99011-31J53-01F	496B-4-2
		94470-31J00	483A-1		496E-4-2
		94473-31J00	483A-2	99011-31J53-029	496B-4-3
		94474-17H00	505A-4		496E-4-3
		94474-31J00	483A-3	99011-31J53-03A	496A-5
		94479-35F00	445A-8		496C-5
				474A-5	
93100-31820	970F-1	94480-31J00	483A-4		496F-5
93300-31820	970D-1	94483-31J00	483A-5		
93700-31830	970G-1	94484-31J00	483A-6		
93900-31820	970E-1	94491-31J01	483A-7		
94402-31J10	481A-4	94510-31J00	482A-1		
94411-31J10-YKV	481A-1	94530-06G00	483A-13		
94413-31J10	481A-13	94530-31J00	483A-11		
94414-31J10	481A-14	94540-06G00	483A-14		
94420-31J10-YVB	444B-2-1	94540-31J00	483A-12		
	444D-2-1	94630-31J10	481A-9		
	444F-2-1	94642-10GA0	423A-12	01421-0620A	107A-7
94420-31J10-YVWW	444B-2-2		423B-12	01547-0512B	352A-6
	444D-2-2		423C-12		352B-6
	444F-2-2		423D-12	01547-0516A	163A-34
	444G-2-2		423E-12	01547-0612A	462A-14
	444H-2-2		423F-12		462B-14
94420-31J20-YMD	444J-2-2		423G-12		462C-14
	444A-2		423H-12		462D-14
	444C-2		423J-12		462E-14
	444E-2	95643-58J00	330A-8		462F-14
	444G-2-1		330B-8		534A-4
94429-21E00	444H-2-1		330C-8		534A-7
	444J-2-1		330D-8		536A-11
	401A-7		330E-8		558A-22
	401A-11		330F-8		558A-31
	444B-3-1	95700-14F00	505A-11	01547-0616A	536A-12
	444D-3-1	95700-31870	352B-7	01547-0625A	112A-27
	444F-3-1	96514-17K00	474A-11		212A-33
94430-31J10-YVWW	444B-3-2	96514-17K10	474A-12		301A-14
	444D-3-2	99000-25030	901A-5		536A-13

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
01547-0630A	108A-4		420C-7	03541-0516A	339A-3
01547-0635A	112A-28		420D-6	03541-0516B	483A-10
01547-0670A	108A-5		420E-7	03541-0520B	155A-8
01547-0685A	108A-6		420F-6	04111-2015A	558A-21
01550-0610A	112A-9		420G-7	04211-09149	112A-4
	187A-26		420H-7		112A-13
01550-0612A	104A-12		420J-7		112A-29
	105A-13	01550-0820A	482A-2		180A-10
	350A-20	01550-0835A	420A-11	04211-13189	104A-6
	350B-20		420B-10		105A-6
	350C-20		420C-11		107A-5
	350D-20		420D-10	04221-04089	212A-7
	350E-20		420E-11	04221-08149	201A-28
	350F-20		420F-10	07120-0612A	127A-5
	407A-13		420G-11		163A-35
	427A-4		420H-11		172A-16
	427B-4		420J-11	07120-0890A	108A-7
	444A-19	01550-1050A	104A-25	07130-0510A	212A-38
	444B-17	01550-1070A	104A-26	07130-0512A	303A-6
	444C-19	01550-1235A	407A-7		530A-8
	444D-17	02112-0525B	355A-4		530B-8
	444E-19	02112-0545B	355A-2		530C-8
	444F-17	02112-0612A	112A-8		530D-10
	444G-19		206A-40		530E-10
	444H-19	02122-0616B	104A-18		530F-10
	444J-19		105A-18		550A-8
	533A-6	02122-0630A	505A-13		550B-8
	539A-18	02142-0516A	415A-8		550C-8
01550-0616A	185A-7		415A-14		550D-8
	187A-20	02142-0520A	415A-9		550E-8
	534A-14		415A-15		550F-8
01550-0620A	312A-9	02142-0616A	339A-13	07130-0525B	467A-3
	312B-9		558A-27	07130-0612A	187A-10
	312C-9	03211-0414B	334A-3		206A-41
	312D-9		334A-7	07130-0620A	127A-15
	312E-9		334A-13	07130-0625A	127A-14
	312F-9		334A-17		170A-2
	534A-15	03211-0416A	339A-9	07130-0665A	201A-29
	444A-14	03241-0516B	423A-19	07130-0670A	201A-30
	444B-12		423B-19	07130-0825A	163A-5
	444C-14		423C-19	07130-0840B	401A-19
	444D-12		423D-19		401A-20
	444E-14		423E-19	07130-1016B	420A-26
	444F-12		423F-19		420B-25
	444G-14		423G-19		420C-26
	444H-14		423H-19		420D-25
	444J-14		423J-19		420E-21
01550-0812A	108A-19	03511-0516A	155A-17		420F-20
01550-0816A	420A-7	03541-0512A	481A-26		420G-26
	420B-6		481A-27		420H-26

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
	420J-21		550F-23	09103-10226	108A-26
08112-63030	127A-22	08322-0106A	558A-20	09103-10392	535A-17
08113-69050	212A-11	08322-0106B	474A-7	09103-10428	543A-18
08211-06141	212A-15	08322-0108A	108A-9	09103-12016	108A-27
08310-00067	301A-12	08331-31109	170A-6	09103-14001	303A-4
08310-0006A	212A-34	08331-3112A	212A-35	09106-05023	212A-39
08316-1005A	334A-10	08331-3114A	212A-23	09106-06075	104A-28
	334A-19	08331-3118A	407A-11		105A-26
	339A-16	08331-31409	120A-15		108A-16
08316-1006A	104A-11	08331-31509	170A-13	09106-06078	163A-18
	105A-12	08332-1104A	415A-29	09106-06120	303A-7
	107A-8	08332-1106A	415A-18	09106-07021	104A-23
	140C-23	08332-1108A	180A-7		105A-23
	140F-23	08361-3506A	301A-13	09106-08106	122A-5
	163A-36		301A-15	09106-08131	415A-27
	312A-6	09100-08287	541A-13	09106-08136	108A-8
	312B-6	09103-06213	112A-5	09106-08142	108A-3
	312C-6		180A-8	09106-08150	415A-3
	312D-6	09103-06214	112A-14	09106-08160	530A-10
	312E-6		112A-22		530B-10
08316-1008A	312F-6	09103-06220	104A-14		530C-10
	505A-7		105A-10		530D-16
	104A-8	09103-06231	312A-11		530E-16
	105A-8		312B-11		530F-16
	163A-24		312C-11		550A-6
08316-1606B	541A-14		312D-11		550B-6
	467A-6		312E-11		550C-6
	467A-12		312F-11		550D-13
08319-2106A	472A-6	09103-06239	180A-9		550E-13
08319-3106B	444A-16	09103-06257	112A-6		550F-13
	444B-14	09103-06261	112A-23	09106-08162	163A-25
	444C-16	09103-06263	112A-15	09106-08164	163A-20
	444D-14	09103-06266	104A-3	09106-08178	163A-4
	444E-16		105A-3	09106-08197	163A-10
	444F-14	09103-06283	482A-5	09108-06096	104A-10
	444G-16	09103-06314	112A-26		105A-11
	444H-16	09103-08357	350A-18	09108-06124	107A-6
08319-3110A	444J-16		350B-18	09108-08143	104A-7
	108A-28		350C-18		105A-7
	524A-16		350D-18	09111-06041	212A-14
	524B-16		350E-18	09111-06072	541A-10
	524C-16		350F-18	09111-06085	187A-13
	524D-16	09103-08512	412A-2	09111-06107	541A-16
	524E-16		412B-2	09111-06116	558A-16
	524F-16		412C-2	09111-10058	407A-2
	550A-20		412D-2	09116-06165	474A-3
	550B-20		412E-2	09116-06183	312A-27
	550C-20		412F-2		312B-27
	550D-23	09103-10033	543A-16		312C-27
	550E-23	09103-10205	108A-25		312D-27

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
09118-06097	312E-27	09139-05092	406A-5	09148-05038	481A-21
	312F-27	09139-06027	472A-3	09148-05045	483A-15
	185A-5	09139-06029	558A-10	09148-05052	406A-7
	09118-08152-A05	09139-06120	445A-11		423A-18
09119-06109	460A-5		481A-24		423B-18
	460B-5	09139-06126	482A-7		423C-18
	460C-5	09139-06128	163A-15		423D-18
	460D-5	09139-06144	406A-6		423E-18
	460E-5	09139-06172	423A-16		423F-18
	460F-5		423B-16		423G-18
	460G-5		423C-16		423H-18
	460H-5		423D-16		423J-18
	460J-5		423E-16		474A-6
09125-06060	541A-18		423F-16		481A-6
09125-06122	212A-10		423G-16		481A-22
09126-06011	127A-25		423H-16	09148-06020	481A-3
	206A-39	09139-06181	423J-16	09159-06096	312A-12
09127-06023	462A-7		420A-21		312B-12
	462B-7		420B-20		312C-12
	462C-7		420C-21		312D-12
	462D-7		420D-20		312E-12
	462E-7		420E-16		312F-12
09128-06013	462F-7		420F-15		339A-11
	312A-4		420G-21		339A-14
	312B-4		420H-21	09159-06100	163A-33
	312C-4	09139-06190	420J-16	09159-10115	543A-17
	312D-4		444A-7	09159-12056	108A-29
	312E-4		444B-5		543A-4
	312F-4		444C-7		543A-7
09136-05062	333A-9		444D-5		543A-12
09139-05074	401A-12		444E-7	09159-20004	206A-46
	423A-17		444F-5	09159-20006	541A-8
	423B-17		444G-7	09159-24010	201A-15
	423C-17		444H-7	09160-05501	339A-2
	423D-17		444J-7	09160-06012	444A-11
	423E-17	09139-06192	444A-10		444B-9
	423F-17		444B-8		444C-11
	423G-17		444C-10		444D-9
	423H-17		444D-8		444E-11
	423J-17		444E-10		444F-9
09139-05091	445A-5		444F-8		444G-11
	444A-21		444G-10		444H-11
	444B-19		444H-10		444J-11
	444C-21		444J-10	09160-06055	163A-19
	444D-19	09139-08016	352A-3	09160-06109	534A-11
	444E-21		352B-3	09160-06130	472A-4
	444F-19	09139-10003	401A-3	09160-06131	462A-8
	444G-21	09140-06025	212A-31		462B-8
	444H-21	09140-16001	127A-20		462C-8
	444J-21	09140-22012	120A-17		462D-8

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
09160-08043	462E-8		412C-4		427B-7
	462F-8		412D-4	09259-36027	112A-16
	460A-6		412E-4	09261-04009	170A-5
	460B-6		412F-4	09261-06002	170A-12
	460C-6	09180-06195	312A-10	09262-10016	180A-6
	460D-6		312B-10	09262-20082	206A-30
	460E-6		312C-10	09262-20139	206A-9
	460F-6		312D-10	09262-25006	127A-23
	460G-6		312E-10	09262-25073	206A-10
	460H-6		312F-10	09262-25167	530A-3
	460J-6	09180-06278	339A-10		530B-3
09160-08146	163A-23	09180-06290	185A-4		530C-3
09160-12011	212A-32	09180-06306	472A-5		530D-3
09160-12037	543A-19	09180-06331	534A-12		530E-3
09160-15045	201A-31	09180-06345	312A-26		530F-3
09160-18022	407A-9		312B-26	09262-28052	550A-3
09160-25009	206A-47		312C-26		550B-3
09160-25056	201A-16		312D-26		550C-3
09160-25070	550A-11		312E-26		550D-10
	550B-11		312F-26		550E-10
	550C-11	09180-06356	462A-9		550F-10
	550D-24		462B-9	09262-28053	206A-31
	550E-24		462C-9	09262-32022	550A-16
	550F-24		462D-9		550B-16
09160-25074	201A-2		462E-9		550C-16
09160-27008	206A-24		462F-9		550D-20
09161-10009	536A-4	09180-08152	163A-7		550E-20
	539A-14	09180-08156	163A-21		550F-20
	558A-26	09180-12140	122A-3	09263-15003	201A-33
09164-08015	524A-22	09181-10158	170A-4	09263-17046	543A-14
	524B-22	09181-10195	122A-8	09263-20070	541A-3
	524C-22	09181-14167	212A-19	09263-20074	543A-9
	524D-22	09181-16212	127A-21	09263-22068	206A-15
	524E-22	09181-20251	206A-28	09263-27013	541A-4
	524F-22	09181-22167	206A-8	09263-35013	201A-3
09164-22007	120A-18	09181-22223	206A-29	09267-30010	524A-3
09164-24008	201A-17	09181-25223	201A-18		524A-17
09168-06023	104A-13	09200-06068	558A-19		524B-3
	105A-14	09206-08001	104A-2		524B-17
09168-06026	112A-10		105A-2		524C-3
09168-08016	108A-20	09206-12002	122A-2		524C-17
09168-12017	187A-24	09208-06007	415A-28		524D-3
09168-12018	127A-7	09208-08019	415A-16		524D-17
09168-14002	101A-15	09247-14036	108A-23		524E-3
	108A-24	09248-14011	112A-18		524E-17
	112A-19	09248-16012	108A-21		524F-3
09168-16002	108A-22	09250-06015	524D-23		524F-17
09169-06082	406A-8		524E-23	09280-04004	108A-11
09169-08049	412A-4		524F-23		108A-15
	412B-4	09251-07003	427A-7	09280-05007	108A-17

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
09280-12009	108A-13		481A-20		427B-2
09280-13004	170A-8		482A-8	09401-12404	427A-9
09280-17003	112A-31		483A-9		427B-9
09280-17004	206A-11	09320-10051	185A-3		558A-18
09280-18008	187A-9	09320-10066	533A-5	09401-12414	187A-22
09280-19005	104A-29	09320-12049	163A-22	09401-14301	155A-10
	105A-27	09320-12077	163A-8	09401-22405	155A-20
09280-24010	206A-48	09320-20010	445A-10	09402-28513	187A-4
09280-33004	101A-16	09321-10012	505A-3	09402-35501	187A-5
	112A-17	09329-18001	185A-9	09403-06324	536A-7
09280-55005	101A-17	09352-13162-010	420A-17	09403-07334	536A-10
	104A-17		420B-16	09403-11307	163A-26
	105A-17		420C-17	09403-16412	536A-8
09280-85001	312A-24		420D-16	09404-06429	180A-12
	312B-24		420G-17		334A-21
	312C-24		420H-17		350A-22
	312D-24	09352-42703-600	180A-11		350A-27
	312E-24	09360-10062	536A-1		350B-22
	312F-24		536A-2		350B-27
09283-06008	201A-34		539A-13		350C-22
09283-10005	180A-4		558A-25		350C-27
09283-14005	212A-20	09360-10064	536A-3		350D-22
09283-38028	206A-32	09367-06007	420A-15		350D-27
09284-37001	550A-4		420B-14		350E-22
	550B-4		420C-15		350E-27
	550C-4		420D-14		350F-22
	550D-11		420G-15		350F-27
	550E-11		420H-15	09407-10404	185A-11
	550F-11	09367-06009	427A-10	09407-14403	350A-14
09285-32004	530A-4		427B-10		350B-14
	530B-4	09367-08005	420A-30		350C-14
	530C-4		420B-29		350D-14
	530D-4		420C-30		350E-14
	530E-4		420D-29		350F-14
	530F-4		420E-25	09407-14407	163A-42
09285-39001	550A-17		420F-24		310A-8
	550B-17		420G-30		350A-12
	550C-17		420H-30		350B-12
	550D-21		420J-25		350C-12
	550E-21	09380-27001	206A-12		350D-12
	550F-21		206A-33		350E-12
09289-05015	126A-10		206A-34		350F-12
09320-04009	163A-39		206A-35		352A-5
09320-07014	333A-8	09381-22002	120A-11		352B-5
09320-08028	445A-6	09401-06101	140C-20		355A-5
	481A-11		140F-20		420A-31
	482A-6	09401-08411	187A-15		420B-30
09320-08066	163A-14	09401-10410	140C-21		420C-31
09320-08501	534A-13		140F-21		420D-30
09320-09016	481A-8	09401-11413	427A-2		420G-31

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
	420H-31		334A-14		
09407-17403	350A-13		334A-18		
	350B-13	09471-12188	333A-5		
	350C-13	09471-12216	333A-7		
	350D-13	09471-12222	333A-6		
	350E-13	09481-03501	350A-2		
	350F-13		350B-2		
	427A-5		350C-2		
	427B-5		350D-2		
09407-18402	427A-16		350E-2		
	427B-16		350F-2		
09408-00200	140C-24	09481-10504	350A-3		
	140F-24		350B-3		
09408-00266	534A-3		350C-3		
09408-00307	534A-6		350D-3		
09409-06314	423A-23		350E-3		
	423B-23	09481-15504	350F-3		
	423C-23		350A-4		
	423D-23		350B-4		
	423E-23		350C-4		
	423F-23		350D-4		
	423G-23		350E-4		
	423H-23		350F-4		
	423J-23	09481-25504	350A-5		
	481A-23		350B-5		
09409-06314-5PK	481A-25		350C-5		
09409-06329	185A-10		350D-5		
09409-08326	481A-28		350E-5		
	423A-21		350F-5		
	423B-21	09481-30101	312A-3		
	423C-21		312B-3		
	423D-21		312C-3		
	423E-21		312D-3		
	423F-21		312E-3		
	423G-21		312F-3		
	423H-21	09482-00635	104A-15		
	423J-21		105A-15		
09420-04008	303A-5	09493-20014	108A-14		
09420-06001	120A-19	09493-28010	108A-10		
09421-04004	127A-18	09811-00173	474A-13		
09440-07001	120A-16	09812-00006	474A-14		
09440-17009	212A-21	09813-00030	474A-16		
09443-14058	407A-4	09813-00031	474A-15		
09443-19011	407A-5	09814-00015	474A-17		
09444-20001	212A-22	09814-00016	474A-18		
09448-18022	415A-17				
09448-41005	407A-10				
09471-12140	339A-7				
09471-12186	334A-4				
	334A-8				

SUZUKI DL1000(X)AL8 PARTS CATALOGUE

SUZUKI MOTOR CORPORATION All rights reserved

No part of this document may be reproduced or transmitted in any form or by any means, electronic or mechanical, for any purpose, without the express written permission of Suzuki Motor Corporation.

SUZUKI MOTOR CORPORATION

Service Material & Training Group, Service Material In-House Production Dept.
300 Takatsuka, Minami, Hamamatsu, Japan

SUZUKI MOTOR CORPORATION

PRINTED IN JAPAN

9900B-31348-000