
2. Outline drawings



Reference for maintenance space

Maintenance cover for - Cores - Air filters

150 to 250

Accessory parts

More than 750

150 to 250

Maintenance cover for fan
(480 X 258)

Maintenance cover

3. Before installation

- Shutter cover cartons should be removed just before connecting duct. If the shutter move freely, it could be damaged during the installation.
- If carrying the product into the building is difficult due to the product's size, it is possible to stand the product up like the picture below.

Control cover upside

A CAUTION

- Before standing the product up, remove the Lossnay cores and filters (See page 5 of the operating instructions.)
- Deep caution is necessary during the carry.
- Vertical installation is prohibited.
- Do not hold flanges during the carrying.
- Do not remove shutter cover cardboards while carrying.

