

sound>play

POWER PLAY HIGH TECH SMART RING
8972



User Guide

INTRODUCTION

Enjoy all the features of TikTok right at your fingertips with the SoundPlay Smart Remote Ring! This Bluetooth-compatible smart ring has a comfortable, ergonomic design that lets you scroll through or like TikTok videos, play/pause, control volume, and take pictures or record videos from up to 30 feet away. The SoundPlay Smart Remote Ring comes with a magnetic charging case that securely holds the ring and quickly charges it for up to 100 hours of TikTok fun!

FEATURES

- Complete TikTok control; lets you scroll through, play, pause, and like TikTok videos.
- Takes pictures and records videos from up to 30 feet away.
- Magnetic charging case for quick, secure charging; charges the ring up to 5 times.
- Lightweight and comfortable design that easily fits on your finger.
- Works with most iPhones, iPads and Android devices.

WHAT'S INCLUDED?

- Smart Remote Ring
- Magnetic Charging Case
- USB-C Charging Cable
- User Guide



Pairing the Smart Remote Ring with Devices

NOTE: The Smart Remote Ring only works with iOS version 15 or above.

- To use the Smart Remote Ring with an iOS device such as an iPhone or iPad, Assistive Touch needs to be turned on.
- To turn Assistive Touch on, go to settings > Accessibility > Touch and turn Assistive Touch mode ON.



- Keep your device and the ring within 3 ft. of each other for pairing.
- Press and hold the Power Button to turn the smart ring on. It will enter pairing mode and the Ring Light Indicator will alternate flashing red and blue.
- Go to the Bluetooth settings on your device, search and select "Tzumi Smart Ring" from the devices list, and finish the pairing process.

NOTE: After successfully pairing, your devices will remember each other. No pairing will be needed next time.

TIKTOK MODE

Up Button

1. Short press to go back to the previous video.
2. Press and hold to raise the volume.
3. Double press to go to the Next Page.

Power Button

1. Short press to play/pause or replay a video.
2. Double press to like a video.
3. Press and hold for 1 second to turn off your device's display.

Down Button

1. Short press to go to the next video.
2. Press and hold to turn the volume down.
3. Double press to go back to the Previous Page.

PHOTOGRAPH MODE

- Open the camera app on your device and select Camera or Video.
- Press and hold the Up and Down buttons for 2 seconds to take photos or start/end video recordings.

CHARGING THE SMART RING AND CASE

Both the Smart Remote Ring and charging case have a rechargeable internal battery.

- To charge the Smart Remote Ring, place it in the charging case.
- The Charging Case Indicator will light up blue while the ring is charging, and turn off once it is fully charged.
- When the ring detects that its battery power is low, it will emit a low power alarm, and its charging indicator light will slowly flash red. When the battery level is critically low, it will automatically shut down.
- To charge the case, plug one end of the included USB-C cable into the case's charging port, and the other end into a USB power source. The Charging Case Indicator will light up red while the case is charging, and turn off once it's fully charged.

CLEANING AND CARE

- If your Smart Remote Ring appears to need cleaning, wipe its surface down with a soft, dry cloth.
- Never use abrasive cleaning agents or chemicals.
- Wipe off any accumulated dust periodically.

IMPORTANT SAFETY INSTRUCTIONS

Be sure to read all the safety precautions and warnings below before attempting to use your Smart Remote Ring.

- Do not strike, drop, or apply strong pressure to the Smart Remote Ring with sharp or heavy objects. Strong impacts and shocks may cause irreversible damage to the unit.
- Do not use the product for anything other than its intended use.
- This product is not a toy and should never be left unattended with children.
- Do not attempt to disassemble or modify this product in any way or try to repair it by yourself.
- Keep the ring away from all heat sources, including direct sunlight. Do not expose it to humidity, water, or any other liquid.
- Do not use the ring if it is wet or damp. This unit is not waterproof nor water-resistant.
- If you do not use the Smart Remote Ring for long periods of time, be sure to store it in a dry, clean place, away from dust, dirt, and other debris.

SPECIFICATIONS:

- Bluetooth Version: Version 5.1
- Ring Battery: 25mAh
- Charging Case Battery: 200mAh
- Charging Time: 1 hr. (Smart Ring); 1.5 hr. (Case)
- Size: 1.7 x 1.5 x 0.98 in. (4.2 x 3.7 x 2.5 cm)
- Weight: 0.19 lb. (85.2 g)

CUSTOMER SUPPORT:

If you have any questions about using the SoundPlay Smart Remote Ring, we are here to help. Call or email us and an experienced customer support representative will be happy to assist you: support@tzumi.com or 1-855-60-TZUMI.



SoundPlay Smart Remote Ring. Distributed by tzumi Inc. NY, NY, 10016.
©Copyright 2023 tzumi Inc. All Rights Reserved. Made in China. All pictures shown are for illustration purposes only. Actual product may vary due to product enhancement. All other trademarks and trade names on this package are those of their respective owners. Subject to change without prior notice.

FCC Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
-- Reorient or relocate the receiving antenna.
-- Increase the separation between the equipment and receiver.
-- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
-- Consult the dealer or an experienced radio/TV technician for help
This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.